

Modem-HOWTO

Table of Contents

<u>Modem-HOWTO</u>	1
David S.Lawyer mailto:dave@lafn.org	1
1. Introduction	1
2. Modems for a Linux PC	1
3. Modem Pools	1
4. Serial Port and Modem Basics	1
5. Configuring Overview	2
6. Locating the Serial Port: IO address, IROs	2
7. Configuring the Serial Driver (high-level) "stty"	2
8. Modem Configuration (excluding serial port)	2
9. Serial Port Devices /dev/ttyS2, (or /dev/ttys/2) etc.	2
10. Interesting Programs You Should Know About	3
11. Trying Out Your Modem (Dialing Out)	3
12. Dial-In	3
13. Uugetty for Dial-In (from the old Serial-HOWTO)	3
14. What Speed Should I Use with My Modem?	3
15. Communications Programs And Utilities	3
16. Two Modems (Modem Doubling)	4
17. Troubleshooting	4
18. Flash Upgrades	4
19. Other Sources of Information	4
20. Appendix A: How Analog Modems Work (technical) (unfinished)	5
21. Appendix B: (Reserved for future use)	5
22. Appendix C: "baud" vs. "bps"	5
23. Appendix D: Terminal Server Connection	5
24. Appendix E: Digital Modems: ISDN, DSL, RAS	5
25. Appendix F: Leased Line Modems	5
26. Appendix G: Fax pixels (dots)	5
27. Appendix H: Antique Modems	5
1. Introduction	5
1.1 DSL, Cable, and ISDN Modems in other HOWTOs	6
1.2 Also not covered: PCMCIA Modems, PPP	6
1.3 Copyright, Disclaimer, Trademarks, & Credits	6
Copyright	6
Disclaimer	6
Trademarks	7
Credits	7
1.4 Contacting the Author	7
1.5 New Versions of this HOWTO	7
1.6 New in Recent Versions	7
1.7 What is a Modem ?	8
1.8 Does My Computer Contain a Modem ?	8
1.9 Quick Install	8
External Modem Install	8
Internal Modems (ISA, PCI and AMR)	8
Internal Modems: Manual configuration	9
ISA Modems: What IOs and IROs may be used?	9
Both PCI and ISA: Use setserial to tell the serial driver	9

Table of Contents

Modem-HOWTO

Use MS Windows to set the BIOS (A last resort method)	9
All Modems	10
2. Modems for a Linux PC	10
2.1 External vs. Internal	10
2.2 Is a Driver Needed ?	11
2.3 External Modems	11
PnP External Modems	11
Cabling & Installation	11
What the Lights (LED's) Mean (for some external modems)	11
2.4 Internal Modems	12
2.5 Software-based Modems (winmodems, linmodems)	12
Introduction to software modems (winmodems)	12
Linmodems	13
Linmodem sites and documentation	13
Software-based modem types	13
Is this modem a software modem?	14
Should I get a software modem?	14
2.6 PCI Modems	15
2.7 AMR Modems	15
2.8 USB Modems	15
2.9 Which Internal Modems might not work with Linux	15
MWave and some DSP Modems	15
Rockwell (RPI) Drivers	16
3. Modem Pools	16
3.1 Introduction	16
3.2 Analog Modem Pools, Multi-modem Cards	17
3.3 Digital Modems, RAS	17
4. Serial Port and Modem Basics	18
4.1 Modem Converts Digital to Analog (and conversely)	18
4.2 What is a Serial Port ?	19
Intro to Serial	19
Pins and Wires	19
Internal Modem Contains Serial Port	19
4.3 IO Address & IRQ	20
4.4 Names: ttyS0, ttyS1, etc.	20
4.5 Interrupts	20
4.6 Data Compression (by the Modem)	21
4.7 Error Correction	22
4.8 Data Flow (Speeds)	22
4.9 Flow Control	23
Example of Flow Control	23
Hardware vs. Software Flow Control	24
Symptoms of No Flow Control	24
Modem-to-Modem Flow Control	24
4.10 Data Flow Path: Buffers	24
4.11 Modem Commands	25
4.12 Serial Driver Module	25

Table of Contents

Modem-HOWTO

5. Configuring Overview	26
6. Locating the Serial Port: IO address, IRQs	26
6.1 IO & IRQ Overview	26
6.2 PCI Bus Support	28
Introduction	28
Requesting that future drivers support your serial port	28
More info on PCI	28
6.3 Common mistakes made re low-level configuring	28
6.4 IRQ & IO Address Must be Correct	29
6.5 What is the IO Address and IRQ per the driver ?	29
Introduction	29
I/O Address & IRQ: Boot-time messages	29
The /proc directory and setserial	30
6.6 What is the IO Address & IRQ of my Serial Port Hardware?	31
Introduction	31
PCI: What IOs and IRQs have been set?	31
PCI: Enabling a disabled port	31
ISA PnP ports	32
Finding a port that is not disabled (ISA, PCI, PnP, non-PnP)	32
Exploring via MS Windows (a last resort)	32
6.7 Choosing Serial IRQs	32
IRQ 0 is not an IRQ	33
Interrupt sharing, Kernels 2.2+	33
What IRQs to choose?	33
6.8 Choosing Addresses --Video card conflict with ttyS3	34
6.9 Set IO Address & IRQ in the hardware (mostly for PnP)	34
Using a PnP BIOS to IO-IRQ Configure	35
6.10 Giving the IRQ and IO Address to Setserial	35
7. Configuring the Serial Driver (high-level) "stty"	36
7.1 Introduction	36
7.2 Hardware flow control (RTS/CTS)	36
7.3 Speed Settings	36
7.4 Ignore CD Setting: clocal	36
7.5 What is stty ?	37
8. Modem Configuration (excluding serial port)	37
8.1 Finding Your Modem	37
8.2 AT Commands	37
8.3 Init Strings: Saving and Recalling	38
Where is my "init string" so I can modify it ?	39
8.4 Other AT Modem Commands	39
8.5 Blacklisting	40
8.6 What AT Commands are Now Set in my Modem?	40
8.7 Modem States (or Modes)	40
9. Serial Port Devices /dev/ttyS2, (or /dev/ttys/2) etc.	41
9.1 Devfs (The new Device File System)	41
9.2 Serial Port Device Names & Numbers	41
9.3 USB (Universal Serial Bus) Ports	42

Table of Contents

Modem-HOWTO

9.4 Link ttySN to /dev/modem	42
9.5 cua Device Obsolete	42
10. Interesting Programs You Should Know About	42
10.1 What is setserial ?	42
Introduction	43
Probing	44
Boot-time Configuration	45
Configuration Scripts/Files	45
Edit a script (required prior to version 2.15)	45
New configuration method using /etc/serial.conf	46
IRQs	47
Laptops: PCMCIA	47
10.2 What is isapnp ?	47
10.3 What is wvdialconf ?	48
11. Trying Out Your Modem (Dialing Out)	48
11.1 Are You Ready to Dial Out ?	48
11.2 Dialing Out with wvdial	48
11.3 Dialing Out with Minicom	49
11.4 Dialing Out with Kermit	49
12. Dial-In	50
12.1 Dial-In Overview	50
12.2 What Happens when Someone Dials In ?	51
12.3 56k Doesn't Work for Dialin	52
12.4 Getty	52
Introduction to Getty	52
Getty "exits" after login (and can respawn)	53
About mgetty	53
About uugetty	53
About getty em	53
About agetty	54
About mingetty, and fbgetty	54
12.5 Why "Manual" Answer is Best	54
12.6 Dialing Out while Waiting for an Incoming Call	54
12.7 Ending a Dial-in Call	55
Caller logs out	55
When DTR drops (is negated)	55
Caller hangs up	56
12.8 Dial-in Modem Configuration	56
12.9 Callback	57
12.10 Voice Mail	57
12.11 Simple Manual Dial-In	57
12.12 Complex GUI Dial-In, VNC	58
12.13 Interoperability with MS Windows	58
13. Uugetty for Dial-In (from the old Serial-HOWTO)	59
13.1 Installing getty ps	59
13.2 Setting up uugetty	59
Modern Modems	60

Table of Contents

Modem-HOWTO

Old slow modems	60
Login Banner	60
13.3 Customizing uugetty	61
14. What Speed Should I Use with My Modem?	61
14.1 Speed and Data Compression	62
14.2 Where do I Set Speed ?	62
14.3 Can't Set a High Enough Speed	62
Speeds over 115.2k	62
How speed is set in hardware: the divisor and baud base	63
Setting the divisor, speed accounting	63
Crystal frequency is higher than baud base	64
14.4 Speed Table	64
15. Communications Programs And Utilities	64
15.1 Minicom vs. Kermit	64
15.2 List of Communication Software	65
Least Popular Dialout	65
Most Popular Dialout	65
Fax	65
Voicemail Software	65
Dial-in (uses getty)	66
Other	66
15.3 SLiRP and term	66
15.4 MS Windows	66
16. Two Modems (Modem Doubling)	67
16.1 Introduction	67
16.2 Modem Bonding	67
EOL	67
Multilink	67
17. Troubleshooting	67
17.1 My Modem is Physically There but Can't be Found	67
No response to AT	68
17.2 "Modem is busy"	69
17.3 "You are already online! Hang up first." (from minicom)	69
17.4 I can't get near 56k on my 56k modem	69
17.5 Uploading (downloading) files is broken/slow	69
17.6 For Dial-in I Keep Getting "line NNN of inittab invalid"	69
17.7 I Keep Getting: ``Id "S3" respawning too fast: disabled for 5 minutes!"	70
17.8 My Modem is Hosed after Someone Hangs Up, or uugetty doesn't respawn	70
17.9 NO DIALTONE	70
17.10 NO CARRIER	70
17.11 uugetty Still Doesn't Work	71
17.12 (The following subsections are in both the Serial and Modem HOWTOs)	71
17.13 My Serial Port is Physically There but Can't be Found	71
17.14 Extremely Slow: Text appears on the screen slowly after long delays	72
17.15 Somewhat Slow: I expected it to be a few times faster	72
17.16 The Startup Screen Show Wrong IRQs for the Serial Ports	73
17.17 "Cannot open /dev/ttyS?: Permission denied"	73

Table of Contents

Modem-HOWTO

17.18 "Operation not supported by device" for ttyS?	73
17.19 "Cannot create lockfile. Sorry"	74
17.20 "Device /dev/ttyS? is locked."	74
17.21 "/dev/tty? Device or resource busy"	74
17.22 "Input/output error" from setserial or stty	75
17.23 Overrun errors on serial port	75
17.24 Modem doesn't pick up incoming calls	75
17.25 Port get characters only sporadically	75
17.26 Troubleshooting Tools	76
18. Flash Upgrades	76
19. Other Sources of Information	77
19.1 Misc	77
19.2 Books	77
19.3 HOWTOs	77
19.4 Usenet newsgroups	78
19.5 Web Sites	78
20. Appendix A: How Analog Modems Work (technical) (unfinished)	78
20.1 Modulation Details	78
Intro to Modulation	78
Frequency Modulation	78
Amplitude Modulation	79
Phase Modulation	79
Combination Modulation	79
20.2 56k Modems (V.90, V.92)	80
20.3 Full Duplex on One Circuit	81
20.4 Echo Cancellation	82
21. Appendix B: (Reserved for future use)	82
22. Appendix C: "baud" vs. "bps"	82
22.1 A simple example	82
22.2 Real examples	83
23. Appendix D: Terminal Server Connection	83
24. Appendix E: Digital Modems: ISDN, DSL, RAS	84
24.1 Introduction	84
24.2 ISDN "Modems"	84
24.3 Digital Subscriber Line (DSL)	84
24.4 56k Digital-Modems	84
25. Appendix F: Leased Line Modems	85
26. Appendix G: Fax pixels (dots)	85
27. Appendix H: Antique Modems	85
27.1 Introduction	85
27.2 Old CCITT (ITU) and Bell Protocols	86
27.3 Historical Overview	86
Teletypes and dumb terminals	86
PCs and BBSs	86
The Internet	86
Speeds	87
27.4 Proprietary protocols, etc.	87

Table of Contents

Modem-HOWTO

<u>27.5 Autobauding</u>	87
<u>27.6 Modem-to-modem Speed</u>	87
<u>27.7 Modem-to-serial port Speed</u>	88
<u>Same speed required</u>	88
<u>Equalizing speed</u>	88
<u>Use "CONNECT" message to set speed</u>	88
<u>Setting modem-to-modem speeds by the serial speed</u>	89
<u>Manual bauding</u>	89
<u>Unsupported speeds</u>	90
<u>Modern modems, speed buffering</u>	90
<u>27.8 Before AT Commands</u>	90
<u>27.9 Acoustic-Coupling</u>	90
<u>27.10 Data Compression and Error Correction</u>	90

Modem–HOWTO

David S.Lawyer <mailto:dave@lafn.org>

v0.25, September 2002

*Help with selecting, connecting, configuring, trouble–shooting, and understanding analog modems for a PC.
Limited coverage of V.90 digital modems.*

1. [Introduction](#)

- [1.1 DSL, Cable, and ISDN Modems in other HOWTOs](#)
- [1.2 Also not covered: PCMCIA Modems, PPP](#)
- [1.3 Copyright, Disclaimer, Trademarks, & Credits](#)
- [1.4 Contacting the Author](#)
- [1.5 New Versions of this HOWTO](#)
- [1.6 New in Recent Versions](#)
- [1.7 What is a Modem ?](#)
- [1.8 Does My Computer Contain a Modem ?](#)
- [1.9 Quick Install](#)

2. [Modems for a Linux PC](#)

- [2.1 External vs. Internal](#)
- [2.2 Is a Driver Needed ?](#)
- [2.3 External Modems](#)
- [2.4 Internal Modems](#)
- [2.5 Software–based Modems \(winmodems, linmodems\)](#)
- [2.6 PCI Modems](#)
- [2.7 AMR Modems](#)
- [2.8 USB Modems](#)
- [2.9 Which Internal Modems might not work with Linux](#)

3. [Modem Pools](#)

- [3.1 Introduction](#)
- [3.2 Analog Modem Pools, Multi–modem Cards](#)
- [3.3 Digital Modems, RAS](#)

4. [Serial Port and Modem Basics](#)

- [4.1 Modem Converts Digital to Analog \(and conversely\)](#)
- [4.2 What is a Serial Port ?](#)
- [4.3 IO Address & IRQ](#)
- [4.4 Names: ttyS0, ttyS1, etc.](#)
- [4.5 Interrupts](#)

- [4.6 Data Compression \(by the Modem\)](#)
- [4.7 Error Correction](#)
- [4.8 Data Flow \(Speeds\)](#)
- [4.9 Flow Control](#)
- [4.10 Data Flow Path: Buffers](#)
- [4.11 Modem Commands](#)
- [4.12 Serial Driver Module](#)

5. Configuring Overview

6. Locating the Serial Port: IO address, IRQs

- [6.1 IO & IRQ Overview](#)
- [6.2 PCI Bus Support](#)
- [6.3 Common mistakes made re low-level configuring](#)
- [6.4 IRQ & IO Address Must be Correct](#)
- [6.5 What is the IO Address and IRQ per the driver ?](#)
- [6.6 What is the IO Address & IRQ of my Serial Port Hardware?](#)
- [6.7 Choosing Serial IRQs](#)
- [6.8 Choosing Addresses --Video card conflict with ttyS3](#)
- [6.9 Set IO Address & IRQ in the hardware \(mostly for PnP\)](#)
- [6.10 Giving the IRQ and IO Address to Setserial](#)

7. Configuring the Serial Driver (high-level) "stty"

- [7.1 Introduction](#)
- [7.2 Hardware flow control \(RTS/CTS\)](#)
- [7.3 Speed Settings](#)
- [7.4 Ignore CD Setting: clocal](#)
- [7.5 What is stty ?](#)

8. Modem Configuration (excluding serial port)

- [8.1 Finding Your Modem](#)
- [8.2 AT Commands](#)
- [8.3 Init Strings: Saving and Recalling](#)
- [8.4 Other AT Modem Commands](#)
- [8.5 Blacklisting](#)
- [8.6 What AT Commands are Now Set in my Modem?](#)
- [8.7 Modem States \(or Modes\)](#)

9. Serial Port Devices /dev/ttyS2, (or /dev/ttys/2) etc.

- [9.1 Devfs \(The new Device File System\)](#)
- [9.2 Serial Port Device Names & Numbers](#)
- [9.3 USB \(Universal Serial Bus\) Ports](#)
- [9.4 Link ttySN to /dev/modem](#)
- [9.5 cua Device Obsolete](#)

10. Interesting Programs You Should Know About

- [10.1 What is setserial ?](#)
- [10.2 What is isapnp ?](#)
- [10.3 What is wvdialconf ?](#)

11. Trying Out Your Modem (Dialing Out)

- [11.1 Are You Ready to Dial Out ?](#)
- [11.2 Dialing Out with wvdial](#)
- [11.3 Dialing Out with Minicom](#)
- [11.4 Dialing Out with Kermit](#)

12. Dial-In

- [12.1 Dial-In Overview](#)
- [12.2 What Happens when Someone Dials In ?](#)
- [12.3 56k Doesn't Work for Dialin](#)
- [12.4 Getty](#)
- [12.5 Why "Manual" Answer is Best](#)
- [12.6 Dialing Out while Waiting for an Incoming Call](#)
- [12.7 Ending a Dial-in Call](#)
- [12.8 Dial-in Modem Configuration](#)
- [12.9 Callback](#)
- [12.10 Voice Mail](#)
- [12.11 Simple Manual Dial-In](#)
- [12.12 Complex GUI Dial-In, VNC](#)
- [12.13 Interoperability with MS Windows](#)

13. Uugetty for Dial-In (from the old Serial-HOWTO)

- [13.1 Installing getty ps](#)
- [13.2 Setting up uugetty](#)
- [13.3 Customizing uugetty](#)

14. What Speed Should I Use with My Modem?

- [14.1 Speed and Data Compression](#)
- [14.2 Where do I Set Speed ?](#)
- [14.3 Can't Set a High Enough Speed](#)
- [14.4 Speed Table](#)

15. Communications Programs And Utilities

- [15.1 Minicom vs. Kermit](#)
- [15.2 List of Communication Software](#)
- [15.3 SLiRP and term](#)

- [15.4 MS Windows](#)

16. Two Modems (Modem Doubling)

- [16.1 Introduction](#)
- [16.2 Modem Bonding](#)

17. Troubleshooting

- [17.1 My Modem is Physically There but Can't be Found](#)
- [17.2 "Modem is busy"](#)
- [17.3 "You are already online! Hang up first." \(from minicom\)](#)
- [17.4 I can't get near 56k on my 56k modem](#)
- [17.5 Uploading \(downloading\) files is broken/slow](#)
- [17.6 For Dial-in I Keep Getting "line NNN of inittab invalid"](#)
- [17.7 I Keep Getting: ``Id "S3" respawning too fast: disabled for 5 minutes"](#)
- [17.8 My Modem is Hosed after Someone Hangs Up, or uugetty doesn't respawn](#)
- [17.9 NO DIALTONE](#)
- [17.10 NO CARRIER](#)
- [17.11 uugetty Still Doesn't Work](#)
- [17.12 \(The following subsections are in both the Serial and Modem HOWTOs\)](#)
- [17.13 My Serial Port is Physically There but Can't be Found](#)
- [17.14 Extremely Slow: Text appears on the screen slowly after long delays](#)
- [17.15 Somewhat Slow: I expected it to be a few times faster](#)
- [17.16 The Startup Screen Show Wrong IROs for the Serial Ports.](#)
- [17.17 "Cannot open /dev/ttyS?: Permission denied"](#)
- [17.18 "Operation not supported by device" for ttyS?](#)
- [17.19 "Cannot create lockfile. Sorry"](#)
- [17.20 "Device /dev/ttyS? is locked."](#)
- [17.21 "/dev/tty? Device or resource busy"](#)
- [17.22 "Input/output error" from setserial or stty](#)
- [17.23 Overrun errors on serial port](#)
- [17.24 Modem doesn't pick up incoming calls](#)
- [17.25 Port get characters only sporadically](#)
- [17.26 Troubleshooting Tools](#)

18. Flash Upgrades

19. Other Sources of Information

- [19.1 Misc](#)
- [19.2 Books](#)
- [19.3 HOWTOs](#)
- [19.4 Usenet newsgroups](#)
- [19.5 Web Sites](#)

20. Appendix A: How Analog Modems Work (technical) (unfinished)

- [20.1 Modulation Details](#)
- [20.2 56k Modems \(V.90, V.92\)](#)
- [20.3 Full Duplex on One Circuit](#)
- [20.4 Echo Cancellation](#)

21. Appendix B: (Reserved for future use)

22. Appendix C: "baud" vs. "bps"

- [22.1 A simple example](#)
- [22.2 Real examples](#)

23. Appendix D: Terminal Server Connection

24. Appendix E: Digital Modems: ISDN, DSL, RAS

- [24.1 Introduction](#)
- [24.2 ISDN "Modems"](#)
- [24.3 Digital Subscriber Line \(DSL\)](#)
- [24.4 56k Digital-Modems](#)

25. Appendix F: Leased Line Modems

26. Appendix G: Fax pixels (dots)

27. Appendix H: Antique Modems

- [27.1 Introduction](#)
- [27.2 Old CCITT \(ITU\) and Bell Protocols](#)
- [27.3 Historical Overview](#)
- [27.4 Proprietary protocols, etc.](#)
- [27.5 Autobauding](#)
- [27.6 Modem-to-modem Speed](#)
- [27.7 Modem-to-serial port Speed](#)
- [27.8 Before AT Commands](#)
- [27.9 Acoustic-Coupling](#)
- [27.10 Data Compression and Error Correction](#)

1. Introduction

1.1 DSL, Cable, and ISDN Modems in other HOWTOs

This HOWTO covers conventional analog modems for PCs on the ISA, PCI, or USB buses. USB coverage is weak. For other types of modems see:

- DSL-HOWTO (formerly ADSL mini-howto)
- ADSL-Bandwidth-Management-HOWTO
- Cable-Modems-HOWTO (same as Cable Modem Providers HOWTO)
- SuSE ISDN Howto (not a LDP Howto)
<http://brenner.chemietechnik.uni-dortmund.de/doc/sdb/en/html/isdn.html>
- <http://public.swbell.net/ISDN/overview.html> tutorial on ISDN
- ISDN docs in the kernel documentation subdirectory: "isdn".
- <http://www.isdn4linux.de> (1998, old)
- [Appendix D: Other Types of Modems](#)

1.2 Also not covered: PCMCIA Modems, PPP

For modems on the PCMCIA bus see the PCMCIA-HOWTO: PCMCIA serial and modem devices. This HOWTO also doesn't cover PPP (used to connect to the Internet via a modem) or communication programs. Except it does show how to use communication programs to test that your modem works OK and can make phone calls. If you want to use a modem to connect to the Internet then you need to set up PPP. There's a lot of documentation for PPP (including a PPP-HOWTO). More documentation should be found in /usr/doc/ppp, /usr/share/doc/ppp or the like.

1.3 Copyright, Disclaimer, Trademarks, & Credits

Copyright

Copyright (c) 1998-2001 by David S. Lawyer <mailto:dave@lafn.org>

Please freely copy and distribute (sell or give away) this document in any format. Send any corrections and comments to the document maintainer. You may create a derivative work and distribute it provided that you:

1. If it's not a translation: Email a copy of your derivative work (in a format LDP accepts) to the author(s) and maintainer (could be the same person). If you don't get a response then email the LDP (Linux Documentation Project): submit@linuxdoc.org.
2. License the derivative work in the spirit of this license or use GPL. Include a copyright notice and at least a pointer to the license used.
3. Give due credit to previous authors and major contributors.

If you're considering making a derived work other than a translation, it's requested that you discuss your plans with the current maintainer.

Disclaimer

While I haven't intentionally tried to mislead you, there are likely a number of errors in this document. Please let me know about them. Since this is free documentation, it should be obvious that I cannot be held legally responsible for any errors.

Trademarks.

Any brand names (starts with a capital letter) should be assumed to be a trademark). Such trademarks belong to their respective owners.

"Hayes" is a trademark of Microcomputer Products Inc. I use "winmodem" to mean any modem which requires MS-Windows and not in the trademark sense. All other trademarks belong to their respective owners.

Credits

The following is only a rough approximation of how this this document (as of 2000) was created: About 1/4 of the material here was lifted directly from Serial-HOWTO v. 1.11 (1997) by Greg Hankins. <mailto:greg@twoguys.org> (with his permission). About another 1/4 was taken from that Serial-HOWTO and revised. The remaining 1/2 is newly created by the new author: David S. Lawyer <mailto:dave@lafn.org>.

1.4 Contacting the Author

Since I don't follow the many different brands/models of modems please don't email me with questions about them (or suggestions of which one to buy). If you are interested in a certain model (to find out if it works under Linux, etc.) see the huge list at [Web Sites](#). Also, please don't ask me how to configure a modem unless you've looked over this HOWTO and still can't do it. I've no personal experience with software-based modems.

Please let me know of any errors in facts, opinions, logic, spelling, grammar, clarity, links, etc. But first, if the date is over a month or two old, check to see that you have the latest version. Please send me any other info that you think belongs in this document.

1.5 New Versions of this HOWTO

New versions of this Modem-HOWTO come out every few months. The modem situation is rapidly changing (and I'm still learning). Your problem might be solved in the latest version. It will be available to browse and/or download at LDP mirror sites. For a list of such sites see: <http://www.tldp.org/mirrors.html> If you only want to quickly compare the date of this the version v0.25, September 2002 with the date of the latest version go to: <http://www.tldp.org/HOWTO/Modem-HOWTO.html>

1.6 New in Recent Versions

For a full revision history going back to v0.00 see the source file (in linuxdoc format) at <http://www.ibiblio.org/pub/linux/docs/HOWTO/other-formats/sgml/Modem-HOWTO.sgml.gz>.

v0.25 September 2002: Must restart minicom after configuring it unless you used the `-s` option. HCF is not an all-software modem as was incorrectly claimed. Better clarity for "Quick Install" and 56k modems. Does my PC have a modem?

v0.24 June 2002: new callback link, "You are already online" error, fixed several typos reported by Francesco Ronconi

v0.23 January 2002: dropped connection w/V.90, X3 to force dialing if NO DIALTONE, more on USB, wvdial added to "Trying Out Your Modem", major revision to "Antique Modems", several broken links fixed,

better clarity re RAS, digital modems.

1.7 What is a Modem ?

A modem is a device that lets one send digital signals over an ordinary telephone line not designed for digital signals. If telephone lines were all digital then you wouldn't need a modem. It permits your computer to connect to and communicate with the rest of the world. When you use a modem, you normally use a communication program or web browser to utilize the modem and dial-out on a telephone line. Advanced modem users can set things up so that others may phone in to them and use their computer. This is called "dial-in".

There are four basic types of modems for a PC: external, USB, internal and built-in. The external and USB set on your desk outside the PC while the other two types are not visible since they're inside the PC. The external modem plugs into a connector on the back of the PC known as a "serial port". The USB modem plugs into the USB bus cable. See [USB Modems](#). The internal modem is a card that is inserted inside the computer. The built-in modem is part of the motherboard and is thus built into the computer. It's is just like an internal modem except it can't be removed or replaced. As of 2001, built-in modems are primarily for laptops. What is said in this HOWTO regarding internal modems will generally apply also to built-in modems.

For a more detailed comparison see [External vs. Internal](#). When you get an internal, built-in, or USB modem, you also get a dedicated serial port (which can only be used with the modem and not with anything else such as another modem or a printer). In Linux, the serial ports are named ttyS0, ttyS1, etc. (usually corresponding respectively to COM1, COM2, etc. in Dos/Windows). For the new devfs they are all in the /dev/ttys/ directory and named 0, 1, etc. See [Modem & Serial Port Basics](#) for more details on modems and serial ports.

Modems usually include the ability to send Faxes (Fax Modems). See [Fax](#) for a list of fax software. "Voice" modems can work like an automatic answering machine and handle voicemail. See [Voicemail](#).

1.8 Does My Computer Contain a Modem ?

Internal modems usually have a pair of modular telephone jacks on the back of the computer. They should be right next to each other and look like a jack on the wall of a house where a telephone plugs in. Network cards also have modular jacks, but they are seldom in pairs and are slightly wider since they normally have 8 pins. Internal DSL "modems" exist and also have telephone jacks, but I think they are not very common (most are external) as of 2002.

1.9 Quick Install

External Modem Install

With a straight-thru or modem cable, connect the modem to an unused serial port on the PC. Make sure you know the name of the serial port: in most cases COM1 is ttyS0, COM2 is ttyS1, etc. You may need to check the BIOS setup menu to determine this. Plug in the power cord to provide power to the modem. See [All Modems](#) for further instructions.

Internal Modems (ISA, PCI and AMR)

The first thing to do is to make sure that the modem will work under Linux since (as of 2002) many modems don't. See [modem list](#). If the modem is both PnP and directly supported by the serial driver (kernel 2.4 +) then

Modem–HOWTO

there is no configuring for you to do since the Linux serial driver will configure it.

To physically install a modem card, remove the cover of the PC by /removing some screws (perhaps screw size 6–32 in the U.S.). Find a matching vacant slot for it next to the other adapter cards. Before inserting the card in the slot, remove a small cover plate on the back of the PC so that the telephone jacks on the card will be accessible from the rear of the PC. Then carefully align the card with the slot and push the card all the way down into the slot. Attach the card with a mounting screw (usually 3mm, .5mm pitch —don't use the wrong size).

If you have a modem that is not a winmodem (see [Software–based Modems \(winmodems\)](#)) the serial driver may configure it for you and you have nothing to do. This should be noted in the boot–time messages (use `dmesg` to see them or `shift–page–up` after they have flashed by).

Internal Modems: Manual configuration

But if it didn't get automatically assigned a port `ttySx` and an IRQ (or you need to change these values) then you need to configure it yourself. You first need to decide which `ttySx` (or `ttys/x`) to assign it to. Pick a `ttySx` that is not already in use by other serial ports. Then you have the problem of setting an IRQ number and IO address. For PnP modems: If the BIOS has already set these in the physical device (which a PnP BIOS will do if it thinks you don't have a PnP OS) then you need to determine the IRQ and IO address and then tell this to "setserial".

In other cases you may have some choice of IRQs and IO addresses (including the case where you are able to change what the BIOS has set). See [Choosing Serial IRQs](#) and [Choosing Addresses](#). For ISA modems there are standard IO addresses to use (corresponding to the `ttySx`). For example you may find it feasible to use `/dev/ttyS2` at IO address `0x3e8` and IRQ 11. PCI modems seem to use different IO addresses so as not to conflict with ISA modems.

ISA Modems: What IOs and IRQs may be used?

For old modems with jumpers look at the manual (or jumpers if they say). If the BIOS has already configured the ISA modem then "pnpdump —dumppregs" should show it. If you need to set or change them use "isapnp". Use the "pnpdump" to see what changes are possible.

Both PCI and ISA: Use setserial to tell the serial driver

You must find the file where "setserial" is run at boot–time and add a line something like: "setserial `/dev/ttyS2 irq 5 port 0x0b8`". For setserial v2.15 and later the results of running "setserial" on the command line may (or may not) be saved to `/etc/serial.conf` so that it runs each time you boot. See [What is Setserial](#) for more info. See the next subsection [All Modems](#) for further instructions on quick installation.

Use MS Windows to set the BIOS (A last resort method)

If you are using the BIOS to configure you may attempt to use MS Windows9x to "force" the BIOS to set a certain IRQ and/or IO. It can set them into the PnP BIOS's flash memory where they will be used to configure for Linux as well as Windows. See "Plug–and–Play–HOWTO and search for "forced" (occurs in several places). For Windows3.x you can do the same thing using the ICU under Windows 3.x. A few modems have a way to disable PnP in the modem hardware using software (under Windows) that came with the modem.

All Modems

Plug the modem into a telephone line. Then configure a communication program such as minicom or a ppp program (such as wvdial). Set the serial port speed to a baud rate a few times higher than the bit rate of your modem. See [Speed Table](#) for more details on the "best" speeds to use. Tell it the full name of your serial port such as /dev/ttyS1 (or /dev/ttys/1). Set hardware flow control (RTS/CTS).

Minicom is the easiest to set up and to use to test your modem. But if you are lucky you may get ppp to work the first time and not need to bother with minicom. With minicom you may check to see if your modem is there (and ready to dial): Once you've set up minicom, type the command: AT, hit enter and you should see an "OK" response which comes direct from the modem. See [Dialing Out with Minicom](#).

2. [Modems for a Linux PC](#)

2.1 External vs. Internal

A modem for a PC may be either internal or external. The internal one is installed inside of your PC (you must remove screws, etc. to install it) and the external one just plugs into a serial port connector on a PC. Internal modems are less expensive, are less likely to suffer data loss due to buffer overrun, usually use less electricity, and use up no space on your desk.

External modems are usually easier to install and usually require less configuration. They have lights which may give you a clue as to what is happening and aid in troubleshooting. The fact that the serial port and modem can be physically separated also aids in troubleshooting. External modems are easy to move to another computer. If you need to turn the power off to reset your modem (this is seldom necessary) then with an external you don't have to power down the entire PC.

Unfortunately most external modems have no switch to turn off the power supply when not in use and thus are likely to consume a little electricity even when turned off (unless you unplug the power supply from the wall). Each watt they draw usually costs you over \$1/yr. Another possible disadvantage of an external is that you will be forced to use an existing serial port which may not support a speed of over 115,200 bps (although as of late 2000 most new internal modems don't either --but some do). For details [Can't Set a High Enough Speed](#)

Internal modems present a special problem for Linux, but will work just as well as external modems provided you avoid the ones that will work only for MS Windows. Configuring them ranges from very easy (automatically) to difficult depending on both the modem, your skills, and how easy it is to find info about your modem --info that is not all in this HOWTO. Some of the modems will work only under MS Windows due to lack of Linux modem drivers (for software modems). If you buy a new one that you're not sure will work under Linux, try to get an agreement that you can return it for a refund if it doesn't work out.

While most new modems are plug-and-play you have various ways to deal with the PnP configuring:

- The serial driver does it all for you (more likely for a PCI modem)
- Use the "isapnp" program
- Let a PnP BIOS do the configuring

The last 2 items of the above have shortcomings. Isapnp documentation is difficult to understand although reading the Plug-and-Play-HOWTO (long) will aid in understanding it. If you want the PnP BIOS to do the configuring, all you need to do is to make sure that it knows that you don't have a PnP operating system. But it

may not do it correctly and you may need to find out what it's done see [What is set in my serial port hardware?](#).

Many Linux users still say that it's a lot simpler just to get an external modem and plug it in. But if you get the right internal modem it may be just as easy.

2.2 Is a Driver Needed ?

Hardware modems (including all external modems) don't really need any modem driver. But any software modem (winmodem, linmodem) must have a modem driver (if it exists for Linux). The serial port the modem resides on does need a driver and it's supplied either as a Linux serial module or compiled into the kernel. Any serial driver for a PCI Modem should install automatically since they are detected by system software.

Software modems require software to run them and obviously do need a driver. The drivers for MS Windows are *.exe programs which will not run under Linux. So you must use a Linux driver (if it exists). See [Software-based Modems \(winmodems, linmodems\)](#)

2.3 External Modems

PnP External Modems

Many external modems are labeled "Plug and Play" (PnP) but they should all work fine as non-PnP modems. While the serial port itself may need to be configured (IRQ number and IO address) unless the default configuration is OK, an external modem uses no such IRQ/IO configuration. You just plug the modem into the serial port.

How can an external modem be called PnP since it can't be configured by PnP? Well, it has a special PnP identification built into it that can be read (thru the serial port) by a PnP operating system. Such an operating system would then know that you have a modem on a certain port and would also know the id number. If it's a software modem, it could try to locate a driver for it. It could also tell application programs what port your modem is on. (such as /dev/ttyS2 or COM3). But since you don't have such a PnP operating system you may need to configure your application program manually by giving it the /dev id (such as /dev/ttyS2). Some programs can probe for a modem on various ports.

Cabling & Installation

Connecting an external modem is simple compared to connecting most other devices to a serial port that require various types of "null modem" cables (which will not work for modems). Modems use straight through cable, with no pins crossed over. Most computer stores should have this. Make sure you get the correct gender and number of pins. Hook up your modem to one of your serial ports. If you are willing to accept the default IRQ and IO address of the port you connect it to, then you are ready to start your communication program and configure the modem itself.

What the Lights (LED's) Mean (for some external modems)

- TM Test Modem
- AA Auto Answer (If on, your modem will answer an incoming call)
- RD Receive Data line = RxD
- SD Send Data line = TxD

- TR data Terminal Ready = DTR (set by your PC)
- RI Ring Indicator (If on, someone is "ringing" your modem)
- OH Off Hook (If off, your modem has hung up the phone line)
- MR Modem Ready = DSR ??
- EC Error Correction
- DC Data Compression
- HS High Speed (for this modem)

2.4 Internal Modems

An internal modem is installed in a PC by taking off the cover of the PC and inserting the modem card into a vacant slot on the motherboard. There are modems for PCI slots, other modems for the older ISA slots, and ARM software "modems" for the new small AMR slot. Some new PC don't have any ISA slots. Only some newer PCs will have ARM slots. While external modems plug into the serial port (via a short cable) the internal modems have the serial port built into the modem. In other words, the modem card is both a serial port and a modem.

Setting the IO address and IRQ for a serial port was formerly done by jumpers on the card. These are little black rectangular "cubes" about 5x4x2 mm in size which push in over pins on the card. Plug-and-Play modems (actually the serial port part of the modems) don't use jumpers for setting these but instead are configured by sending configuration commands to them over the bus inside the computer. Such configuration commands can be sent by a PnP BIOS, by the isapnp program (for the ISA bus only), by setpci (for the PCI bus), or by newer serial device drivers for certain modems. Under Linux you may have a choice of how to configure the ones that don't get io-irq configured by the serial driver.

1. ISA bus: Use "isapnp" which may be run automatically at every boot-time
2. Let a PnP BIOS do it, and then maybe tell setserial the IO and IRQ
3. PCI bus: Use lspci -vv to look at it and setpci to configure.

See [Quick Install](#) for more details, especially for the PCI bus.

2.5 Software-based Modems (winmodems, linmodems)

Introduction to software modems (winmodems)

Software modems turn over some (or even almost all) of the work of the modem to the main processor (CPU) chip of your computer (such as a Pentium chip). This requires special software (a modem driver) to do the job. Until late 1999, such software was released only for MS Windows and wouldn't work with Linux. Even worse was that the maker of the modem kept the interface to the modem secret so that no one could write a Linux driver for it (even though a few volunteers were willing to write Linux drivers).

But things have improved some since then so that today (late 2001) many such modems do have a linux driver. There is no standard interface so that different brands/models of software-modems need different drivers (unless the different brands/models happen to use the same chipset internally).

Another name for a software modem (used by MS) is "driver-based modem". The conventional hardware-based modem (that works with Linux) doesn't need a modem driver (but does use the Linux serial driver) After about mid-(UnERDau) Apnt brands/mmodems wera software modsus.

Modem–HOWTO

Software modems fall into 2 categories: linmodems and winmodems. Winmodems will only work under MS Windows. Linmodems will work under Linux (but formerly were mostly winmodems so some still call them "winmodems"). The term "Winmodem" is also a trademark for a certain model of "winmodem" but that's not the meaning of it in this document.

Linmodems

In late 1999, two software–based modems appeared that could work under Linux and were thus called "linmodems". Lucent Technologies (LT) unofficially released a Linux binary–only code to support most of its PCI modems. PC–TEL (includes "Zoltrix") introduced a new software–based modem for Linux. After that, interest increased for getting winmodems to work under linux. There is a GPL'ed driver for Intel's (Modem Silicon Operations) MD563x HaM chipset (nee Ambient division of Cirrus Logic). As of mid–2001 there are also drivers for: Conexant HSF and HCF, Motorola SM56, ESS (ISA only), and IBM's Mwave for Thinkpads 600+.

What percent of software modems now (2001) work under Linux? Well, there's a number of modem chips not supported: Lucent/Agere ARM (Scorpio), 3COM/US Robotics, some SmartLink (3 different chipsets), Ambient HSP, and possibly others. But there might be support for some of these by the time you read this. So it seems that over half the software modem chips are now supported (as of late 2001).

Be warned in advance that determining if your modem is a linmodem may or may not be easy. You may need to first find out what chipset you have and who makes it. Just knowing the brand and model number of your modem may not be sufficient. There are complex ways to find this out using say "lspci" (more than once) and then looking up the chip maker using the long modem number. This requires checking a database or searching the Internet. It's not always simple. It could happen that you will put a fair amount of effort into this only to get the bad news that your modem isn't supported. See Linmodem–HOWTO for more details.

Linmodem sites and documentation

- Linmodem–HOWTO
- Winmodems–and–Linux–HOWTO (not as well written as Linmodem–HOWTO)
- <http://linmodems.org> is a project to turn winmodems into linmodems. Has a mailing list.
- Conexant+Rockwell–modem–HOWTO
- [modem list](#). Has links to linmodem info.
- PCTel–HSP–MicroModem–Configuration–mini–HOWTO

Software–based modem types

There are two basic types of software modems. In one type the software does almost all of the work. The other is where the software only does the "control" operations (which is everything except processing the digital waveshapes --to be explained later). Since the hardware doesn't do the control it's called a "controllerless" modem. The first type is an all–software modem (sometimes just called a software modem).

For both of these types there must be analog hardware in the modem to generate an electrical waveshape to send out the phone line. It's generated from a digital signal (which is sort of a "digital waveshape"). It's something like the digital electronics creates a lot of discrete points on graph paper and then the modem draws a smooth curve thru them. There must also be hardware to convert the incoming waveshape to digital. This is just analog–to–digital conversion (and conversely). It's done by a codec (coder–decoder).

Modem-HOWTO

Then this digital waveshape must be converted to a data byte stream. This is known as demodulation, while turning data bytes into a digital waveshape is known as modulation. The modem can't just send an incoming data byte stream to the PC but must first do decompression, error correction, and convert from serial to the parallel bus of the computer. Likewise for an outgoing data byte stream.

The difference between the two types of software-based modems is where the digital modulation takes place. In the all-software modem this modulation is done in the CPU using a Host Signal Processor (HSP). In the controllerless modem it's done in the modem but all other digital work is done by the CPU. This other digital work consists of dealing with AT-commands, data compression, error correction, and simulating a serial port. In the all-software modem, there are still two items handled by hardware: the A/D conversion of waveshapes by the codec and echo cancellation.

Is this modem a software modem?

How do you determine if an internal modem is a software modem? First see if the name, description of it, or even the name of the MS Windows driver for it indicates it's a software modem: HSP (Host Signal Processor), HCF (Host Controlled Family), HSF (Host Signal Family), controllerless, host-controlled, host-based, and soft-... modem. If it's one of these modem it will only work for the cases where a Linux driver is available. Since software modems cost less, a low price is a clue that it's a software modem.

If you don't know the model of the modem and you also have Windows on your Linux PC, click on the "Modem" icon in the "Control Panel". Then check out the modem list (see [Web Sites](#)). If the above doesn't work (or isn't feasible), you can look at the package it came in (or a manual). Read the section on the package that says something like "Minimum System Requirements" or just "System Requirements".

A hardware modem will work fine on old CPUs (such as the 386 or better). So if it requires a modern CPU (such as a Pentium or other "high speed" CPU of say over 150 MHz) this is a clue that it's a all-software modem. If it only requires a 486 CPU (or better) then it's likely a host-controlled software modem. Saying that it only works with Windows is also bad news. However, even in this case there may be a Linux driver for it.

Otherwise, it may be a hardware modem if it fails to state explicitly that you must have Windows. By saying it's "designed for Windows" it may only mean that it fully supports Microsoft's plug-and-play which is OK since Linux uses the same plug-and-play specs (but it's harder to configure under Linux). Being "designed for Windows" thus gives no clue as to whether or not it will work under Linux. You might check the Website of the manufacturer or inquire via email. Some manufacturers are specifically stating that certain models work under Linux. Sometimes they are linmodems that require you to obtain and install a certain linmodem driver.

Should I get a software modem?

Only if you know there is a Linux driver for it that works OK. Besides the problems of getting a driver, what are the pros and cons of software modems? Since the software modem uses the CPU to do some (or all) of its work, the software modem requires less on-board electronics and thus costs less. At the same time, the CPU work load is increased by the modem which may result in slower operation.

The percentage of loading of the CPU by the modem depends on both what CPU you have and whether or not it's an all-software modem. For a modern CPU and a modem that only uses the CPU as a controller, there's little loss of performance. Even if it's an all-software modem, you will not suffer a loss of performance if there are no other CPU-intensive tasks are running at the same time. Of course, when you're not using the software modem there is no degradation in performance at all.

Is the modem cost savings worth it? In many cases yes, especially if you don't use the modem much and/or are not running any other CPU intensive tasks when the modem is in use. The savings in modem cost could be used for a better CPU which would speed things up a little. But the on-board electronics of a modem can do the job more efficiently than a general purpose CPU (except that it's not efficient at all when it's not in use). So if you use the modem a lot it's probably better to avoid all-software modems (and then you can use a less powerful CPU :-).

2.6 PCI Modems

A PCI modem card is one which inserts into a PCI-bus slot on the motherboard of a PC. While many PCI winmodems will not work under Linux (no driver available) other PCI modems will work under Linux. The Linux serial driver has been modified to support certain PCI hardware modem cards (but not winmodems/linmodems). If it's a linmodem, it will work only if you install a certain linmodem driver. If the Linux serial driver supports your hardware modem then the driver will set up the PnP configuration for you. See [PCI Bus Support Underway](#). If no special support for your PCI hardware modem is in the Linux serial driver it may still work OK but you have to do some work to configure it.

2.7 AMR Modems

These are all winmodems that insert into a special AMR (Audio Modem Riser) slot on the motherboard. Audio cards are sometimes used in this slot. The slot's main use is for HSF type modems where the CPU does almost all of the work. This results in a small modem card and thus a short AMR slot. Such a "modem" is actually little more than a codec which transforms digital signals representing an analog voltage wave into the analog wave itself (and conversely). Linux supports at least one of them.

2.8 USB Modems

USB = Universal Serial Bus. Some USB modems work with Linux and some don't. Linux has support for modems that conform to the USB Communication Device Class Abstract Control Model (= USB CDC ACM). There's a module for ACM named acm.o. See the /usb/acm... document in the kernel documentation directory (/usr/share/doc/kernel-doc-2.4.x in Debian, perhaps /usr/doc/kernel... in some distributions). The ACM serial port for the first (0th) such modem is (with devfs) is: /dev/usb/acm/0. Otherwise it might be /dev/usb/ttyACM0.

2.9 Which Internal Modems might not work with Linux

- [Software-based Modems \(winmodems, linmodems\)](#) Only about half have a Linux driver available.
- [MWave and DSP Modems](#) might work, but only if you first start Windows/Dos each time you power on your PC
- Modems with [RPI \(Rockwell\)](#) drivers work but with reduced performance

MWave and some DSP Modems

Note that there's now a Linux driver for the ACP (Mwave) modem used in IBM Thinkpads 600+. See the mini-HOWTO: ACP-Modem.

While hardware modems used use DSPs (Digital Signal Processors) some of these DSPs are programmed by a driver which must be downloaded from the hard disk to the DSPs memory just before using the modem.

Modem-HOWTO

Unfortunately, such downloading is normally done by Dos/Windows programs (which doesn't work for Linux). But there has been substantial success in getting some of these modems to work with Linux. For example, there is a Linux driver available to run a Lucent (DSP) modem.

Ordinary modems that work fine with Linux (without needing a driver for the modem) often have a DSP too (and may mention this on the packaging), but the program that runs the DSP is stored inside the modem. These work fine under Linux. An example of a DSP modem that has problems working under Linux is the old IBM's Aptiva MWAVE.

One way to get some DSP modems to work with Linux is to boot from DOS (if you have it on your Linux PC). You first install the driver under DOS (using DOS and not Window drivers). Then start Dos/Windows and start the driver for the modem so as to program the DSP. Then without turning off the computer, start Linux.

One may write a "batch" file (actually a script) to do this. Here is an example but you must modify it to suit your situation.

```
rem mwave is a batch file supplied by the modem maker
call c:\mww\dll\mwave start
rem loadlin.exe is a DOS program that will boot Linux from DOS (See
rem Config-HOWTO).
c:\linux\loadlin f:\vmlinuz root=/dev/hda3 ro
```

One may create an icon for the Window's desktop which points to such a batch file and set the icon properties to "Run in MSDOS Mode". Then by clicking on this icon one sets up the modem and goes to Linux. Another possible way to boot Linux from DOS is to press CTRL-ALT-DEL and tell it to reboot (assuming that you have set things up so that you can boot directly into Linux). The modem remains on the same com port (same IO address) that it used under DOS.

The Newcom ifx modem needs a small kernel patch to work correctly since its simulation of a serial port is non-standard. The patch and other info for using this modem with Linux is at <http://quinine.pharmacy.ohio-state.edu/~ejolson/linux/newcom.html>.

Rockwell (RPI) Drivers

Some older Rockwell chips need Rockwell RPI (Rockwell Protocol Interface) drivers for compression and error correction. They can still be used with Linux even though the driver software works only under MS Windows. This is because the MS Windows software (which you don't have) does only compression and error correction. If you are willing to operate the modem without compression and error correction then it's feasible to use it with Linux. To do this you will need to disable RPI by sending the modem (via the initialization string) a "RPI disable" command each time you power on your modem. On my old modem this command was +H0. Not having data compression available makes it slower to get webpages but is just as fast when downloading files that are already compressed.

3. [Modem Pools](#)

3.1 Introduction

These are multiple modems which might be used by an ISP or by an organization that has a number of phone lines for dialing in and out. There are two types of modem pools: analog and digital. An ISP will use digital so

that they can support 56k (V.90, V.92) modems at near maximum speed.

A modem pool could be a number of modems on the same card (such as an analog multi-port modem card) or many modems in an external chassis (something like an external modem). The modems may be analog modems similar to modems used for home/office PCs (can't send above 33.6k even if they are "56k modems"). They also could be "digital modems" which can send at nearly 56k (if you have a good line). The "digital modems" require a digital connection to the telephone line and don't use any serial ports at all. All of these modem pools will require that you install special drivers for them.

3.2 Analog Modem Pools, Multi-modem Cards

A "multimodem card" is short for "multiport modem card". Some put a hyphen after "multi": multi-modem or multi-port. An analog modem pool is just many analog modems (the common home/office modem) provided either on an internal plug-in card or in an external chassis. Each modem comes with a built-in serial port. There is usually a system of sharing interrupts or of handling interrupts by their own electronics, thus removing much of this burden from the CPU. Note that these modems are not "digital modems" and will thus not be able to use 56k for people who dial-in.

Here is a list of some companies that make analog multiport modem cards which plug into slots in a PC. 8 modems/card is common. The cards listed claim to work with Linux and the websites should point you to a driver for them.

Multi-modem Cards (analog, not digital):

- Equinox SST Multi-modem. PCI, 56k, 4 or 8 ports
<http://www.equinox.com/product/multi-modem.htm>
- MultiModemISI by Multi-Tech Systems. 56k or 33.6k, PCI, 4 or 8 ports. ISDN/56k hybrids.
<http://www.multitech.com/PRODUCTS/MultiModemISI/>
- PCI-RAS cards by Perle. 56k, 4 or 8 ports.
http://www.perle.com/solutions/app_notes/multi_modem/pci_ras_fax.html
- RocketModem by Comtrol. ISA 33.6k, 4 or 8 port.
<http://www.comtrol.com/sales/specs/rm.htm>
- RocketModem II by Comtrol. PCI 56k, 4 or 6 port
<http://www.comtrol.com/sales/specs/rmii.htm>
- RockForce. 56k, 2 or 4 port Two port V.92/V.44
<http://www.mainpine.com/> #RockForce+ Two port V.90 (www.mainpine.com/prodrockplus.html)
#RockForceDUO Two port V.92/V.44 (www.mainpine.com/prodduo.html) #RockForceQUATRO
Four port V.92/V.44 (www.mainpine.com/prodquattro.html) #RockForceDUO+ Two port
V.92/V.44/V.34 SuperG3 Fax = #(www.mainpine.com/prodduoplus.html) #RockForceQUATRO+
Four port V.92/V.44/V.34 SuperG3 Fax = #(www.mainpine.com/prodquattroplus.html) #
- Multi-modem communication adapters by Digi.
<http://www.dgii.com/solutions/mmcommadapters/index.html>

3.3 Digital Modems, RAS

"digital modems" are much different than the analog modems that most people use in their PCs. They require a digital connection to the telephone line and don't use serial ports for the interface to the computer. Instead, they interface directly to a computer bus via a special card(s) (which may also contain the "digital modems"). They are able to send at near 56k, something no analog modem can do. They are often a component of "remote access servers" (RASs) or "digital modem pools"

Modem–HOWTO

The cables from the phone company that carry digital signals have been designed for high bandwidth so that the same cable carries multiple telephone calls. It's done by "time–division multiplexing". A single phone call in a cable is carried on two different channels, one for each direction. So the RAS must connect each such channel–pair to the appropriate "digital modem" that services that phone call. Such tasks are done by what is sometimes called a "... concentrator".

Now the digital signal received by a "digital modem" may really represent an analog signal which has been sent to it by an analog modem. One way to deal with it would be to convert it to an analog signal and then put that thru an analog modem to get the digital data sent by the analog modem. But why do all this work? Since the signal is already in digital form, why not process it digitally? That's how it's done. The digital signal is processed and converted to another digital stream of bytes which represents data bytes sent by the analog modem. A "digital signal processor" (DSP) is commonly used for this task. A CPU could also handle it but it would be heavily loaded.

Likewise, a "digital modem" must handle sending digital signals in the opposite direction from a RAS to a digital telephone line. Thus it only makes digital–to–digital conversions and doesn't deal in analog at all. It thus is not really a modem at all since it doesn't modulate any analog carrier. So the name "digital modem" is a misnomer but it does do the job formerly done by modems. Thus some "digital modems" call themselves "digital signal processors", or "remote access servers", etc. and may not even mention the word "modem".

Such a RAS system may be a stand–alone proprietary server, a chassis containing digital modems that connects to a PC via a special interface card, or just a card itself. Digi calls one such card a "remote access server concentrator adapter". One incomplete description of what is needed to become an ISP is: See [What do I need to be an ISP?](#) Cyclades promotes their own products here so please do comparison shopping before buying anything.

4. Serial Port and Modem Basics

You don't have to understand the basics to use and install a modem. But understanding it may help to determine what is wrong if you run into problems. After reading this section, if you want to understand it even better you may want to see [How Modems Work](#) in this document (not yet complete). More details on the serial port (including much of this section) will be found in Serial–HOWTO.

4.1 Modem Converts Digital to Analog (and conversely)

Most all telephone main lines are digital already but the lines leading to your house (or business) are usually analog which means that they were designed to transmit a voltage wave which is an exact replica of the sound wave coming out of your mouth. Such a voltage wave is called "analog". If viewed on an oscilloscope it looks like a sine wave of varying frequency and amplitude. A digital signal is like a square wave. For example 3 v (volts) might be a 1–bit and 0 v could be a 0–bit. For most serial ports (used by external modems) +12 v is a 0–bit and –12 v is a 1–bit (some are + or – 5 v).

To send data from your computer over the phone line, the modem takes the digital signal from your computer and converts it to "analog". It does this by both creating an analog sine wave and then "MODulating" it. Since the result still represents digital data, it could also be called a digital signal instead of analog. But it looks something like an analog signal and almost everyone calls it analog. At the other end of the phone line another modem "DEModulates" this signal and the pure digital signal is recovered. Put together the "mod" and "dem" parts of the two words above and you get "modem" (if you drop one of the two d's). A "modem" is thus a MODulator–DEModulator. Just what modulation is may be found in the section [Modulation Details](#).

4.2 What is a Serial Port ?

Intro to Serial

The serial port is an I/O (Input/Output) device. Since modems have a serial port between them and the computer, it's necessary to understand the serial port as well as the modem.

Most PC's have one or two serial ports. Each has a 9-pin connector (sometimes 25-pin) on the back of the computer. Computer programs can send data (bytes) to the transmit pin (output) and receive bytes from the receive pin (input). The other pins are for control purposes and ground.

The serial port is much more than just a connector. It converts the data from parallel to serial and changes the electrical representation of the data. Inside the computer, data bits flow in parallel (using many wires at the same time). Serial flow is a stream of bits over a single wire (such as on the transmit or receive pin of the serial connector). For the serial port to create such a flow, it must convert data from parallel (inside the computer) to serial on the transmit pin (and conversely).

Most of the electronics of the serial port is found in a computer chip (or a part of a chip) known as a UART. For more details on UARTs see the section "What are UARTS" in the Serial-HOWTO.

But you may want to finish this section first so that you will hopefully understand how the UART fits into the overall scheme of things.

Pins and Wires

Old PC's used 25 pin connectors but only about 9 pins were actually used so today most connectors are only 9-pin. Each of the 9 pins usually connects to a wire. Besides the two wires used for transmitting and receiving data, another pin (wire) is signal ground. The voltage on any wire is measured with respect to this ground. Thus the minimum number of wires to use for 2-way transmission of data is 3. Except that it has been known to work with no signal ground wire but with degraded performance and sometimes with errors.

There are still more wires which are for control purposes (signalling) only and not for sending bytes. All of these signals could have been shared on a single wire, but instead, there is a separate dedicated wire for every type of signal. Some (or all) of these control wires are called "modem control lines". Modem control wires are either in the asserted state (on) of +12 volts or in the negated state (off) of -12 volts. One of these wires is to signal the computer to stop sending bytes out the serial port cable. Conversely, another wire signals the device attached to the serial port to stop sending bytes to the computer. If the attached device is a modem, other wires may tell the modem to hang up the telephone line or tell the computer that a connection has been made or that the telephone line is ringing (someone is attempting to call in). See the Serial-HOWTO: Pinout and Signals for more details.

Internal Modem Contains Serial Port

For an internal modem there is no 9-pin connector but the behavior is almost exactly as if the above mentioned cable wires existed. Instead of a 12 volt signal in a wire giving the state of a modem control line, the internal modem may just use a status bit in its own memory (a register) to determine the state of this non-existent "wire". The internal modem's serial port looks just like a real serial port to the computer. It even includes the speed limits that one may set at ordinary serial ports such as 115200 bits/sec. Unfortunately for Linux, many internal modems today don't work exactly this way but instead use software (running on the

CPU) to do much of the modem's work. Unfortunately, such software is often only available for the MS Windows OS (it hasn't been ported to Linux). Thus you can't use most of these modems with Linux See [Software-based Modems \(winmodems\)](#).

4.3 IO Address & IRQ

Since the computer needs to communicate with each serial port, the operating system must know that each serial port exists and where it is (its I/O address). It also needs to know which wire (IRQ number) the serial port must use to request service from the computer's CPU. It requests service by sending an interrupt on this wire. Thus every serial port device must store in its non-volatile memory both its I/O address and its Interrupt ReQuest number: IRQ. See [Interrupts](#). For the PCI bus it doesn't work exactly this way since the PCI bus has its own system of interrupts. But since the PCI-aware BIOS sets up chips to map these PCI interrupts to IRQs, it seemingly behaves just as described above except that sharing of interrupts is allowed (2 or more devices may use the same IRQ number).

I/O addresses are not the same as memory addresses. When an I/O addresses is put onto the computer's address bus, another wire is energized. This both tells main memory to ignore the address and tells all devices which have I/O addresses (such as the serial port) to listen to the address to see if it matches the device's. If the address matches, then the I/O device reads the data on the data bus.

4.4 Names: ttyS0, ttyS1, etc.

The serial ports are named ttyS0, ttyS1, etc. (and usually correspond respectively to COM1, COM2, etc. in DOS/Windows). The /dev directory has a special file for each port. Type "ls /dev/ttyS*" to see them. Just because there may be (for example) a ttyS3 file, doesn't necessarily mean that there exists a physical serial port there.

Which one of these names (ttyS0, ttyS1, etc.) refers to which physical serial port is determined as follows. The serial driver (software) maintains a table showing which I/O address corresponds to which ttyS. This mapping of names (such as ttyS1) to I/O addresses (and IRQ's) may be both set and viewed by the "setserial" command. See [What is Setserial](#). This does not set the I/O address and IRQ in the hardware itself (which is set by jumpers or by plug-and-play software). Thus what physical port corresponds to say ttyS1 depends both on what the serial driver thinks (per setserial) and what is set in the hardware. If a mistake has been made, the physical port may not correspond to any name (such as ttyS2) and thus it can't be used. See [Serial Port Devices /dev/ttyS2, etc.](#) for more details>

4.5 Interrupts

Bytes come in over the phone line to the modem, are converted from analog to digital by the modem and passed along to the serial port on their way to their destination inside your computer. When the serial port receives a number of bytes (may be set to 1, 4, 8, or 14) into its FIFO buffer, it signals the CPU to fetch them by sending an electrical signal known as an interrupt on a certain wire normally used only by that port. Thus the FIFO waits for a number of bytes and then issues an interrupt.

However, this interrupt will also be sent if there is an unexpected delay while waiting for the next byte to arrive (known as a timeout). Thus if the bytes are being received slowly (such as someone typing on a terminal keyboard) there may be an interrupt issued for every byte received. For some UART chips the rule is like this: If 4 bytes in a row could have been received, but none of these 4 show up, then the port gives up waiting for more bytes and issues an interrupt to fetch the bytes currently in the FIFO. Of course, if the FIFO

is empty, no interrupt will be issued.

Each interrupt conductor (inside the computer) has a number (IRQ) and the serial port must know which conductor to use to signal on. For example, ttyS0 normally uses IRQ number 4 known as IRQ4 (or IRQ 4). A list of them and more will be found in "man setserial" (search for "Configuring Serial Ports"). Interrupts are issued whenever the serial port needs to get the CPU's attention. It's important to do this in a timely manner since the buffer inside the serial port can hold only 16 (1 in old serial ports) incoming bytes. If the CPU fails to remove such received bytes promptly, then there will not be any space left for any more incoming bytes and the small buffer may overflow (overrun) resulting in a loss of data bytes.

For an external modem, there is no way (such as flow control) to stop the flow rapidly enough to prevent this. For an internal modem the 16-byte FIFO buffer is on the same card and a good modem will not write to it if it's full. Thus a good internal modem will not overrun the 16-byte buffers but it may need to use [Modem-to-Modem Flow Control](#) to prevent the modem itself from being overrun. This is one advantage of an internal modem over an external.

Interrupts are also issued when the serial port has just sent out all 16 of its bytes from its small transmit buffer out the external cable. It then has space for 16 more outgoing bytes. The interrupt is to notify the CPU of that fact so that it may put more bytes in the small transmit buffer to be transmitted. Also, when a modem control line changes state an interrupt is issued.

The buffers mentioned above are all hardware buffers. The serial port also has large buffers in main memory. This will be explained later

Interrupts convey a lot of information but only indirectly. The interrupt itself just tells a chip called the interrupt controller that a certain serial port needs attention. The interrupt controller then signals the CPU. The CPU then runs a special program to service the serial port. That program is called an interrupt service routine (part of the serial driver software). It tries to find out what has happened at the serial port and then deals with the problem such as transferring bytes from (or to) the serial port's hardware buffer. This program can easily find out what has happened since the serial port has registers at IO addresses known to the serial driver software. These registers contain status information about the serial port. The software reads these registers and by inspecting the contents, finds out what has happened and takes appropriate action.

4.6 Data Compression (by the Modem)

Before continuing with the basics of the serial port, one needs to understand about something done by the modem: data compression. In some cases this task is actually done by software run on the computer's CPU but unfortunately at present, such software only works for MS Windows. The discussion here will be for the case where the modem itself does the compression since this is what must happen in order for the modem to work under Linux.

In order to send data faster over the phone line, one may compress (encode it) using a custom encoding scheme which itself depends on the data. The encoded data is smaller than the original (less bytes) and can be sent over the Internet in less time. This process is called "data compression".

If you download files from the Internet, they are likely already compressed and it is not feasible for the modem to try to compress them further. Your modem may sense that what is passing thru has already been compressed and refrain from trying to compress it any more. If you are receiving data which has been compressed by the other modem, your modem will decompress it and create many more bytes than were sent over the phone line. Thus the flow of data from your modem into your computer will be higher than the flow

over the phone line to you. The ratio of this flow is called the compression ratio. Compression ratios as high as 4 are possible, but not very likely.

4.7 Error Correction

Similar to data compression, modems may be set to do error correction. While there is some overhead cost involved which slows down the byte/sec flow rate, the fact that error correction strips off start and stop bits actually increases the data byte/sec flow rate.

For the serial port's interface with the external world, each 8-bit byte has 2 extra bits added to it: a start-bit and a stop-bit. Without error correction, these extra start and stop bits usually go right thru the modem and out over the phone lines. But when error correction is enabled, these extra bits are stripped off and the 8-bit bytes are put into packets. This is more efficient and results in higher byte/sec flow in spite of the fact that there are a few more bytes added for packet headers and error correction purposes.

4.8 Data Flow (Speeds)

Data (bytes representing letters, pictures, etc.) flows from your computer to your modem and then out on the telephone line (and conversely). Flow rates (such as 56k (56000) bits/sec) are (incorrectly) called "speed". But almost everyone says "speed" instead of "flow rate". If there were no data compression the flow rate from the computer to the modem would be about the same as the flow rate over the telephone line.

Actually there are two different speeds to consider at your end of the phone line:

- The speed on the phone line itself (DCE speed) modem-to-modem
- The speed from your computer's serial port to your modem (DTE speed)

When you dial out and connect to another modem on the other end of the phone line, your modem often sends you a message like "CONNECT 28800" or "CONNECT 115200". What do these mean? Well, its either the DCE speed or the DTE speed. If it's higher than the advertised modem speed it must be the DTE modem-to-computer speed. This is the case for the 115200 speed shown above. The 28800 must be a DCE (modem-to-modem) speed since the serial port has no such speed. One may configure the modem to report either speed. Some modems report both speeds and report the modem-to-modem speed as (for example): CARRIER 28800.

If you have an internal modem you would not expect that there would be any speed limit on the DTE speed from your modem to your computer since you modem is inside your computer and is almost part of your computer. But there is since the modem contains a dedicated serial port within it.

It's important to understand that the average speed is often less than the specified speed, especially on the short DTE computer-to-modem line. Waits (or idle time) result in a lower average speed. These waits may include long waits of perhaps a second due to [Flow Control](#). At the other extreme there may be very short waits (idle time) of several micro-seconds separating the end of one byte and the start of the next byte. In addition, modems will fallback to lower speeds if the telephone line conditions are less than pristine.

For a discussion of what DTE speed is best to use see section [What Speed Should I Use](#).

4.9 Flow Control

Flow control means the ability to slow down the flow of bytes in a wire. For serial ports this means the ability to stop and then restart the flow without any loss of bytes. Flow control is needed for modems to allow a jump in instantaneous flow rates.

Example of Flow Control

For example, consider the case where you connect a 33.6k external modem via a short cable to your serial port. The modem sends and receives bytes over the phone line at 33.6k bits per second (bps). Assume it's not doing any data compression or error correction. You have set the serial port speed to 115,200 bits/sec (bps), and you are sending data from your computer to the phone line. Then the flow from the your computer to your modem over the short cable is at 115.2k bps. However the flow from your modem out the phone line is only 33.6k bps. Since a faster flow (115.2k) is going into your modem than is coming out of it, the modem is storing the excess flow ($115.2k - 33.6k = 81.6k$ bps) in one of its buffers. This buffer would soon overrun (run out of free storage space) unless the high 115.2k flow is stopped.

But now flow control comes to the rescue. When the modem's buffer is almost full, the modem sends a stop signal to the serial port. The serial port passes on the stop signal on to the device driver and the 115.2k bps flow is halted. Then the modem continues to send out data at 33.6k bps drawing on the data it previous accumulated in its buffer. Since nothing is coming into the buffer, the level of bytes in it starts to drop. When almost no bytes are left in the buffer, the modem sends a start signal to the serial port and the 115.2k flow from the computer to the modem resumes. In effect, flow control creates an average flow rate in the short cable (in this case 33.6k) which is significantly less than the "on" flow rate of 115.2k bps. This is "start-stop" flow control.

In the above simple example it was assumed that the modem did no data compression. This would be true when the modem is sending a file which is already compressed and can't be compressed further. Now let's consider the opposite extreme where the modem is compressing the data with a high compression ratio. In such a case the modem might need an input flow rate of say 115.2k bps to provide an output (to the phone line) of 33.6k bps (compressed data). The compression ratio is 3.43 ($115.2/33.6$) which is much higher than average. In this case the modem is able to compress and the 115.2 bps PC-to-modem flow and send the same data out on the phone line at 33.6bps. There's no need for flow control here. But such a high compression ratio rarely happens so that most of the time flow control is needed to slow down the flow on the 115.2 bps PC-to-modem cable. The flow is stopped and started so that the average flow is usually well under the "on" flow of 115.2 bps.

In the above example the modem was an external modem. But the same situation exists (as of late 2000) for most internal modems. There is still a speed limit on the PC-to-modem speed even though this flow doesn't take place over an external cable. This makes the internal modems compatible with the external modems.

In the above example of flow control the flow was from the computer to a modem. But there is also flow control which is used for the opposite direction of flow: from a modem (or other device) to a computer. Each direction of flow involve 3 buffers: 1. in the modem 2. in the UART chip (called FIFOs) 3. in main memory managed by the serial driver. Flow control protects certain buffers from overflowing. The small UART FIFO buffers are not protected in this way but rely instead on a fast response to the interrupts they issue. FIFO stand for "First In, First Out" which is the way it handles bytes. All the 3 buffers use the FIFO rule but only one of them also uses it as a name. This is the essence of flow control but there are still some more details.

You don't often need flow control in the direction from the modem to a PC. For complex example of a case where it's needed see "Complex Flow Control Example" in the Serial-HOWTO. But if you don't have a high enough speed set between the modem and the computer (serial port speed) then you do need to slow down the flow coming into the modem from the telephone line. To do this your modem must tell the other modem to stop sending. See [Modem-to-Modem Flow Control](#).

Hardware vs. Software Flow Control

If feasible it's best to use "hardware" flow control that uses two dedicated "modem control" wires to send the "stop" and "start" signals. Modern modems almost always use hardware flow control between the modem and the serial port.

Software flow control uses the main receive and transmit wires to send the start and stop signals. It uses the ASCII control characters DC1 (start) and DC3 (stop) for this purpose. They are just inserted into the regular stream of data. Software flow control is not only slower in reacting but also does not allow the sending of binary data unless special precautions are taken. Since binary data will likely contain DC1 and DC3, special means must be taken to distinguish between a DC3 that means a flow control stop and a DC3 that is part of the binary code. Likewise for DC1. To get software flow control to work for binary data requires both modem (hardware) and software support

Symptoms of No Flow Control

Understanding flow-control theory can be of practical use. For example I used my modem to access the Internet and it seemed to work fine. But after a few months I tried to send long files from my PC to an ISP and a huge amount of retries and errors resulted (but eventually Kermit could send a long file after many retries). Receiving in the other direction (from my ISP to me) worked fine. The problem turned out to be a modem with broken flow control. My modem's buffer was overflowing (overrunning) on long outgoing files since no "stop" signal was ever sent to my computer to halt sending to the modem. There was no problem in the direction from the modem to my computer since the capacity (say 115.2 kbps) was always higher than the flow over the telephone line. But it was a problem in the other direction where the PC could send at 115.2 kbps until it overran the modem). The fix was to enable flow control by putting into the init string an enable-flow-control command for the modem.

Modem-to-Modem Flow Control

This is the flow control of the data sent over the telephone lines between two modems. Practically speaking, it only exists when you have error correction enabled. Actually, even without error correction it's possible to enable software flow control between modems but it may interfere with sending binary data so it's not often used.

4.10 Data Flow Path; Buffers

Much has been explained about this including flow control, a pair of 16-byte FIFO buffers (in the UART), and a pair of larger buffers inside a device connected to the serial port (such as a modem). But there is still another pair of buffers. These are large buffers (perhaps 4k) in main memory also known as serial port buffers. When an application program sends bytes to the serial port (and modem) they first get stashed in the transmit serial port buffer in main memory. The pair consists of both this transmit buffer and a receive buffer for the opposite direction of byte-flow. Here's an example diagram for the case of browsing the Internet with a browser. Transmit data flow is left to right while receive flow is right to left.

Modem-HOWTO

application	4k-byte	16-byte	1k-byte	tele-
BROWSER	MEMORY	UART	MODEM	phone
program	buffer	buffer	buffer	line

The serial device driver takes out say 16 bytes from this transmit buffer, one byte at a time and puts them into the 16-byte transmit buffer in the serial UART for transmission. Once in that transmit buffer, there is no way to stop them from being transmitted. They are then transmitted to the modem which also has a fair sized (say 1k) buffer. When the device driver (on orders from flow control) stops the flow of outgoing bytes from the computer, what it actually stops is the flow of outgoing bytes from the large transmit buffer in main memory. Even after this has happened and the flow to the modem has stopped, an application program may keep sending bytes to the 4k transmit buffer until it becomes fill.

When it gets fill, the application program can't send any more bytes to it (a "write" statement in a C_program blocks) and the application program temporarily stops running and waits until some buffer space becomes available. Thus a flow control "stop" is ultimately able to stop the program that is sending the bytes. Even though this program stops, the computer does not necessarily stop computing. It may switch to running other processes while it's waiting at a flow control stop. The above was a little oversimplified since there is another alternative of having the application program itself do something else while it is waiting to "write".

4.11 Modem Commands

Commands to the modem are sent to it from the communication software over the same conductor as used to send data. The commands are short ASCII strings. Examples are "AT&K3" for enabling hardware flow control (RTS/CTS) between your computer and modem; and "ATDT5393401" for Dialing the number 5393401. Note all commands are prefaced by "AT". Some commands such as enabling flow control help configure the modem. Other commands such as dialing a number actually do something. There are about a hundred or so different possible commands. When your communication software starts running, it first sends an "init" string of commands to the modem to configure it. All commands are sent on the ordinary data line before the modem dials (or receives a call).

Once the modem is connected to another modem (on-line mode), everything that is sent from your computer to your modem goes directly to the other modem and is not interpreted by the modem as a command. There is a way to "escape" from this mode of operation and go back to command mode where everything sent to the modem will be interpreted as a command. The computer just sends "+++" with a specified time spacing before and after it. If this time spacing is correct, the modem reverts to command mode. Another way to do this is by a signal on a certain modem control line.

There are a number of lists of modem commands on the Internet. The section [Web Sites](#) has links to a couple of such web-sites. Different models and brands of modems do not use exactly the same set of such commands. So what works for one modem might not work for another. Some common commands (not guaranteed to work on all modems) are listed in this HOWTO in the section [Modem Configuration](#)

4.12 Serial Driver Module

The device driver for the serial port is the software that operates the serial port. It is now provided as a serial module. >From kernel 2.2 on, this module will normally get loaded automatically if it's needed. In earlier kernels, you had to have `kerneld` running in order to do auto-load modules on demand. Otherwise the serial module needed to be explicitly listed in `/etc/modules`. Before modules became popular with Linux, the serial driver was usually built into the kernel (and sometimes still is). If it's built-in don't let the serial module load or else you will have two serial drivers running at the same time. With 2 drivers there are all sorts of

errors including a possible "I/O error" when attempting to open a serial port. Use "lsmmod" to see if the module is loaded.

When the serial module is loaded it displays a message on the screen about the existing serial ports (often showing a wrong IRQ). But once the module is used by `setserial` to tell the device driver the (hopefully) correct IRQ then you should see a second display similar to the first but with the correct IRQ, etc. See "Serial Module" in the Serial-HOWTO. See [What is Setserial](#) for more info on `setserial`.

5. [Configuring Overview](#)

Since each modem has an associated serial port and the port has both hardware and software, there are three parts to configuring a modem:

- Locate the serial port hardware: IO address, IRQ; Done by PnP methods or jumpers, `setserial`. See [Locating the Serial Port: IO address IRQs](#) [What is Setserial](#)
- Configure the serial port driver (high-level): Done by the communication program (stty-like). Sets speed, flow control, etc. See [Configuring the Serial Driver \(high-level\)](#) See [What is stty ?](#)
- Configure the modem itself: Done by the communication program See [Modem Configuration](#)

The above omits a few other things that "setserial" can do besides locating the serial ports. But normally you don't need to use them. Setserial may be used in the future to enable super-high speed.

Communication programs include `minicom`, `seyon`, or `wvdial` (for PPP) and `mgetty` for dial-in. Such communication programs require that you configure them although the default configuration they come with may only need a little tweaking.

Unfortunately the communication program doesn't locate the serial port. This "locating" is the low-level PnP configuring of the serial port: setting its IO address and IRQ in both the hardware and the driver. If you are lucky, this will happen automatically when you boot Linux. Setting these in the hardware was formerly done by jumpers and then running "setserial" but today it's done by "Plug-and-Play" software. You may still need "setserial". So if the serial driver can't find the serial port your modem is on, then you can try to find it yourself per the next section but it may not be easy.

6. [Locating the Serial Port: IO address, IRQs](#)

6.1 IO & IRQ Overview

For a serial port to work properly, it must have both an IRQ and an IO address. Without an IO address, it can't be located and will not work at all. Without an IRQ it will need to use inefficient polling methods for which one must set the IRQ to 0. So every serial port needs an IO address and IRQ. In olden days this was set by jumpers on a serial port card. Today it's set by digital signals sent to the hardware and this is part of "Plug-and-Play (PnP).

The driver must also know both the IO address and IRQ so that it can locate the port chip. Modern serial port drivers (kernel 2.4) try to determine this by PnP methods so one doesn't need to tell them (by using "setserial"). Such a driver might also set an IO address or enable the hardware. But unfortunately, there is some PCI serial port hardware that the driver doesn't recognize so you may need to enable the port yourself. See [PCI: Enabling a disabled port](#)

Modem-HOWTO

The driver also probes possible ISA serial port addresses to see if there are any serial ports there. This works for the case of jumpers and sometimes works for a PnP port when the driver doesn't do PnP (prior to kernel 2.4).

Locating the serial port by giving it an IRQ and IO address is low-level configuring. It's often automatically done by the serial driver but sometimes you have to do it yourself. What follows repeats what was said above but in more detail.

The low-level configuring consists of assigning an IO address, IRQ, and name (such as ttyS2). This IO-IRQ pair must be set in both the hardware and told to the serial driver. Only the driver needs to know the name. We could call this "io-irq" configuring for short. The "setserial" program is one way to tell the driver. The other way is for the driver to use PnP methods to determine/set the IO/IRQ and then remember what it did. For jumpers you must always use "setserial". If you need to configure but don't understand certain details it's easy to get into trouble.

When Linux starts, some effort is made to detect and configure (low-level) a few serial ports. Exactly what happens depends on your BIOS, hardware, Linux distribution, etc. If the serial ports work OK, there may be no need for you to do any more low-level configuring.

If you're having problems with the serial ports, then you may need to do low-level configuring. If you have kernel 2.2 or lower, then you need to do it if you:

- Plan to use more than 2 ISA serial ports
- Are installing a new serial port (such as an internal modem)

For kernel 2.2+ you may be able to use more than 2 serial ports without doing any low-level configuring by sharing interrupts. All PCI ports should support this but for ISA it only works for some hardware. It may be just as easy to give each port a unique interrupt if they is available. See [Interrupt sharing and Kernels 2.2+](#)

The low-level configuring (setting the IRQ and IO address) seems to cause people more trouble than the high-level stuff, although for many it's fully automatic and there is no configuring to be done. Until the serial driver knows the correct IRQ and IO address, the port will not usually not work at all. Also, PnP ports can be disabled so that they can't be found (except with PnP tools such as lspci). Applications, and utilities such as "setserial" and "scanport" (Debian only ??) don't use PnP tools and thus can't detect disabled ports.

Even if an ISA port can be found by the probing of the serial driver it may work extremely slow if the IRQ is wrong. See [Extremely Slow: Text appears on the screen slowly after long delays](#). PCI ports are less likely to get the IRQ wrong.

In the Wintel world, the IO address and IRQ are called "resources" and we are thus configuring certain resources. But there are many other types of "resources" so the term has many other meanings. In summary, the low-level configuring consists of enabling the device, giving it a name (ttyS2 for example) and putting two values (an IRQ number and IO address) into two places:

1. the device driver (often by running "setserial" at boot-time)
2. configuration registers of the serial port hardware itself

You may watch the start-up (= boot-time) messages. They are usually correct. But if you're having problems, your serial port may not show up at all or if you do see a message from "setserial" it may not show the true configuration of the hardware (and it is not necessarily supposed to). See [I/O Address & IRQ: Boot-time messages](#).

6.2 PCI Bus Support

Introduction

Although some PCI modems are "winmodems" without a Linux driver (and will not work under Linux), other PCI modems will often work OK under Linux. If it's a software modem, then you need to find a driver for it. See Linmodem-HOWTO.

If you have kernel 2.4, then there should be support for PnP (either built-in or by modules). Some PCI serial ports can be automatically detected and low-level configured by the serial driver. Others may not be. No support exists in the serial driver for software modems. But separate drivers exist for many of them. Kernel 2.2 had no support for PCI serial ports (although some people got them working anyway). The 2.4 serial driver will read the id number digitally stored in the serial hardware to determine how to support it (if it knows how). It should assign an I/O address to it, determine its IRQ, etc. So you don't need to use "setserial" for it.

Requesting that future drivers support your serial port

If you have a PCI internal modem which you are convinced is not a winmodem but it will not work because the latest serial driver doesn't support it, you can help in attempting to create a driver for it. To do this you'll need to contact the maintainer of the serial driver, Theodore (Ted) Y. Ts'o. But first check out the modem list site <http://www.idir.net/~gromitkc/winmodem.html> for the latest info on PCI modems and related topic.

Look at [Ted Ts'o's site](#) for the details of what you need to do. Here's a summary of what you need to do to help him. You will need to email Ted Ts'o a copy of the output of "lspci -vv" with full information about the model and manufacturer of the PCI modem (or serial port). Then he will try to point you to a test driver which might work for it. You will then need to get it, compile it and possibly recompile your kernel. Then you will test the driver to see if it works OK for you and report the results to Ted Ts'o. If you are willing to do all the above (and this is the latest version of this HOWTO) then email the needed info to him at: <mailto:tytso@mit.edu>.

More info on PCI

PCI ports are not well standardized. Some use main memory for communication with the PC. Some require special enabling of the IRQ. The output of "lspci -vv" can help determine if one can be supported. If you see a 4-digit IO port, the port might work by just telling "setserial" the IO port and the IRQ. Some people have gotten a 3COM 3CP5610 PCI Modem to work that way. For example, if lspci shows IRQ 10, I/O at 0xecb8 and you decide to name it ttyS2 then the command is:

```
setserial /dev/ttyS2 irq 10 port 0xecb8 autoconfig
```

Note that the boot-time message "Probing PCI hardware" means reading the PnP configuration registers in the PCI cards which reveals the IO addresses and IRQs. This is different than the probing of IO addresses by the serial driver which means reading certain IO addresses to see if what's read looks like there's a serial port at that address.

6.3 Common mistakes made re low-level configuring

Here are some common mistakes people make:

Modem-HOWTO

- setserial command: They run it (without the "autoconfig" and auto_irq options) and think it has checked the hardware to see if what it shows is correct (it hasn't).
- setserial messages: They see them displayed on the screen at boot-time (or by giving the setserial command) and erroneously think that the result always shows how their hardware is actually configured.
- /proc/interrupts: When their serial device isn't in use they don't see its interrupt there, and erroneously conclude that their serial port can't be found (or doesn't have an interrupt set).
- /proc/ioports and /proc/tty/driver/serial: People think this shows the actual hardware configuration when it only shows about the same info (possibly erroneous) as setserial.

6.4 IRQ & IO Address Must be Correct

There are really two answers to the question "What is my IO and IRQ?" 1. What the device driver thinks has been set (This is what setserial usually sets and shows.). 2. What is actually set in the hardware. Both 1. and 2. above should be the same. If they're not it spells trouble since the driver has incorrect info on the physical serial port. In some cases the hardware is disabled so it has no IO address or IRQ.

If the driver has the wrong IO address it will try to send data to a non-existing serial port --or even worse, to some other device. If it has the wrong IRQ the driver will not get interrupt service requests from the serial port, resulting in a very slow or no response. See [Extremely Slow: Text appears on the screen slowly after long delays](#). If it has the wrong model of UART there is also apt to be trouble. To determine if both IO-IRQ pairs are identical you must find out how they are set in both the driver and the hardware.

6.5 What is the IO Address and IRQ per the driver ?

Introduction

What the driver thinks is not necessarily how the hardware is actually set. If everything works OK then what the driver thinks is likely correct (set in the hardware) and you don't need to investigate (unless you're curious or want to become a guru). Ways to determine what the driver thinks include: boot-time messages [I/O Address & IRQ: Boot-time messages](#), the /proc directory "files" [The /proc directory and setserial](#), and the "setserial" command.

I/O Address & IRQ: Boot-time messages

In many cases your ports will automatically get low-level configured at boot-time (but not always correctly). To see what is happening, look at the start-up messages on the screen. Don't neglect to check the messages from the BIOS before Linux is loaded (no examples shown here). These BIOS messages may be frozen by pressing the Pause key. Use Shift-PageUp to scroll back to the messages after they have flashed by. Shift-PageDown will scroll in the opposite direction. The dmesg command (or looking at logs in /var/log) will show some of the messages but they seem to miss important ones from setserial. Here's an example of the start-up messages (as of mid 1999). Note that ttyS00 is the same as /dev/ttyS0.

```
At first you see what was detected (but the irq is only a wild guess):
```

```
Serial driver version 4.27 with no serial options enabled
ttyS00 at 0x03f8 (irq = 4) is a 16550A
ttyS01 at 0x02f8 (irq = 3) is a 16550A
ttyS02 at 0x03e8 (irq = 4) is a 16550A
```

```
Later setserial shows you what was saved, but it's not necessarily
```

Modem-HOWTO

correct either:

```
Loading the saved-state of the serial devices...
/dev/ttyS0 at 0x03f8 (irq = 4) is a 16550A
/dev/ttyS1 at 0x02f8 (irq = 3) is a 16550A
/dev/ttyS2 at 0x03e8 (irq = 5) is a 16550A
```

Note that there is a slight disagreement: The first message shows ttyS2 at irq=4 while the second shows it at irq=5. `dmesg` may not display the second message. In most cases the second message is the correct one. But if your having trouble it may be misleading. Before reading the explanation of all of this complexity in the rest of this section, you might just try using your serial port and see if it works OK. If so it may not be essential to read further.

The second message is from the `setserial` program being run at boot-time. It shows what the device driver thinks is the correct configuration. But this too could be wrong. For example, the irq could actually be set to irq=8 in the hardware (both messages wrong). The irq=5 could be there because someone incorrectly put this into a configuration file (or the like). The fact that Linux sometimes gets IRQs wrong is because it doesn't by default probe for IRQs. It just assumes the "standard" ones (first message) or accepts what you told it when you configured it (second message). Neither of these is necessarily correct. If the serial driver has the wrong IRQ, the serial port is very slow or doesn't seem to work at all.

The first message is a result of Linux probing the serial port addresses but it doesn't probe for IRQs. If a port shows up here it exists but the IRQ may be wrong. Linux doesn't check IRQs because doing so is not foolproof. It just assumes the IRQs are as shown because they are the "standard" values. You may check them manually with `setserial` using the `autoconfig` and `auto_irq` options but this isn't guaranteed to be correct either.

The data shown by the BIOS messages (which you see at first before Linux is booted) is what is initially set in the hardware. If your serial port is Plug-and-Play (PnP) then it's possible that "isapnp" or "setpci" will run and change these settings. Look for messages about this after Linux starts. The last serial port message shown in the example above should agree with the BIOS messages (as possibly modified by isapnp or setpci). If they don't agree then you either need to change the setting in the port hardware or use `setserial` to tell the driver what is actually set in the hardware.

Also, if you have Plug-and-Play (PnP) serial ports, they can only be found by PnP software unless the IRQ and IO has been set inside the hardware by Plug-and-Play software. Prior to kernel 2.4 this was a common reason why the start-up messages did not show a serial port that physically exists. A PnP BIOS may automatically low-level configure them. PnP configuring will be explained later.

The /proc directory and setserial

Type "`setserial -g /dev/ttyS*`". There are some other ways to find this info by looking at "files" in the `/proc` directory. Be warned that there is no guarantee that the same is set in the hardware.

`/proc/ioports` will show the IO addresses that the drivers are using. `/proc/interrupts` shows the IRQs that are used by drivers of currently running processes (that have devices open). It shows how many interrupts have actually be issued. `/proc/tty/driver/serial` shows much of the above, plus the number of bytes that have been received and sent (even if the device is not now open).

Note that for the IO addresses and IRQ assignments, you are only seeing what the driver thinks and not necessarily what is actually set in the hardware. The data on the actual number of interrupts issued and bytes processed is real however. If you see a large number of interrupts and/or bytes then it probably means that the

device is (or was) working. But the interrupts might be from another device. If there are no bytes received (rx:0) but bytes were transmitted (tx:3749 for example), then only one direction of flow is working (or being utilized).

Sometimes a showing of just a few interrupts doesn't mean that the interrupt is actually being physically generated by any serial port. Thus if you see almost no interrupts for a port that you're trying to use, that interrupt might not be set in the hardware. To view `/proc/interrupts` to check on a program that you're currently running (such as "minicom") you need to keep the program running while you view it.

6.6 What is the IO Address & IRQ of my Serial Port Hardware?

Introduction

If it's PCI or ISA PnP then what's set in the hardware has been done by PnP methods. Even if nothing has been set or the port disabled, PnP ports may still be found by using "lspci -v" or "isapnp --dumppregs". Ports disabled by jumpers (or hardware failures) are completely lost. See [ISA PnP ports](#), [PCI: What IOs and IRQs have been set?](#), [PCI: Enabling a disabled port](#)

PnP ports don't store their configuration in the hardware when the power is turned off. This is in contrast to Jumpers (non-PnP) which remain the same with the power off. That's why a PnP port is more likely to be found in a disabled state than an old non-PnP one.

PCI: What IOs and IRQs have been set?

For PCI, the BIOS almost always sets the IRQ and may set the IO address as well. To see how it's set use "lspci -vv" (best) or look in `/proc/bus/pci` (or for kernels <2.2 `/proc/pci`). The modem's serial port is often called a "Communication controller". Look for this. If lspci shows "I/O ports at ... [disabled]" then the serial port is disabled and the hardware has no IO address so it's lost and can't be used. See [PCI: Enabling a disabled port](#) for how to enable it.

If more than one IO address is shown, the first one is more likely to be it. You can't change the IRQ (at least not with "setpci") This is because if one writes an IRQ it's hardware register no action is taken on it. It's the BIOS that should actually set up the IRQs and then write the correct value to this register for lspci to view. If you must, change the IO address with "setpci" by changing the `BASE_ADDRESS_0` or the like.

PCI: Enabling a disabled port

If the port communicates via an IO address then "lspci -vv" should show "Control: I/O+ ..." with + meaning that the IO address is enabled. If it shows "I/O-" (and "I/O ports at ... [disabled]") then you may need to use the setpci command to enable it. For example "setpci -d 151f:000 command=101". 151f is the vendor id, and 000 is the device id both obtained from "lspci -n -v" or from `/proc/bus/pci` or from "scanpci -v". The "command=101" means that 101 is put into the command register which is the same as the "Control" register displayed by "lspci". The 101h sets two bits: the 1 sets I/O to + and the 100 part keeps SERR# set to +. In this case only the SERR# bit of the Control register was initially observed to be + when the lspci command was run. So we kept it enabled to + by setting bit 8 (where bit 0 is I/O) to 1 by the first 1 in 101. Some serial cards don't use SERR# so if you see SERR#- then there's no need to enable it so then use: command=1. Then you'll need to set up "setserial" to tell the driver the IO and IRQ.

Bit 8 is actually the 9th bit since we started counting bits from 0. Don't be alarmed that `lspci` shows a lot of – signs showing that the card doesn't have many features available (or enabled). Serial ports are relatively slow and don't need these features.

Another way to enable it is to let the BIOS do it by telling the BIOS that you don't have a plug-and-play operating system. Then the BIOS should enable it when you start your PC. If you have MS Windows9x on the same PC then doing this might cause problems with Windows (see [Plug-and-Play-HOWTO](#)).

ISA PnP ports

For an ISA Plug-and-Play (PnP) port one may try the `pnpdump` program (part of `isapnptools`). If you use the `—dumpregs` option then it should tell you the actual IO address and IRQ set in the port. It should also find an ISA PnP port that is disabled. The address it "trys" is not the device's IO address, but a special address used for communicating with PnP cards.

Finding a port that is not disabled (ISA, PCI, PnP, non-PnP)

Perhaps the BIOS messages will tell you some info before Linux starts booting. Use the shift-PageUp key to step back thru the boot-time messages and look at the very first ones which are from the BIOS. This is how it was before Linux started. `setserial` can't change it but `isapnp` or `setpci` can. Starting with kernel 2.4, the serial driver can make such changes for many (but not all) serial ports.

Using "scanport" (Debian only ??) will probe all I/O ports and will indicate what it thinks may be serial port. After this you could try probing with `setserial` using the "autoconfig" option. You'll need to guess the addresses to probe at (using clues from "scanport"). See [What is Setserial](#).

For a port set with jumpers, the IO ports and IRQs are set per the jumpers. If the port is not Plug-and-Play (PnP) but has been setup by using a DOS program, then it's set at whatever the person who ran that program set it to.

Exploring via MS Windows (a last resort)

For PnP ports, checking on how it's configured under DOS/Windows may (or may not) imply how it's under Linux. MS Windows stores its configuration info in its Registry which is not used by Linux so they are not necessarily configured the same. If you let a PnP BIOS automatically do the configuring when you start Linux (and have told the BIOS that you don't have a PnP operating system when starting Linux) then Linux should use whatever configuration is in the BIOS's non-volatile memory. Windows also makes use of the same non-volatile memory but doesn't necessarily configure it that way.

6.7 Choosing Serial IRQs

If you have Plug-and-Play ports then either a PnP BIOS or a serial driver may configure all your devices for you so then you may not need to choose any IRQs. PnP software determines what it thinks is best and assigns them (but it's not always best). But if you directly use `isapnp` (ISA bus) or jumpers then you have to choose. If you already know what IRQ you want to use you could skip this section except that you may want to know that IRQ 0 has a special use (see the following paragraph).

IRQ 0 is not an IRQ

While IRQ 0 is actually the timer (in hardware) it has a special meaning for setting a serial port with `setserial`. It tells the driver that there is no interrupt for the port and the driver then will use polling methods. Such polling puts more load on the CPU but can be tried if there is an interrupt conflict or mis-set interrupt. The advantage of assigning IRQ 0 is that you don't need to know what interrupt is set in the hardware. It should be used only as a temporary expedient until you are able to find a real interrupt to use.

Interrupt sharing, Kernels 2.2+

Sharing of IRQs is where two devices use the same IRQ. As a general rule, this wasn't allowed for the ISA bus. The PCI bus may share IRQs but one can't share the same IRQ between the ISA and the PCI bus. Most multi-port boards may share IRQs. Sharing is not as efficient since every time a shared interrupt is given a check must be made to determine where it came from. Thus if it's feasible, it's nicer to allocate every device its own interrupt.

Prior to kernel 2.2, serial IRQs could not be shared with each other except for most multiport boards. Starting with kernel 2.2 serial IRQs may be sometimes shared between serial ports. In order for sharing to work in 2.2 the kernel must have been compiled with `CONFIG_SERIAL_SHARE_IRQ`, and the serial port hardware must support sharing (so that if two serial cards put different voltages on the same interrupt wire, only the voltage that means "this is an interrupt" will prevail). Since the PCI bus specs permit sharing, any PCI card should allow sharing.

What IRQs to choose?

The serial hardware often has only a limited number of IRQs. Also you don't want IRQ conflicts. So there may not be much of a choice. Your PC may normally come with `ttyS0` and `ttyS2` at IRQ 4, and `ttyS1` and `ttyS3` at IRQ 3. Looking at `/proc/interrupts` will show which IRQs are being used by programs currently running. You likely don't want to use one of these. Before IRQ 5 was used for sound cards, it was often used for a serial port.

Here is how Greg (original author of `Serial-HOWTO`) set his up in `/etc/rc.d/rc.serial`. `rc.serial` is a file (shell script) which runs at start-up (it may have a different name or location). For versions of "setserial" after 2.15 it's not always done this way anymore but this example does show the choice of IRQs.

```
/sbin/setserial /dev/ttyS0 irq 3          # my serial mouse
/sbin/setserial /dev/ttyS1 irq 4          # my Wyse dumb terminal
/sbin/setserial /dev/ttyS2 irq 5          # my Zoom modem
/sbin/setserial /dev/ttyS3 irq 9          # my USB modem
```

Standard IRQ assignments:

```
IRQ 0    Timer channel 0 (May mean "no interrupt".  See below.)
IRQ 1    Keyboard
IRQ 2    Cascade for controller 2
IRQ 3    Serial port 2
IRQ 4    Serial port 1
IRQ 5    Parallel port 2, Sound card
IRQ 6    Floppy diskette
IRQ 7    Parallel port 1
IRQ 8    Real-time clock
IRQ 9    Redirected to IRQ2
IRQ 10   not assigned
```

Modem-HOWTO

```
IRQ 11    not assigned
IRQ 12    not assigned
IRQ 13    Math coprocessor
IRQ 14    Hard disk controller 1
IRQ 15    Hard disk controller 2
```

There is really no Right Thing to do when choosing interrupts. Try to find one that isn't being used by the motherboard, or any other boards. 2, 3, 4, 5, 7, 10, 11, 12 or 15 are possible choices. Note that IRQ 2 is the same as IRQ 9. You can call it either 2 or 9, the serial driver is very understanding. If you have a very old serial board it may not be able to use IRQs 8 and above.

Make sure you don't use IRQs 1, 6, 8, 13 or 14! These are used by your motherboard. You will make her very unhappy by taking her IRQs. When you are done you might want to double-check `/proc/interrupts` when programs that use interrupts are being run and make sure there are no conflicts.

6.8 Choosing Addresses --Video card conflict with ttyS3

Here's a problem with some old serial cards. The IO address of the IBM 8514 video board (and others like it) is allegedly `0x?2e8` where ? is 2, 4, 8, or 9. This may conflict with the IO address of `ttyS3` at `0x02e8`. You may think that this shouldn't happen since the addresses are different in the high order digit (the leading 0 in `02e8`). You're right, but a poorly designed serial port may ignore the high order digit and respond to any address that ends in `2e8`. That is bad news if you try to use `ttyS3` (ISA bus) at this IO address.

For the ISA bus you should try to use the default addresses shown below. PCI cards use different addresses so as not to conflict with ISA addresses. The addresses shown below represent the first address of an 8-byte range. For example `3f8` is really the range `3f8-3ff`. Each serial device (as well as other types of devices that use IO addresses) needs its own unique address range. There should be no overlaps (conflicts). Here are the default addresses for commonly used serial ports on the ISA bus:

```
ttyS0 address 0x3f8
ttyS1 address 0x2f8
ttyS2 address 0x3e8
ttyS3 address 0x2e8
```

Suppose there is an address conflict (as reported by `setserial -g /dev/ttyS*`) between a real serial port and another port which does not physically exist (and shows `UART: unknown`). Such a conflict shouldn't cause problems but it sometimes does in older kernels. To avoid this problem don't permit such address conflicts or delete `/dev/ttySx` if it doesn't physically exist.

6.9 Set IO Address & IRQ in the hardware (mostly for PnP)

After it's set in the hardware don't forget to insure that it also gets set in the driver by using `setserial`. For non-PnP serial ports they are either set in hardware by jumpers or by running a DOS program ("jumperless") to set them (it may disable PnP). The rest of this subsection is only for PnP serial ports. Here's a list of the possible methods of configuring PnP serial ports:

- Using a PnP BIOS CMOS setup menu (usually only for external modems on `ttyS0` (Com1) and `ttyS1` (Com2))
- Letting a PnP BIOS automatically configure a PnP serial port See [Using a PnP BIOS to I0-IRQ Configure](#)
- Doing nothing if the serial driver recognized your card OK

Modem–HOWTO

- Using `isapnp` for a PnP serial port non–PCI)
- Using `setpci` (`pciutils` or `pcitools`) for the PCI bus

The IO address and IRQ must be set (by PnP) in their registers each time the system is powered on since PnP hardware doesn't remember how it was set when the power is shut off. A simple way to do this is to let a PnP BIOS know that you don't have a PnP OS and the BIOS will automatically do this each time you start. This might cause problems in Windows (which is a PnP OS) if you start Windows with the BIOS thinking that Windows is not a PnP OS. See [Plug–and–Play–HOWTO](#).

Plug–and–Play (PnP) was designed to automate this io–irq configuring, but for Linux it initially made life much more complicated. In modern Linux (2.4 kernels —partially in 2.2 kernels), each device driver has to do it's own PnP (using supplied software which it may utilize). There is unfortunately no centralized planning for assigning IO addresses and IRQs as there is in MS Windows. But it usually works out OK in Linux anyway.

Using a PnP BIOS to IO–IRQ Configure

While the explanation of how to use `setpci` or `isapnp` for io–irq configuring should come with such software, this is not the case if you want to let a PnP BIOS do such configuring. Not all PnP BIOS can do this. The BIOS usually has a CMOS menu for setting up the first two serial ports. This menu may be hard to find. For an "Award" BIOS it was found under "chipset features setup" There is often little to choose from. Unless otherwise indicated in a menu, these first two ports normally get set at the standard IO addresses and IRQs. See [Serial Port Device Names & Numbers](#)

Whether you like it or not, when you start up a PC a PnP BIOS starts to do PnP (io–irq) configuring of hardware devices. It may do the job partially and turn the rest over to a PnP OS (which Linux is in some sense) or if it thinks you don't have a PnP OS it may fully configure all the PnP devices but not configure the device drivers. This is what you want but it's not always easy to figure out exactly what the PnP BIOS has done.

If you tell the BIOS that you don't have a PnP OS, then the PnP BIOS should do the configuring of all PnP serial ports —not just the first two. An indirect way to control what the BIOS does (if you have Windows 9x on the same PC) is to "force" a configuration under Windows. See [Plug–and–Play–HOWTO](#) and search for "forced". It's easier to use the CMOS BIOS menu which may override what you "forced" under Windows. There could be a BIOS option that can set or disable this "override" capability.

If you add a new PnP device, the BIOS should PnP configure it. It could even change the io–irq of existing devices if required to avoid any conflicts. For this purpose, it keeps a list of non–PnP devices provided that you have told the BIOS how these non–PnP devices are io–irq configured. One way to tell the BIOS this is by running a program called ICU under DOS/Windows.

But how do you find out what the BIOS has done so that you set up the device drivers with this info? The BIOS itself may provide some info, either in its setup menus or via messages on the screen when you turn on your computer. See [What is set in my serial port hardware?](#). Other ways of finding out is to use `lspci` for the PCI bus or `isapnp` —`dumpregs` for the ISA bus. The cryptic results it shows you may not be clear to a novice.

6.10 Giving the IRQ and IO Address to Setserial

Once you've set the IRQ and IO address in the hardware (or arranged for it to be done by PnP) you also need to insure that the "setserial" command is run each time you start Linux. See the subsection [Boot–time](#)

7. [Configuring the Serial Driver \(high-level\) "stty"](#)

7.1 Introduction

This configuring is normally done by your communications program such as wvdial. It may do much of it without even letting you know what it's done. In olden days it was done with the "stty" utility. If you set something with stty, the communications program may change the setting so it's usually best to just let the communications program handle it. See [What is stty ?](#)

7.2 Hardware flow control (RTS/CTS)

See [Flow Control](#) for an explanation of it. You should always use hardware flow control if possible. Your communication program or "getty" should have an option for setting it (and if you're in luck it might be enabled by default). It needs to be set both inside your modem (by an init string or default) and in the device driver. Your communication program should set both of these (if you configure it right).

If none of the above will fully enable hardware flow control. Then you must do it yourself. For the modem, make sure that it's either done by the init string or is on by default. If you need to tell the device driver to do it is best done on startup by putting it in a file that runs at boot-time. See the subsection [Boot-time Configuration](#) You need to add the following to such a file for each serial port (example is ttyS2) you want to enable hardware flow control on:

```
stty crtscts < /dev/ttyS2
or
stty -F /dev/ttyS2 crtscts
```

If you want to see if flow control is enabled do the following: In minicom (or the like) type AT&V to see how the modem is configured and look for &K3 which means hardware flow control. Then without exiting the communications program (such as minicom) see if the device driver knows about it by typing: stty -F /dev/ttyS2 -a. Look for "crtscts" (without a disabling minus sign).

7.3 Speed Settings

Besides flow control there is speed. See [What Speed Should I Use with My Modem](#). There's also are parity and bits-per-byte settings. Normally the port is set by the communications program at 8N1 (8-bits per byte, No parity, and 1 stop bit). If you're running PPP then you must use 8N1. So if you get a complaint that it's not 8-bit clean then it's likely not 8N1 as it should be.

7.4 Ignore CD Setting: clocal

If the modem is not sending a CD signal and clocal is disabled (stty shows -clocal) then a program may not be able to open the serial port. If the port can't open, the program may just hang, waiting (often in vain) for a CD signal from the modem. Actually, a skilled programmer can write the program in such a way as to force the port to open even when CD and -clocal say not to so it's not always a problem.

One way to avoid any possible problems is to send "AT&C" to the modem so that CD from the modem will

always be on. CD always-on is fine for dial-out but for dial-in the CD signal is sometimes (but rarely) used to detect an incoming call.

Minicom sets clocal automatically when it starts up so there is no problem. But version 6.0.192 of Kermit hung when I set -clocal and tried to "set line ...".

Here's a problem that existed prior to the year 2000 or thereabouts. It's since been fixed. If -clocal is set and there is no CD signal, then the "stty" command will hang and there is seemingly no way to set clocal (except by running minicom). But minicom will restore -clocal when it exits. One way to get out of this is to use minicom to send the "AT&C" to the modem (to get the CD signal) and then exit minicom with no reset so that the CD signal always remains on. Then you may use stty again.

7.5 What is stty ?

stty is something like setserial but it sets the speed (baud rate), hardware flow control, and other parameters of a serial port. Typing "stty -F /dev/ttyS2 -a" should show you how ttyS2 is configured. Most of the stty settings are for things that you never need to use with modems. Many of the settings are only needed for Text-Terminals (and some are only needed for antique terminals of the 1970s). Your communication package should automatically set up the several settings needed for modems. For this reason you normally don't need to use stty so it's not covered much in this Modem-HOWTO. But stty is sometimes useful for trouble-shooting. More is said about stty in the Serial-HOWTO or Text-Terminal-HOWTO..

8. [Modem Configuration \(excluding serial port\)](#)

8.1 Finding Your Modem

Before spending a lot of time deciding how to configure your modem, you first need to make sure it can be found and that AT-commands and the like can be sent to it. So I suggest you first give it a very simple configuration using the communication program you will be using on the port and see if it works. If this works you may then want to improve on the configuration, if not then see [My Modem is Physically There but Can't be Found](#). A winmodem may be hard to find and will not work under Linux.

8.2 AT Commands

While the serial port on which a modem resides requires configuring, so does the modem itself. The modem is configured by sending AT commands (or the like) to it on the same serial line that is used to send data.

Most modems use an AT command set. These are cryptic and short ASCII commands where all command strings must be prefaced by the letters AT. AT means: ATtention, expect a command to follow. For example: ATZ&K3<return> This is an AT-command string with two commands here: Z and &K3. Z is short for Z0 and a few modems require that you use Z0 instead of just Z. It's like this for other commands ending in 0. The command string is terminated by a return character (use the <enter> key if you are manually typing it). A string that's too long (40 or more characters) may not work on older modems. You may use either uppercase or lowercase letters.

Unfortunately there are many different variations of the AT command set so that what works for one modem may or may not work for another modem. Thus there is no guarantee that the AT commands given in this section will work on your modem.

Modem-HOWTO

Such command strings are either automatically sent to the modem by communication programs or are manually typed in by you. Most communication programs provide a screen where you may change (edit) and save the init string that the communication program will use. The modem itself has a stored configuration (profile) which is like a long init string. It represents the configuration of the modem when it's first tuned on. You may change it to suit your taste. In most cases there are a few different such configurations (profiles) and there are ways to designate one of them to be active.

If you have a manual for your modem (either on paper or on floppy disk) you might find AT-commands there. 3Com modems (and others ??) have AT-Command help files built into the modem so if you type say "AT\$" to the modem it will display some "online help".

You can also find info on AT commands on the Internet. You should first try a site for your modem manufacturer. If this doesn't work out then you can search the Internet using terms that are from AT commands such as &C1, &D3, etc. This will tend to find sites that actually list AT-Commands instead of sites that just talk about them in general. You might also try a few of the sites listed in the subsection [Web Sites](#). Be warned that the AT-commands for a different brand of modem may be somewhat different.

8.3 Init Strings: Saving and Recalling

The examples given in this subsection are from the Hayes AT modem command set. All command strings must be prefaced by the two letters AT. For example: AT&C1&D3^M (^M is the return character). When a modem is powered on, it automatically configures itself with one of the configurations it has stored in its non-volatile memory. If this configuration is satisfactory there is nothing further to do.

If it's not satisfactory, then one may either alter the stored configuration or configure the modem each time you use it by sending it a string of commands known as an "init string" (= initialization string). Normally, a communication program does this. What it sends will depend on how you configured the communications program. Your communication program should allow you to edit the init string and change it to whatever you want. Sometimes the communications program will let you select the model of your modem and then it will use an init string that it thinks is best for that modem.

The configuration of the modem when it's first powered on may be expressed by an init string. You might think of this as the default "string" (called a profile). If your communications program sends the modem another string (the init string), then this string will modify the default configuration. For example, if the init string only contains two commands, then only those two items will be changed. However, some commands will recall a stored profile from inside the modem so a single such command in the init string can thereby change everything in the configuration.

Modern modems have a few different stored profiles to choose from that are stored in the modem's non-volatile memory (it's still there when you turn it off). In my modem there are two factory profiles (0 and 1, neither of which you can change) and two user defined profiles (0 and 1) that the user may set and store. Your modem may have more. To view some of these profiles send the command &V. At power-up one of the user-defined profiles is loaded. For example, if you type the command &Y0 (just Y0 for a 3Com modem) then in the future profile 0 will be used at power-on.

There are also commands to load (activate) any of the stored profiles. Such a load command may be put in an init string. Of course if it loads the same profile that was automatically loaded at power-up, nothing is changed (unless the active profile has been modified since power-up). Since your profile could have thus been modified it's a good idea to use some kind of an init string even if it does nothing more than load a stored profile.

Modem-HOWTO

Examples of loading saved profiles:

Z0 loads user-defined profile 0 and resets (hangs up, etc.)

&F1 loads factory profile 1

Once you have sent commands to the modem to configure it the way you want (such as loading a factory profile and modifying it a little) you may save this as a user-defined profile:

&W0 saves the current configuration to user-profile 0.

Many people don't bother saving a good configuration in their modem, but instead, send the modem a longer init string each time the modem is used. Another method is to restore the factory default by &F1 at the start of the init string and then modify it a little by adding a few other commands to the end of the init string. Since there is no way to modify the factory default this prevents anyone from changing the configuration by modifying (and saving) the user-defined profile.

You may choose an init string supplied by someone else that they think is right for your modem. Some communication programs have a library of init strings to select from. The most difficult method (and one which will teach you the most about modems) is to study the modem manual and write one yourself. You could save this configuration inside the modem so that you don't need an init string. A third alternative is to start with an init string that someone else wrote, but modify it to suit your purposes.

If you look at init strings used by communication programs you may see symbols which are not valid modem commands. These symbols are commands to the communication program itself and will not be sent to the modem. For example, ~ may mean to pause briefly.

Where is my "init string" so I can modify it ?

This depends on your communication program (often a PPP program). If this is the latest version of Modem-HOWTO send me info for other cases.

- Gnome: run pppsetup
- wvdial: edit /etc/wvdial.conf
- minicom: hit ^Ao (or possibly ALT-o), then select "Modem and Dialing"

8.4 Other AT Modem Commands

For dial-in see [Dial-in Modem Configuration](#). The rest of this section is mostly what was in the old Serial-HOWTO. All strings must start with AT. Here's a few Hayes AT codes that should be in the string (if they are not set by using a factory default or by a saved configuration).

- E1 command echo ON
- Q0 result codes are reported
- V1 result codes are verbose
- S0=0 never answer (uugetty does this with the WAITFOR option)

Here's some more AT commands for special purposes:

- &C1 CD is only on when you're connected
- &S0 DSR is always on
- X3 Dial even if there is no dialtone (Use where dial-tones don't exist).

Note: to get his old USR Courier V.34 modem to reset correctly when DTR drops, Greg Hankins had to set `&D2` and `S13=1` (this sets bit 0 of register S13). This has been confirmed to work on USR Sportster V.34 modems as well.

Note: some old Supra modems treat CD differently than other modems. If you are using a Supra, try setting `&C0` and *not* `&C1`. You must also set `&D2` to handle DTR correctly.

8.5 Blacklisting

If phone number is dialed a few times with no success, some modems may blacklist a phone number. After a certain time you may try again. Some countries require this to reduce needless repeated dialing. To view the blacklist try `%B`. To delete the blacklist use these AT commands:

- SR Robotics o 3COM: `s40=2` or if NG try `s40=7`
- Lucent: `%t21,18,0`
- Rockwell: `%tcb`
- Cirrus Logic: `*nc9`

8.6 What AT Commands are Now Set in my Modem?

You may try to use `minicom` for viewing your modem profile. It's best not to have any other process running on the modem port when you do this. If you have set up `minicom` for your modem, then you may type on the command line: `minicom -o` to start `minicom` without restoring the saved modem profile. Then type `at&v` to display the profile. To exit `minicom` without disturbing this profile, use the `q` (quit) command for exiting without resetting.

The above may not work for various reasons. If the modem has been set not to echo result codes it may not even display any profile. If there is another process running on the modem port at the same time, some of what the modem sends to you is likely to be read by the other process so you will see only part of the profile. Is there some way to temporarily stop the other process on the port so it will not interfere? I tried the "stop" signal using the "kill" command but it didn't work. If this is the latest version of this HOWTO, let me know if you find a way to do it.

If you have at least one process running on the modem port and kill them, the modem's profile may be reset so you will not observe what the original profile was. This will happen if you kill `getty` (or it's replacements: `login` or `bash`) and have `&D3` set. The killing of `getty` (or the like) will drop DTR and reset the modem's profile to the power-on state. To keep `getty` from respawning when killed, comment it out in `/etc/inittab` and do an "init q".

8.7 Modem States (or Modes)

Since the channel for sending AT commands to the modem is the same channel that is used for the flow of data (files, packets, etc.) then it's important to cleanly separate the AT commands from the data.

When the modem is first turned on it's in the command mode (also called terminal mode, idle state or AT-command mode). Anything sent to it from the PC is assumed to be an AT command and not data. Then if a dial command is sent to it (`ATD...`), it dials and connects to another modem. It's now in the on-line data mode (connected) and sends and receives data (such as Internet pages). In this mode, any AT command one tries to send it will not work but will be transmitted to the other modem instead. Except for the escape

command. This is +++ with a minimum time delay both at the start and end. The time delay allows the modem to determine that it is likely a real escape and not just +++ in a file being transmitted.

So we have two states so far: AT-command and on-line data. But there is a third important state which is sort of a combination of these two. It's the on-line command mode. This is when the modem maintains a connection (without sending/receiving data) but anything sent from the PC is interpreted as an AT command. This is the state reached with a +++ escape signal or by a DTR drop from the PC provided the &D1 has been set. Then one can send AT commands to the modem including commands which will leave this state and go to one of the other two states.

There are other states also: dialing state and handshaking state but they normally lead to the connected (on-line) state. If they don't then the modem should hang up, thereby returning to the initial AT-command (or idle) state.

9. Serial Port Devices /dev/ttyS2, (or /dev/ttys/2) etc.

For creating devices in the device directory see: the Serial-HOWTO: "Creating Devices In the /dev directory".

9.1 Devfs (The new Device File System)

This is a new type of device interface to Linux. It's optional starting with kernel 2.4. It's more efficient than the conventional interface and makes it easy to deal with a huge number of devices. The device names have all changed as well. But there's an option to continue using the old names. For a detailed description of it see: <http://www.atnf.csiro.au/~rgooch/linux/docs/devfs.html>

The name changes (if used) are: ttyS2 becomes tts/2 (Serial port), tty3 becomes vc/3 (Virtual Console), pty1 becomes pty/m1 (PTY master), tty2 becomes pty/s2 (PTY slave). "tts" looks like a directory which contains devices "files": 0, 1, 2, etc. All of these new names should still be in the /dev directory although optionally one may put them elsewhere.

9.2 Serial Port Device Names & Numbers

Devices in Linux have major and minor numbers (unless you use the new devfs). The serial port ttySx (x=0,1,2, etc.) has major number 4. You may see this (and the minor numbers too) by typing: "ls -l ttyS*" in the /dev directory.

There formerly was a "cua" name for each serial port and it behaved just a little differently. For example, ttyS2 would correspond to cua2. The cua major number was 5 and minor numbers started at 64. You may still have the cua devices in your /dev directory but they are now deprecated. Their drivers behave slightly different than for the ttyS ones. name="cua Device Obsolete">.")

Dos/Windows use the COM name while the setserial program uses tty00, tty01, etc. Don't confuse these with dev/tty0, dev/tty1, etc. which are used for the console (your PC monitor) but are not serial ports. The table below is for the "standard" case (but yours could be different). The major/minor numbers don't exist with the devfs. For the PCI bus the IO addresses are different.

			ISA IO			devfs usb
dos	major	minor	address	devfs	devfs usb	acm modem
COM1	/dev/ttyS0	4,	3F8	/dev/tts/0	/dev/usb/tts/0	/dev/usb/acm/0

Modem–HOWTO

```
COM2 /dev/ttyS1 4, 65; 2F8 /dev/tts/1 /dev/usb/tts/1 /dev/usb/acm/1
COM3 /dev/ttyS2 4, 66; 3E8 /dev/tts/2 /dev/usb/tts/2 /dev/usb/acm/2
COM4 /dev/ttyS3 4, 67; 2E8 /dev/tts/3 /dev/usb/tts/3 /dev/usb/acm/3
```

9.3 USB (Universal Serial Bus) Ports

The serial ports on the USB are: `/dev/ttyUSB0`, `/dev/ttyUSB1`, etc. The devfs names for these are: `/dev/usb/tts/0`, `/dev/usb/tts/1`, etc. For many modems they are `/dev/usb/acm/0`, etc. (in devfs notation). For more info see the usb subdirectory in the kernel documentation directory for files: acm and usb–serial.

9.4 Link ttySN to /dev/modem

On some installations, two extra devices will be created, `/dev/modem` for your modem and `/dev/mouse` for a mouse. Both of these are symbolic links to the appropriate serial device in `/dev` which you specified during the installation Except if you have a bus mouse, then `/dev/mouse` will point to the bus mouse device).

Formerly (in the 1990s) the use of `/dev/modem` was discouraged since lock files might not realize that it was really say `/dev/ttyS2`. The newer lock file system doesn't fall into this trap so it's now OK to use such links.

9.5 cua Device Obsolete

Each ttyS device has a corresponding cua device. But the cua device is deprecated so it's best to use ttyS (unless cua is required). There is a difference between cua and ttyS but a savvy programmer can make a ttyS port behave just like a cua port so there is no real need for the cua anymore. Except that some older programs may need to use the cua.

What's the difference? The main difference between cua and ttyS has to do with what happens in a C–program when an ordinary "open" command tries to open the port. If a cua port has been set to check modem control signals, the port can be opened even if the CD modem control signal says not to. Astute programming (by adding additional lines to the program) can force a ttyS port to behave this way also. But a cua port can be more easily programmed to open for dialing out on a modem even when the modem fails to assert CD (since no one has called into it and there's no carrier). That's why cua was once used for dial–out and ttyS used for dial–in.

Starting with Linux kernel 2.2, a warning message is put in the kernel log when one uses cua. This is an omen that cua is defunct and should be avoided if possible.

10. [Interesting Programs You Should Know About](#)

10.1 What is setserial ?

This part is in 3 HOWTOs: Modem, Serial, and Text–Terminal. There are some minor differences, depending on which HOWTO it appears in.

Introduction

If you have a Laptop (PCMCIA) don't use `setserial` until you read [Laptops: PCMCIA](#). `setserial` is a program which allows you to tell the device driver software the I/O address of the serial port, which interrupt (IRQ) is set in the port's hardware, what type of UART you have, etc. Since there's a good chance that the serial ports will be automatically detected and set, many people never need to use `setserial`. In any case `setserial` will not work without either serial support built into the kernel or loaded as a module. The module may get loaded automatically if you (or a script) tries to use `setserial`.

`Setserial` can also show how the driver is currently set. In addition, it can be made to probe the hardware I/O port addresses to try to determine the UART type and IRQ, but this has severe limitations. See [Probing](#). Note that it can't set the IRQ or the port address in the hardware of PnP serial ports (but the plug-and-play features of the serial driver may do this). It can't read the PnP data stored in configuration registers in the hardware.

If you only have one or two built-in serial ports, they will usually get set up correctly without using `setserial`. Otherwise, if you add more serial ports (such as a modem card) you may need to deal with `setserial`. Besides the man page for `setserial`, check out info in `/usr/doc/setserial...` or `/usr/share/doc/setserial`. It should tell you how `setserial` is handled in your distribution of Linux.

`Setserial` is often run automatically at boot-time by a start-up shell-script for the purpose of assigning IRQs, etc. to the driver. `Setserial` will only work if the serial module is loaded (or if the equivalent was compiled into your kernel). If the serial module gets unloaded later on, the changes previously made by `setserial` will be forgotten by the kernel. But recent (2000) distributions may contain scripts that save and restore this. If not, then `setserial` must be run again to reestablish them. In addition to running via a start-up script, something akin to `setserial` also runs earlier when the serial module is loaded (or the like). Thus when you watch the start-up messages on the screen it may look like it ran twice, and in fact it has.

`Setserial` does not set either IRQ's nor I/O addresses in the serial port hardware itself. That is done either by jumpers or by plug-and-play. You must tell `setserial` the identical values that have been set in the hardware. Do not just invent some values that you think would be nice to use and then tell them to `setserial`. However, if you know the I/O address but don't know the IRQ you may command `setserial` to attempt to determine the IRQ.

You can see a list of possible commands by just typing `setserial` with no arguments. This fails to show you the one-letter options such as `-v` for verbose which you should normally use when troubleshooting. Note that `setserial` calls an IO address a "port". If you type:

```
setserial -g /dev/ttyS*
```

you'll see some info about how that device driver is configured for your ports. Note that where it says "UART: unknown" it probably means that no uart exists. In other words you probably have no such serial port and the other info shown about the port is meaningless and should be ignored. If you really do have such a serial port, `setserial` doesn't recognize it and that needs to be fixed.

If you add `-a` to the option `-g` you will see more info although few people need to deal with (or understand) this additional info since the default settings you see usually work fine. In normal cases the hardware is set up the same way as "setserial" reports, but if you are having problems there is a good chance that "setserial" has it wrong. In fact, you can run "setserial" and assign a purely fictitious I/O port address, any IRQ, and whatever uart type you would like to have. Then the next time you type "setserial ..." it will display these bogus values without complaint. They will also be officially registered with the kernel as displayed (at the top of the screen)

Modem-HOWTO

by the "scanport" command (Debian). Of course the serial port driver will not work correctly (if at all) if you attempt to use such a port. Thus when giving parameters to "setserial" anything goes. Well almost. If you assign one port a base address that is already assigned (such as 3e8) it may not accept it. But if you use 3e9 it will accept it. Unfortunately 3e9 is already assigned since it is within the range starting at base address 3e8. Thus the moral of the story is to make sure your data is correct before assigning resources with setserial.

While assignments made by setserial are lost when the PC is powered off, a configuration file may restore them (or a previous configuration) when the PC is started up again. In newer versions, what you change by setserial may get automatically saved to a configuration file. In older versions, the configuration file only changes if you edit it manually so the configuration always remains the same from boot to boot. See [Configuration Scripts/Files](#)

Probing

Prior to probing with "setserial", one may run the "scanport" (Debian) command to check all possible ports in one scan. It makes crude guesses as to what is on some ports but doesn't determine the IRQ. But it's a fast first start. It may hang your PC but so far it's worked fine for me. Note that non-Debian distributions don't seem to supply "scanport". Is there an another scan program?

With appropriate options, setserial can probe (at a given I/O address) for a serial port but you must guess the I/O address. If you ask it to probe for /dev/ttyS2 for example, it will only probe at the address it thinks ttyS2 is at (2F8). If you tell setserial that ttyS2 is at a different address, then it will probe at that address, etc. See [Probing](#)

The purpose of this is to see if there is a uart there, and if so, what its IRQ is. Use "setserial" mainly as a last resort as there are faster ways to attempt it such as wvdialconf to detect modems, looking at very early boot-time messages, or using pnpdump --dumppregs. To try to detect the physical hardware use for example :

```
setserial /dev/ttyS2 -v autoconfig
```

If the resulting message shows a uart type such as 16550A, then you're OK. If instead it shows "unknown" for the uart type, then there is supposedly no serial port at all at that I/O address. Some cheap serial ports don't identify themselves correctly so if you see "unknown" you still might have a serial port there.

Besides auto-probing for a uart type, setserial can auto-probe for IRQ's but this doesn't always work right either. In one case it first gave the wrong irq but when the command was repeated it found the correct irq. In versions of setserial >= 2.15, the results of your last probe test could be automatically saved and put into the configuration file /etc/serial.conf which will be used next time you start Linux. At boot-time when the serial module loads (or the like), a probe for UARTs is made automatically and reported on the screen. But the IRQs shown may be wrong. The second report of the same is the result of a script which usually does no probing and thus provides no reliable information as to how the hardware is actually set. It only shows configuration data someone wrote into the script or data that got saved in /etc/serial.conf.

It may be that two serial ports both have the same IO address set in the hardware. Of course this is not permitted but it sometimes happens anyway. Probing detects one serial port when actually there are two. However if they have different IRQs, then the probe for IRQs may show IRQ = 0. For me it only did this if I first used setserial to give the IRQ a fictitious value.

Boot-time Configuration

When the kernel loads the serial module (or if the "module equivalent" is built into the kernel) then only `ttys{0-3}` are auto-detected and the driver is set to use only IRQs 4 and 3 (regardless of what IRQs are actually set in the hardware). You see this as a boot-time message just like as if `setserial` had been run.

To correct possible errors in IRQs (or for other reasons) there may be a file somewhere that runs `setserial` again. Unfortunately, if this file has some IRQs wrong, the kernel will still have incorrect info about the IRQs. This file should run early at boot-time before any process uses the serial port. In fact, your distribution may have set things up so that the `setserial` program runs automatically from a start-up script at boot-time. More info about how to handle this situation for your particular distribution might be found in file named "setserial..." or the like located in directory `/usr/doc/` or `/usr/share/doc/`.

Before modifying a configuration file, you can test out a "proposed" `setserial` command by just typing it on the command line. In some cases the results of this use of `setserial` will automatically get saved in `/etc/serial.conf` when you shutdown. So if it worked OK (and solved your problem) then there's no need to modify any configuration file. See [New configuration method using /etc/serial.conf](#).

Configuration Scripts/Files

Your objective is to modify (or create) a script file in the `/etc` tree that runs `setserial` at boot-time. Most distributions provide such a file (but it may not initially reside in the `/etc` tree). In addition, `setserial 2.15` and higher often have an `/etc/serial.conf` file that is used by the above script so that you don't need to directly edit the script that runs `setserial`. In addition just using `setserial` on the command line (2.15+) may ultimately alter this configuration file.

So prior to version 2.15 all you do is edit a script. After 2.15 you may need to either do one of three things: 1. edit a script. 2. edit `/etc/serial.conf` or 3. run "setserial" on the command line which may result in `/etc/serial.conf` automatically being edited. Which one of these you need to do depends on both your particular distribution, and how you have set it up.

Edit a script (required prior to version 2.15)

Prior to `setserial 2.15` (1999) there was no `/etc/serial.conf` file to configure `setserial`. Thus you need to find the file that runs "setserial" at boot time and edit it. If it doesn't exist, you need to create one (or place the commands in a file that runs early at boot-time). If such a file is currently being used it's likely somewhere in the `/etc` directory-tree. But Redhat <6.0 has supplied it in `/usr/doc/setserial/` but you need to move it to the `/etc` tree before using it. You might use "locate" to try to find such a file. For example, you could type: `locate "*serial*"`.

The script `/etc/rc.d/rc.serial` was commonly used in the past. The Debian distribution used `/etc/rc.boot/0setserial`. Another file once used was `/etc/rc.d/rc.local` but it's not a good idea to use this since it may not be run early enough. It's been reported that other processes may try to open the serial port before `rc.local` runs resulting in serial communication failure. Today it's most likely in `/etc/init.d/` but it isn't normally intended to be edited.

If such a file is supplied, it should contain a number of commented-out examples. By uncommenting some of these and/or modifying them, you should be able to set things up correctly. Make sure that you are using a valid path for `setserial`, and a valid device name. You could do a test by executing this file manually (just type its name as the super-user) to see if it works right. Testing like this is a lot faster than doing repeated

reboots to get it right.

For versions ≥ 2.15 (provided your distribution implemented the change, Redhat didn't) it may be more tricky to do since the file that runs setserial on startup, `/etc/init.d/setserial` or the like was not intended to be edited by the user. See [New configuration method using `/etc/serial.conf`](#).

If you want setserial to automatically determine the uart and the IRQ for ttyS3 you would add something like:

```
/sbin/setserial /dev/ttyS3 auto_irq skip_test autoconfig
```

Do this for every serial port you want to auto configure. Be sure to give a device name that really does exist on your machine. In some cases this will not work right due to the hardware. If you know what the uart and irq actually are, you may want to assign them explicitly with "setserial". For example:

```
/sbin/setserial /dev/ttyS3 irq 5 uart 16550A skip_test
```

New configuration method using `/etc/serial.conf`

Prior to setserial version 2.15, the way to configure setserial was to manually edit the shell-script that ran setserial at boot-time. See [Edit a script \(after version 2.15: perhaps not\)](#). Starting with version 2.15 (1999) of setserial this shell-script is not edited but instead gets its data from a configuration file: `/etc/serial.conf`. Furthermore you may not even need to edit `serial.conf` because using the "setserial" command on the command line may automatically cause `serial.conf` to be edited appropriately.

This was intended so that you don't need to edit any file in order to set up (or change) what setserial does each time that Linux is booted. But there are serious pitfalls because it's not really "setserial" that edits `serial.conf`. Confusion is compounded because different distributions handle this differently. In addition, you may modify it so that it works differently.

What often happens is this: When you shut down your PC the script that runs "setserial" at boot-time is run again, but this time it only does what the part for the "stop" case says to do: It uses "setserial" to find out what the current state of "setserial" is, and it puts that info into the `serial.conf` file. Thus when you run "setserial" to change the `serial.conf` file, it doesn't get changed immediately but only when and if you shut down normally.

Now you can perhaps guess what problems might occur. Suppose you don't shut down normally (someone turns the power off, etc.) and the changes don't get saved. Suppose you experiment with "setserial" and forget to run it a final time to restore the original state (or make a mistake in restoring the original state). Then your "experimental" settings are saved.

If you manually edit `serial.conf`, then your editing is destroyed when you shut down because it gets changed back to the state of setserial at shutdown. There is a way to disable the changing of `serial.conf` at shutdown and that is to remove "###AUTOSAVE###" or the like from first line of `serial.conf`. In at least one distribution, the removal of "###AUTOSAVE###" from the first line is automatically done after the first time you shutdown just after installation. The `serial.conf` file should contain some comments to explain this.

The file most commonly used to run setserial at boot-time (in conformance with the configuration file) is now `/etc/init.d/setserial` (Debian) or `/etc/init.d/serial` (Redhat), or etc., but it should not normally be edited. For 2.15, Redhat 6.0 just had a file `/usr/doc/setserial-2.15/rc.serial` which you have to move to `/etc/init.d/` if you want setserial to run at boot-time.

Modem-HOWTO

To disable a port, use `setserial` to set it to "uart none". The format of `/etc/serial.conf` appears to be just like that of the parameters placed after "setserial" on the command line with one line for each port. If you don't use autosave, you may edit `/etc/serial.conf` manually.

BUG: As of July 1999 there is a bug/problem since with `###AUTOSAVE###` only the `setserial` parameters displayed by "`setserial -Gg /dev/ttyS*`" get saved but the other parameters don't get saved. Use the `-a` flag to "setserial" to see all parameters. This will only affect a small minority of users since the defaults for the parameters not saved are usually OK for most situations. It's been reported as a bug and may be fixed by now.

In order to force the current settings set by `setserial` to be saved to the configuration file (`serial.conf`) without shutting down, do what normally happens when you shutdown: Run the shell-script `/etc/init.d/{set}serial stop`. The "stop" command will save the current configuration but the serial ports still keep working OK.

In some cases you may wind up with both the old and new configuration methods installed but hopefully only one of them runs at boot-time. Debian labeled obsolete files with "...pre-2.15".

IRQs

By default, both `ttyS0` and `ttyS2` will share IRQ 4, while `ttyS1` and `ttyS3` share IRQ 3. But actually sharing serial interrupts (using them in running programs) is not permitted unless you: 1. have kernel 2.2 or better, and 2. you've compiled in support for this, and 3. your serial hardware supports it. See

[Interrupt sharing and Kernels 2.2+](#) If you only have two serial ports, `ttyS0` and `ttyS1`, you're still OK since IRQ sharing conflicts don't exist for non-existent devices.

If you add an internal modem and retain `ttyS0` and `ttyS1`, then you should attempt to find an unused IRQ and set it both on your serial port (or modem card) and then use `setserial` to assign it to your device driver. If IRQ 5 is not being used for a sound card, this may be one you can use for a modem. To set the IRQ in hardware you may need to use `isapnp`, a PnP BIOS, or patch Linux to make it PnP. To help you determine which spare IRQ's you might have, type "man `setserial`" and search for say: "IRQ 11".

Laptops: PCMCIA

If you have a Laptop, read `PCMCIA-HOWTO` for info on the serial configuration. For serial ports on the motherboard, `setserial` is used just like it is for a desktop. But for PCMCIA cards (such as a modem) it's a different story. The configuring of the PCMCIA system should automatically run `setserial` so you shouldn't need to run it. If you do run it (by a script file or by `/etc/serial.conf`) it might be different and cause trouble. The autosave feature for `serial.conf` shouldn't save anything for PCMCIA cards (but Debian did until 2.15-7). Of course, it's always OK to use `setserial` to find out how the driver is configured for PCMCIA cards.

10.2 What is `isapnp` ?

`isapnp` is a program to configure Plug-and-Play (PnP) devices on the ISA bus including internal modems. It comes in a package called "isapnptools" and includes another program, "pnpdump" which finds all your ISA PnP devices and shows you options for configuring them in a format which may be added to the PnP configuration file: `/etc/isapnp.conf`. It may also be used with the `--dumppregs` option to show the current IO address and IRQ of the modem's serial port. The `isapnp` command may be put into a startup file so that it runs each time you start the computer and thus will configure ISA PnP devices. It is able to do this even if your BIOS doesn't support PnP. See `Plug-and-Play-HOWTO`.

10.3 What is wvdialconf ?

wvdialconf will try to find which serial port (ttyS?) has a modem on it. It also creates a configuration program for the wvdial program. wvdial is used for simplified dialing out using the PPP protocol to an ISP. But you don't need to install PPP in order to use wvdialconf. It will only find modems which are not in use. It will also automatically devise a "suitable" init strings but sometimes gets it wrong. Since this command has no options, it's simple to use but you must give it the name of a file to put the init string (and other data) into. For example type: wvdialconf my_config_file_name.

11. [Trying Out Your Modem \(Dialing Out\)](#)

11.1 Are You Ready to Dial Out ?

Once you've plugged in your modem and know which serial port it's on you're ready to try using it. If you already have an account with an ISP to connect to the Internet, you could try using a program like "wvdial" to connect to the Internet using the PPP protocol.

As an alternative to taking one big step using PPP to connect to the Internet, you could do a two step process: First just test out your modem without using PPP (using Minicom or Kermit). Then if your modem works OK, use "wvdial" or other ppp dialer to connect to the Internet. A different strategy is to first try a ppp dialer and then if that doesn't work out, fallback to Minicom or Kermit to see if your modem works OK. Knowing how to use either Minicom or Kermit is handy for dialing out to some places directly without going thru the Internet. If you are going to use Minicom or Kermit you must find a phone number to dial that will accept phone calls from a computer (without using PPP). Perhaps a local library has such a phone number for its on-line catalog.

Then make sure you are ready to phone. Do you know what serial port (such as ttyS2) your modem is on? You should have found this out when you io-irq configured your serial ports. Have you decided what speed you are going to use for this port? See [Speed Table](#) for a quick selection or [What Speed Should I Use with My Modem](#) for more details. If you have no clue of what speed to set, try setting it a few times faster than the advertised speed of your modem. Also remember that if you see a menu where an option is "hardware flow control" and/or "RTS/CTS" or the like, select it. Is a live telephone cable plugged in to your modem? You may want to connect this cable to a real telephone to make sure that it can produce a dial tone.

Now you need to select a communication (dialing) program to use to dial out. Simple dialing programs include: minicom, seyon (X Window), and kermit. Internet dialing programs (using PPP) include wvdial, kppp (for KDE), gnome-ppp (for gnome). See section [Communications Programs](#) about some communications programs. Three examples are presented next: [Dialing Out with wvdial](#) [Dialing Out with Minicom](#) and [Dialing Out with Kermit](#)

11.2 Dialing Out with wvdial

Wvdial is a program with not only dials out, but starts PPP and logs you in to an ISP where you get to the Internet. Wvdial may be configured during the installation process or by using the program "wvdialconf". See the man pages for both "wvdialconf" and "wvdial". However, before using wvdial you must do two other tasks not covered by the wvdial documentation:

- set up your network on your PC. The old HOWTO, "ISP-Hookup-HOWTO" has some info on how

- to do this but fails to mention wvdial which replaces "chatscripts".
- configure your browser

11.3 Dialing Out with Minicom

Minicom comes with most Linux distributions. To configure it you should be the root user. As root, type "minicom -s" to configure. This will take you directly to the configuration (set-up) menus. This allows you to use the configuration immediately. If you just type "minicom" and then configure, you'll need to leave and restart minicom for the configuration to take effect. Within minicom type ^A to see the bottom status line. This shows to type ^A Z for help (you've already typed the ^A so just type z).

Most of the options don't need to be set for just simply dialing out. To configure you have to supply a few basic items: the name of the serial port your modem is on such as /dev/ttyS2 and the speed such as 115200. These are set at the serial port menu. Go to it and set them. Also (if possible) set hardware flow control (RTS/CTS). Then save them. When typing in the speed, you should also see something like "8N1" which you should leave alone. It means: 8-bit bytes, No parity, 1 stop-bit appended to each byte. If you can't find the speed you want, a lower speed will always work for a test. Exit (hit return) when done and save the configuration as default (df) using the menu. Unless you've used the -s option when you called minicom, you'll need to exit minicom and start it again so it can now find the serial port and initialize the modem.

Now you are ready to dial. But first at the main screen you get after you first type "minicom" make sure there's a modem there by typing AT and then hit the <enter> key. It should display OK. If it doesn't something is wrong and there is no point of trying to dial.

If you got the "OK" go back to help and select the dialing directory. You may edit it and type in a phone number, etc. into the directory and then select "dial" to dial it. Alternatively, you may just dial manually (by selecting "manual" and then type the number at the keyboard). If it doesn't work, carefully note any error messages and try to figure out what went wrong.

11.4 Dialing Out with Kermit

You can find the latest version of kermit at <http://www.columbia.edu/kermit/>. For example, say your modem was on ttyS3, and its speed was 115200 bps. You would do the following:

```
linux# kermit
C-Kermit 6.0.192, 6 Sep 96, for Linux
  Copyright (C) 1985, 1996,
    Trustees of Columbia University in the City of New York.
Default file-transfer mode is BINARY
Type ? or HELP for help.
C-Kermit>set line /dev/ttyS3
C-Kermit>set carrier-watch off
C-Kermit>set speed 115200
/dev/ttyS3, 115200 bps
C-Kermit>c
Connecting to /dev/ttyS3, speed 115200.
The escape character is Ctrl-\ (ASCII 28, FS)
Type the escape character followed by C to get back,
or followed by ? to see other options.
ATE1Q0V1 ; you type this and then the Enter key
OK ; modem should respond with this
```

Modem-HOWTO

If your modem responds to AT commands, you can assume your modem is working correctly on the Linux side. Now try calling another modem by typing:

```
ATDT7654321
```

where 7654321 is a phone number. Use ATDP instead of ATDT if you have a pulse line. If the call goes through, your modem is working.

To get back to the `kermit` prompt, hold down the `Ctrl` key, press the backslash key, then let go of the `Ctrl` key, then press the `C` key:

```
Ctrl-\-C
(Back at linux)
C-Kermit>quit
linux#
```

This was just a test using the primitive "by-hand" dialing method. The normal method is to let `kermit` do the dialing for you with its built-in modem database and automatic dialing features, for example using a US Robotics (USR) modem:

```
linux# kermit
C-Kermit 6.0.192, 6 Sep 1997, for Linux
Copyright (C) 1985, 1996,
  Trustees of Columbia University in the City of New York.
Default file-transfer mode is BINARY
Type ? or HELP for help
C-Kermit>set modem type usr          ; Select modem type
C-Kermit>set line /dev/ttyS3         ; Select communication device
C-Kermit>set speed 115200           ; Set the dialing speed
C-Kermit>dial 7654321               ; Dial
Number: 7654321
Device=/dev/ttyS3, modem=usr, speed=115200
Call completed.<BEEP>
Connecting to /dev/ttyS3, speed 115200
The escape character is Ctrl-\ (ASCII 28, FS).
Type the escape character followed by C to get back,
or followed by ? to see other options.

Welcome to ...

login:
```

12. [Dial-In](#)

12.1 Dial-In Overview

Dial-in is where you set up your PC so that others may dial in to your PC (at your phone number) and use your PC. Unfortunately some use the term "dial-in" when what they actually mean is just the opposite: dial-out. Dial-in works like this. Someone with a modem dials your telephone number. Your modem answers the phone ring and connects. Once the caller is connected the `getty` program is notified and starts the login process for the caller. After the caller has logged in, the caller then may use your PC. It could be almost as if they were sitting at the monitor-console.

The caller may use a script to automatically log in. This script will be of the expect-send type. For example it

Modem-HOWTO

expects "login:" and then (after it detects "login:") will send the users login name. It next expects the password and then sends the password, etc. Then once the user has been automatically logged in, the `/etc/passwd` (password file) might specify that a shell (such as `bash`) will be started for the user. Or it might specify that PPP is to start so that the user may be connected to the Internet. See the PPP-HOWTO for more details. The program that you use at your PC to handle dialin is called `getty` or `mgetty`. See [Getty](#)

An advanced `getty` program such as `mgetty` can watch to see if PPP is started by the PC on the other end. If so, the login prompt would be skipped, a PPP connection would be made, and login would take place automatically over the PPP connection.

12.2 What Happens when Someone Dials In ?

Here's a more detailed description of dialin. This all assumes that you are using either `mgetty` or `ugetty`. `Agetty` is inferior and doesn't work exactly as described below (see [About agetty](#))

For dialin to work, the modem must be listening for a ring and `getty` must be running and ready to respond to the call. Your modem is normally listening for incoming calls, but what it does when it gets a ring depends on how it's configured. The modem can either automatically answer the phone or not directly answer it. In the latter case the modem sends a "RING" message to `getty` and then `getty` tells the modem to answer the ring. In either case, it may be set up to answer on say the 4th ring. This means that if the call is not for the modem, one must walk/run to the phone and pick it up manually before the 4th ring. Then they can talk to the other person. If they get to the phone too late they will hear the screeching noise of the modem which has answered the call.

Once the modem answers the call it sends tones to the other modem (and conversely). The two modems negotiate how they will communicate and when this is completed your modem sends a "CONNECT" message (or the like) to `getty`. When `getty` gets this message, it sends a login prompt out the serial port. Once a user name is given to this prompt `getty` may just call on a program named `login` to handle the logging in from there on. While `getty` usually starts running at boot-time it should wait until a connection is made before sending out a "login" prompt.

Now for more details on the two methods of answering the call. For the first method where the modem automatically answers the call, the number of times it will ring before answering is controlled by the S0 register of the modem. If S0 is set to 3, the modem will automatically answer on the 3rd ring. If it's set to 0 then the modem will only answer the call if `getty` sends it an "A" (= Answer) AT command to the modem while the phone is ringing. (Actually an "ATA" is sent since all modem commands are prefixed by "AT".) This is known as "manual" answering since the modem itself doesn't do it automatically (but `getty` does). You might think it best to utilize the ability of the modem hardware to automatically answer the call, but it's actually better if `getty` answers it "manually".

For the "manual" answer case, `getty` opens the port at boot-time and listens. When the phone rings, a "RING" message is sent to the listening `getty`. Then if `getty` wants to answer this ring, it sends the modem an "A" command. Note that `getty` may be set to answer only after say 4 "RING" messages (the 4th ring) similar to the automatic answer method. The modem then makes a connection and sends a "CONNECT ..." message to `getty` which then sends a login prompt to the caller. It's not all quite this simple as are some special tricks used to allow dial-out when waiting for a call. See [Dialing Out while Waiting for an Incoming Call](#)

The automatic answer case uses the CD (Carrier Detect aka DCD) wire from the modem to the serial port to tell when a connection is made. It works like this. At boot-time `getty` tries to open the serial port but the attempt fails since the modem has negated CD (the modem is idle). Then the `getty` program waits at the

open statement in the program until a CD signal is asserted. When a CD signal arrives (perhaps hours later) then the port is opened and `getty` sends the login prompt. While `getty` is waiting (sleeping) at the open statement, other processes can run so it doesn't degrade computer performance. What actually wakes `getty` up is an interrupt which is issued when the CD line from the modem changes its state to on.

You may wonder how `getty` is able to open the serial port in the "manual"-answer case since CD may be negated. Well, there's a way to write a program to force the port to open even if there is no CD signal asserted.

12.3 56k Doesn't Work for Dialin

If you expect that people will be able to dial-in to you at 56k, it can't be done unless you have all the following:

1. You have a digital connection to the telephone company such as a trunkside-T1 or ISDN line
2. You use special digital modems (see [Digital Modems](#))
3. You have a "... concentrator", or the like to interface your digital-modems to the digital lines of the telephone company.

A "... concentrator" may be called a "modem concentrator" or a "remote access concentrator" or it could be included in a "remote access server" (RAS) which includes the digital modems, etc. This type of setup is used by ISPs (Internet Service Providers).

12.4 Getty

Introduction to Getty

`getty` is the program you run for dialin. You don't need it for dialout. In addition to presenting a login prompt, it also may help answer the telephone. Originally `getty` was used for logging in to a computer from a dumb terminal. A major use of it today is for logging in to a Linux console. There are several different `getty` programs but a few of these work OK with modems for dialin. The `getty` program is usually started at boot-time. It must be called from the `/etc/inittab` file. In this file you may find some examples which you will likely need to edit a bit. Hopefully these examples will be for the flavor of `getty` installed on your PC.

There are four different `getty` programs to choose from that may be used with modems for dial-in: `mgetty`, `ugetty`, `getty_em`, and `agetty`. A brief overview is given in the following subsections. `agetty` is the weakest of the four and it's mainly for use with directly connected text-terminals. `mgetty` has support for fax and voice mail but `Uugetty` doesn't. `mgetty` allegedly lacks a few of the features of `ugetty`. `getty_em` is a simplified version of `ugetty`. Thus `mgetty` is likely your best choice unless you are already familiar with `ugetty` (or find it difficult to get `mgetty`). The syntax for these `getty` programs differs, so be sure to check that you are using the correct syntax in `/etc/inittab` for whichever `getty` you use.

In order to see what documentation exists about the various gettys on your computer, use the "locate" command. Type: `locate "*getty*"` (including the quotes may help). Note that many distributions just call the program `getty` even though it may actually be `agetty`, `ugetty`, etc. But if you read the man page (type: `man getty`), it might disclose which `getty` it is. This should be the `getty` program with path `/sbin/getty`.

Getty "exits" after login (and can respawn)

After you log in you will notice (by using "top", "ps -ax", or "ptree") that the getty process is no longer running. What happened to it? Why does getty restart again if your shell is killed? Here's why.

After you type in your user name, getty takes it and calls the login program telling it your user name. The getty process is replaced by the login process. The login process asks for your password, checks it and starts whatever process is specified in your password file. This process is often the bash shell. If so, bash starts and replaces the login process. Note that one process replaces another and that the bash shell process originally started as the getty process. The implications of this will be explained below.

Now in the /etc/inittab file getty is supposed to respawn (restart) if killed. It says so on the line that calls getty. But if the bash shell (or the login process) is killed, getty respawns (restarts). Why? Well, both the login process and bash are replacements for getty and inherit the signal connections established by their predecessors. In fact if you observe the details you will notice that the replacement process will have the same process ID as the original process. Thus bash is sort of getty in disguise with the same process ID number. If bash is killed it is just like getty was killed (even though getty isn't running anymore). This results in getty respawning.

When one logs out, all the processes on that serial port are killed including the bash shell. This may also happen (if enabled) if a hangup signal is sent to the serial port by a drop of DCD voltage by the modem. Either the logout or drop in DCD will result in getty respawning. One may force getty to respawn by manually killing bash (or login) either by hitting the k key, etc. while in "top" or with the "kill" command. You will likely need to kill it with signal 9 (which can't be ignored).

About mgetty

mgetty was written as a replacement for ugetty which was in existence long before mgetty. Both are for use with modems but mgetty is best (unless you already are committed to ugetty). mgetty may be also used for directly connected terminals. In addition to allowing dialup logins, mgetty also provides FAX support and auto PPP detection. It permits dialing out when mgetty is waiting for an incoming phone call. There is a supplemental program called vgetty which handles voicemail for some modems. mgetty documentation is fair (except for voice mail), and is not supplemented in this HOWTO. To automatically start PPP one must edit /etc/mgetty/login.conf to enable "AutoPPP" You can find the latest information on mgetty at <http://www.leo.org/~doering/mgetty/> and <http://alpha.greenie.net/mgetty/>

About ugetty

getty_ps contains two programs: getty is used for console and terminal devices, and ugetty for modems. Greg Hankins (former author of Serial-HOWTO) used ugetty so his writings about it are included here. See [Ugetty](#).

About getty_em

This is a simplified version of ``ugetty''. It was written by Vern Hoxie after he became fully confused with complex support files needed for getty_ps and ugetty.

It is part of the collection of serial port utilities and information by Vern Hoxie available via ftp from scicom.alphacdc.com/pub/linux. The name of the collection is ``serial_suite.tgz''.

About agetty

This subsection is long since the author tried using `agetty` for dialin. `agetty` is seemingly simple since there are no initialization files. But when I tried it, it opened the serial port even when there was no CD signal present. It then sent both a login prompt and the `/etc/issue` file to the modem in the AT-command state before a connection was made. The modem thinks all this an AT command and if it does contain any "at" strings (by accident) it is likely to adversely modify your modem profile. Echo wars can start where `agetty` and the modem send the same string back and forth over and over. You may see a "respawning too rapidly" error message if this happens. To prevent this you need to disable all echoing and result codes from the modem (E0 and Q1). Also use the `-i` option with `agetty` to prevent any `/etc/issue` file from being sent.

If you start `agetty` on the modem port and a few seconds later find that you have the login process running on that port instead of `agetty`, it means that a bogus user name has been sent to `agetty` from the modem. To keep this from happening, I had to save my dial-in profile in the modem so that it become effective at power-on. The other saved profile is for dial-out. Then any dial-out programs which use the modem must use a Z, Z0, or Z1 in their init string to initialize the modem for dial-out (by loading the saved dial-out profile). If the 1-profile is for dial-in you use Z1 to load it, etc. If you want to listen for dial-in later on, then the modem needs to be reset to the dial-in profile. Not all dial-out programs can do this reset upon exit from them.

Thus while `agetty` may work OK if you set up a dial-in profile correctly in the modem hardware, it's probably best suited for virtual consoles or terminals rather than modems. If `agetty` is running for dialin, there's no easy way to dial out. When someone first dials in to `agetty`, they should hit the return key to get the login prompt. `agetty` in the Debian distribution is just named `getty`.

About mingetty, and fbgetty

`mingetty` is a small `getty` that will work only for monitors (the usual console) so you can't use it with modems for dialin. `fbgetty` is as above but supports framebuffer.

12.5 Why "Manual" Answer is Best

The difference between the two ways of answering is exhibited when the computer happens to be down but the modem is still working. For the manual case, the "RING" message is sent to `getty` but since the computer is down, `getty` isn't there and the phone never gets answered. There are no telephone charges when there is no answer. For the automatic answer case, the modem (which is still on) answers the phone but no login message is ever sent since the computer is down. The phone bill runs up as the waiting continues. If the phone call is toll-free, it doesn't make much difference, although it may be frustrating waiting for a login prompt that never arrives. `mgetty` uses manual answer. `Uugetty` can do this too using a configuration script.

12.6 Dialing Out while Waiting for an Incoming Call

Here's what could go wrong with a simple-minded manual-answer situation. Suppose another process dials out while `getty` is listening for a "RING" message from its modem on the serial wire. Then incoming bytes for the dial-out process flow from the modem to the serial port. For example, your modem may send a "CONNECT" message to your serial port when the dial-out process connects. If `getty` reads this there's trouble since reads are destructive reads. Once `getty` reads it, then the dial-out process that is expecting "CONNECT" (or something else) can't read it. Thus the dial-out process is likely to fail.

There's a way to avoid this and here's how mgetty does it. When mgetty is listening for an incoming call, it doesn't read anything from the port until it thinks that the characters are for mgetty. Mgetty monitors the port and if characters arrive, it doesn't read them right away. Instead, it first checks to see if another process is using the port. If so, mgetty backs off and closes the port (but the port remains open for the other process). Thus if another process dials out, mgetty doesn't interfere with it. When the other process finally closes the port, then mgetty resumes "listening". It's a special type of "listening" that refrains from reading until mgetty believes that what it will read is for mgetty (hopefully a "RING" message).

When mgetty checks to see if another process is using the port, it actually checks for valid lockfiles on the port. If the other process failed to use lockfiles, too bad for it. For more details see the mgetty documentation: "How mgetty works". For programmers only: "listening" is actually using the system calls "poll" or "select" to monitor the port. They are likely also used to monitor the port when a non-mgetty process is using the port.

With auto-answer, getty is waiting for CD to be asserted so that it can open the port. One may dial out, but once a connection is made the modem's CD is asserted. If getty were to then read the port it would eat the characters intended to be read by the dial-out connection. While agetty will have this problem, it's claimed that ugetty will check lockfiles before reading (similar to mgetty).

12.7 Ending a Dial-in Call

There are two major ways to end a dial-in call. The caller may either logout or just hang up. For the hangup case see [Caller hangs up](#)

Caller logs out

When the call is over the normal way to end the connection is for the user to log out. This will kill the remote user's shell on your PC. Now since there is nothing running on this port, the port is closed and sends a hangup signal to the modem by negating DTR. This will only happen if stty -a shows hupcl (hang up on close) but this should be the default.

The modem getting this hangup (negated DTR signal) will then hang up the phone line (provided the modem has been configured to do this —see below). The modem should then be ready to answer any new incoming calls. Killing the user's shell also causes getty to respawn and wait for the next call.

As an alternative to using DTR to tell the modem to hang up the phone line, a script used after getty respawns may send the unique escape code sequence +++ to the modem to put it into AT command mode. The +++ must have both an initial and final time delay. Once in AT command mode, a hangup command (H0) may be sent to the modem as well as other AT commands. If the PC fails to successfully signal the modem when a logout happens (or to use the +++ escape when restarting getty), then the modem is apt to remain in on-line mode and no more incoming calls can be received.

When DTR drops (is negated)

When DTR (the "hang-up" signal) is negated, what the modem does depends on the value of the &D option in the modem's profile. If it's &D0 nothing at all happens (the modem ignores the negation of DTR). Here's what happens when DTR drops:

&D2: The modem will hang up and go into AT command mode (off-line) to wait for the next call. Except that it will not be able to automatically answer the phone until DTR is asserted again. But since getty automatically respawns (if so set in /etc/inittab) then getty will immediately restart after a logout and this will

assert DTR. So what happens when someone logs out is that DTR only is negated for a fraction of a second (winks) before it gets asserted again. For the above to happen, the DTR must be negated for at least the time specified by register S25.

&D3 : In this case the modem does a hard reset: It hangs up and restores the saved profile as specified by &Y. It should now be in the same state it was in when first powered on and it's ready for incoming calls. The S25 limit may have no effect so even a very short "wink" is detected. Another brand of modem says the S25 limit is still valid. Thus &D3 is a stronger "reset" than &D2 which doesn't restore the saved profile and could require a longer wink to work.

If you don't know which of the above two to use try using &D3 first. Under favorable conditions, either one should work OK. It's reported that for a few modems only &D2 works OK.

Caller hangs up

Instead of logging out the normal way, a caller may just hang up. This results in a lost connection and of course a loss of carrier. Other problems could also cause a loss of carrier. The "NO CARRIER" result code is displayed. The modem hangs up and waits for the next call. Except that there is no getty running yet to start the login process.

Here's how getty gets started again: The loss of carrier should negate the CD signal sent by the modem to the serial port (provided &C1 has been set). When the PC's serial port gets the negated CD signal it should kill the shell and then getty should respawn.

This paragraph is about other things that happen but do nothing. Only the curious need read it. When the shell is killed, a DTR wink is sent to the modem but since the modem is not on-line anymore and has already hung up, the modem ignores the negation of DTR (hang up). The loss of carrier also negates the DSR signal sent by the modem to the serial port (provided &S1 or &S2 is set) but this signal is ignored (by Linux).

12.8 Dial-in Modem Configuration

The getty programs have a provision for sending an init string to the modem to configure it. But you may need to edit it. Another method is to save a suitable init string inside the modem (see [Init Strings: Saving and Recalling](#) for how to save it in the modem).

The configuration for dial-in depends both on the getty you use and perhaps on your modem. If you can't find suggested configurations in other documentation here are some hints using Hayes AT commands:

- &C1 Make the CD line to the serial port track the actual state of the carrier (CD asserted only when there's carrier). Getty_em requires &C0 (CD always asserted)
- &D3 Do a hard reset of the modem when someone logs out (or hangs up). For some modems it's reported that &D2 is required since they can't tolerate a hard reset ??
- E0 Don't echo AT commands back to the serial port. This is a must for agetty. Some suggest E1 (echo AT commands) for mgetty. For dial-out you want E1 so you can see what was sent.
- &K3 Use hardware flow control
- Q0 Echo results words (such as CONNECT). Most gettys use them. But it's reported an AT&T version of ugetty and agetty require Q2 (no result words for dial-in).
- S0=? mgetty suggests S0=0 (manual answer). If you set S0=3 the modem will auto-answer on the 3rd ring, etc. Agetty uses auto-answer. So does ugetty (usually).
- V1 Display results (such as CONNECT) in words (and not in code)

- X4 Check for dialtone and busy signal

12.9 Callback

Callback is where someone first dials in to your modem. Then, you get a little info from the caller and then call it right back. Why would you want to do this? One reason is to save on telephone bills if you can call the caller cheaper than the caller can call you. Another is to make sure that the caller really is who it claims to be. If a caller calls you and claims to be calling from its usual phone number, then one way to verify this is to actually place a new call to that number.

There's a program for Linux called "callback" that works with `mgetty`. It's at <ftp://ftp.rug.nl/contrib/frank/software/linux/callback/> Step-by-step instructions on how someone installed it (and PPP) is at <http://www.stokely.com/unix.serial.port.resources/callback.html>

12.10 Voice Mail

Voice mail is like an answering machine run by a computer. To do this you must have a modem that supports "voice" and supporting software. Instead of storing the messages on tape, they are stored in digital format on a disk. When a person phones you, they hear a "greeting" message and can then leave a message for you. More advanced systems would have caller-selectable mail boxes and caller-selectable messages to listen to. Free software is available in Linux for simple answering, but doesn't seem to be available yet for the more advanced stuff.

I know of two different voicemail packages for Linux. One is a very minimal package (see [Voicemail Software](#)). The other, more advanced, but currently poorly documented, is `vgetty`. It's an optional addition to the well documented and widely distributed `mgetty` program. It supports ZyXEL-like voice modem commands. In the Debian distribution, you must get the `mgetty-voice` package in addition to the `mgetty` package and `mgetty-doc` package. Obsolete documentation has been removed from `mgetty` but replacement documentation is lacking (except if you use the `-h` (help) option when running certain programs, etc.). But one sees postings about using it on the `mgetty` newsgroup. See [About mgetty](#). It seems that `vgetty` is currently not very stable but it's successfully being used and development of it continues. If this is the latest version of this HOWTO can someone who is familiar with `vgetty` please let me know its current status.

12.11 Simple Manual Dial-In

This is really doing it manually! There's a way to answer a call without bothering to edit any configuration files for dial-in or enabling `getty` but the caller can't login. To do this you run a terminal program such as `minicom`. Make sure it's connected to your modem by typing "AT <enter>" and expect "OK". Then wait for the call. Then you really answer the call manually by typing "ATA" when the phone is ringing. This doesn't run `getty` and the caller can't login. But if the caller is calling in with a terminal program they may type a message to your screen (and conversely). You both may send files back and forth by using the commands built into the terminal programs (such as `minicom`s). Another way to answer such a call would be to type say "ATS0=3" just before the call comes in to enable the modem to auto-answer on the third ring.

This is one way to crudely transfer files with someone on a MS Windows PC who uses HyperTerminal or Terminal (for Windows 3.x or DOS). These two MS programs are something like `minicom`. Using this simple manual method (for Linux-to-Linux or MS-to-Linux) requires two people to be present, one one each end of the phone line connection running a terminal communications program. Be warned that if both people type at the same time it's chaos. It's a "last resort" way to transfer files between any two people that have PCs

(either Linux or MS Windows). It could also be used for testing your modem or as a preliminary test before setting up dial-in.

12.12 Complex GUI Dial-In, VNC

At the opposite extreme to the simple (but labor intensive) manual dial-in is one that results in GUI graphical interface to the Linux PC. This generally requires that a network running TCP/IP protocol exist between the two computers. One way to get such a "network" is to dial-out to a PC set for dial-in and then run PPP on the phone line. PPP will use TCP/IP protocol encapsulated inside the PPP packets. Both sides must run PPP and mgetty can be configured to start PPP as soon as the caller does. The caller may use a PPP-dialer program just like they were dialing an ISP. Programs such as wvdial, eznet, or chat scripts should do it.

Instead of this tiny network over a phone connection a much larger network (the entire world) is reached via an ISP. For their lowest-rate service many of them use proxy servers that will not give you access to the ports you need to use. Even if they don't use proxy servers, the IP address they give you is only temporary for the session, so you'll need to email this IP to whomever wants to reach you. If you get a more expensive ISP service, then you can avoid these problems.

One way to get a GUI interface from the remote PC is to run the GPLed program: Virtual Network Computer (VNC) from AT&T. It has a server part which you run on your Linux PC for dial-in and a viewer (client) part used for dial-out. Neither of these actually does any dialing or login but assumes that you have a network already set up. The VNC server has an X-server built in and may use Linux's twm window manager. See the article on VNC in Linux Magazine: http://www.linux-mag.com/2000-11/desktop_03.html. The AT&T site for VNC is: <http://www.uk.research.att.com/vnc/>.

With VNC one can also connect to remote Windows PCs, get the Windows GUI on a Linux PC, and run Windows programs on the remote Windows PC. Of course the Windows PC must be running VNC (as a server). Obviously, a GUI connection over a modem will be slower than a text-only connection especially if you run KDE or GNOME or want 16-bit color.

12.13 Interoperability with MS Windows

Once you have dial-in set up, others may call in to you using minicom (or the like) from Unix-like systems. From MS Windows one may call you using "HyperTerminal (or just "Terminal" in Windows 3.1 or DOS).

If in Windows one wants to use dial-up with a network protocol over the phone line it's called "Dial-up Networking". But it probably will not be able to communicate with Linux. For setting up such dial-in in Windows one clicks on "server" while dial-out is the "client. Such dial-in is often called "remote control" meaning that the caller can use your PC, run programs on it, and thus control it remotely.

While it's easy to call in to a text-based Linux system from MS Windows, it's not so easy the other way around (partly because Windows is not text-based and would need to put the caller into DOS where files wouldn't be protected like they are in Linux.

However Windows "Dial-up Networking" can establish a dial-in provided the caller uses certain network protocols over the phone line: MS's or Novel's (two protocols not liked by Linux). So if someone with Windows enables their Dial-up networking server in Windows 98, you can't just dial in directly to it from Linux. This type of dial-in doesn't permit the caller to run most of the programs on the host like Linux does. It's called "remote access" and one may transfer files, use the hosts printer, access databases, etc. Is there some way to interface to Dial-up Networking from Linux??

It is possible for two people to crudely chat and send files using Minicom on the Linux end and HyperTerminal on the Windows end. It's all done manually by two live persons, one on each end of the phone connection. See [Simple Manual Dial-In](#).

At the opposite extreme, one would like to run a dial-in so that the person calling would get a GUI interface. For that a network protocol is normally used. It's possible using PC Anywhere for Windows or VNC for both Linux and Windows. But PC Anywhere doesn't seem to talk to Linux ?? Other Window programs for "remote control" include Laplink, Co-Session, and Microcom. Do any such programs support Linux besides VNC ??

13. [Uugetty for Dial-In \(from the old Serial-HOWTO\)](#)

Be aware that you could use mgetty as a (better?) alternative to uugetty. mgetty is newer and more popular than uugetty. See [Getty](#) for a brief comparison of these 2 gettys.

13.1 Installing getty_ps

Since uugetty is part of getty_ps you'll first have to install getty_ps. If you don't have it, get the latest version from metalab.unc.edu:/pub/Linux/system/serial. In particular, if you want to use high speeds (57600 and 115200 bps), you must get version 2.0.7j or later. You must also have libc 5.x or greater.

By default, getty_ps will be configured to be Linux FSSTND (File System Standard) compliant, which means that the binaries will be in /sbin, and the config files will be named /etc/conf.{uu}getty.ttySN. This is not apparent from the documentation! It will also expect lock files to go in /var/lock. Make sure you have the /var/lock directory.

If you don't want FSSTND compliance, binaries will go in /etc, config files will go in /etc/default/{uu}getty.ttySN, and lock files will go in /usr/spool/uucp. I recommend doing things this way if you are using UUCP, because UUCP will have problems if you move the lock files to where it isn't looking for them.

getty_ps can also use syslogd to log messages. See the man pages for syslogd(1) and syslog.conf(5) for setting up syslogd, if you don't have it running already. Messages are logged with priority LOG_AUTH, errors use LOG_ERR, and debugging uses LOG_DEBUG. If you don't want to use syslogd you can edit tune.h in the getty_ps source files to use a log file for messages instead, namely /var/adm/getty.log by default.

Decide on if you want FSSTND compliance and syslog capability. You can also choose a combination of the two. Edit the Makefile, tune.h and config.h to reflect your decisions. Then compile and install according to the instructions included with the package.

13.2 Setting up uugetty

With uugetty you may dial out with your modem while uugetty is watching the port for logins. uugetty does important lock file checking. Update /etc/gettydefs to include an entry for your modem. For help with the meaning of the entries that you put into /etc/gettydefs, see the "serial_suite" collected by Vern Hoxie. How to get it is in section See [About getty em](#). When you are done editing /etc/gettydefs, you can verify that the syntax is correct by doing:

```
linux# getty -c /etc/gettydefs
```

Modern Modems

If you have a 9600 bps or faster modem with data compression, you can lock your serial port to one speed. For example:

```
# 115200 fixed speed
F115200# B115200 CS8 # B115200 SANE -ISTRIP HUPCL #@S @L @B login: #F115200
```

If you have your modem set up to do RTS/CTS hardware flow control, you can add CRTSCTS to the entries:

```
# 115200 fixed speed with hardware flow control
F115200# B115200 CS8 CRTSCTS # B115200 SANE -ISTRIP HUPCL CRTSCTS #@S @L @B login: #F115200
```

Old slow modems

If you have a slow modem (under 9600 bps) Then, instead of one line for a single speed, you need several lines to try a number of speeds. Note that these lines are linked to each other by the last "word" in the line such as #4800. Blank lines are needed between each entry. Are the higher modem-to-serial_port speeds in this example really needed for a slow modem ?? The uugetty documentation shows them so I'm not yet deleting them.

```
# Modem entries
115200# B115200 CS8 # B115200 SANE -ISTRIP HUPCL #@S @L @B login: #57600

57600# B57600 CS8 # B57600 SANE -ISTRIP HUPCL #@S @L @B login: #38400

38400# B38400 CS8 # B38400 SANE -ISTRIP HUPCL #@S @L @B login: #19200

19200# B19200 CS8 # B19200 SANE -ISTRIP HUPCL #@S @L @B login: #9600

9600# B9600 CS8 # B9600 SANE -ISTRIP HUPCL #@S @L @B login: #4800

4800# B4800 CS8 # B4800 SANE -ISTRIP HUPCL #@S @L @B login: #2400

2400# B2400 CS8 # B2400 SANE -ISTRIP HUPCL #@S @L @B login: #1200

1200# B1200 CS8 # B1200 SANE -ISTRIP HUPCL #@S @L @B login: #115200
```

Login Banner

If you want, you can make uugetty print interesting things in the login banner. In Greg's examples, he has the system name, the serial line, and the current bps rate. You can add other things:

```
@B    The current (evaluated at the time the @B is seen) bps rate.
@D    The current date, in MM/DD/YY.
@L    The serial line to which uugetty is attached.
@S    The system name.
@T    The current time, in HH:MM:SS (24-hour).
@U    The number of currently signed-on users. This is a
      count of the number of entries in the /etc/utmp file
      that have a non-null ut_name field.
@V    The value of VERSION, as given in the defaults file.
To display a single '@' character, use either '\@' or '@@'.
```

13.3 Customizing uugetty

There are lots of parameters you can tweak for each port you have. These are implemented in separate config files for each port. The file `/etc/conf.uugetty` will be used by *all* instances of `uugetty`, and `/etc/conf.uugetty.ttySN` will only be used by that one port. Sample default config files can be found with the `getty_ps` source files, which come with most Linux distributions. Due to space concerns, they are not listed here. Note that if you are using older versions of `uugetty` (older than 2.0.7e), or aren't using `FSSTND`, then the default file will be `/etc/default/uugetty.ttySN`. Greg's `/etc/conf.uugetty.ttyS3` looked like this:

```
# sample uugetty configuration file for a Hayes compatible modem to allow
# incoming modem connections
#
# line to initialize
INITLINE=ttyS3
# timeout to disconnect if idle...
TIMEOUT=60
# modem initialization string...
# format: <expect> <send> ... (chat sequence)
INIT="" AT\r OK\r\n
WAITFOR=RING
CONNECT="" ATA\r CONNECT\s\A
# this line sets the time to delay before sending the login banner
DELAY=1
#DEBUG=010
```

Add the following line to your `/etc/inittab`, so that `uugetty` is run on your serial port, substituting in the correct information for your environment – run-levels (2345 or 345, etc.) config file location, port, speed, and default terminal type:

```
S3:2345:respawn:/sbin/uugetty -d /etc/default/uugetty.ttyS3 ttyS3 F115200 vt100
```

Restart `init`:

```
linux# init q
```

For the speed parameter in your `/etc/inittab`, you want to use the highest bps rate that your modem supports.

Now Linux will be watching your serial port for connections. Dial in from another machine and login to you Linux system.

`uugetty` has a lot more options, see the man page for `uugetty` (often just called `getty`) for a full description. Among other things there is a scheduling feature, and a ringback feature.

14. [What Speed Should I Use with My Modem?](#)

By "speed" we really mean the "data flow rate" but almost everybody incorrectly calls it speed. For all modern modems you have no choice of the speed that the modem uses on the telephone line since it will automatically choose the highest possible speed that is feasible under the circumstances. If one modem is slower than the other, then the faster modem will operate at the slower modem's speed. On a noisy line, the speed will drop still lower.

While the above speeds are selected automatically by the modems you do have a choice as to what speed will be used between your modem and your computer (PC-to-modem speed). This is sometimes called "DTE speed" where "DTE" stands for Data Terminal Equipment (Your computer is a DTE.) You need to set this speed high enough so this part of the signal path will not be a bottleneck. The setting for the DTE speed is the maximum speed of this link. Most of the time it should actually operate at lower speeds.

For an external modem, DTE speed is the speed (in bits/sec) of the flow over the cable between you modem and PC. For an internal modem, it's the same idea since the modem also emulates a serial port. It may seem ridiculous having a speed limit on communication between a computer and a modem card that is directly connected inside the computer to a much higher speed bus. But it's that way since the modem card probably includes a dedicated serial port which does have speed limits (and settable speeds).

14.1 Speed and Data Compression

What speed do you choose? If it were not for "data compression" one might try to choose a DTE speed exactly the same as the modem speed. Data compression takes the bytes sent to the modem from your computer and encodes them into a fewer number of bytes. For example, if the flow (speed) from the PC to the modem was 20,000 bytes/sec (bps) and the compression ratio was 2 to 1, then only 10,000 bytes/sec would flow over the telephone line. Thus for a 2:1 compression ratio you need to set the DTE speed to double the maximum modem speed on the phone line. If the compression ratio were 3 to 1 you need to set it 3 times faster, etc.

14.2 Where do I Set Speed ?

This DTE (PC-to-modem) speed is normally set by a menu in your communications program or by an option given to the getty command if someone is dialing in. You can't set the DCE modem-to-modem speed since this is set automatically by the modem to the highest feasible speed after negotiation with the other modem. Well, actually you can set the modem-to-modem speed with the S37 register but you shouldn't do it. If the two modems on a connection were to be set this way to different speeds, then they couldn't communicate with each other.

14.3 Can't Set a High Enough Speed

Speeds over 115.2k

The top speed of 115.2k has been standard since the mid 1990's. But by the year 2000, most new serial ports supported higher speeds of 230.4k and 460.8k. Some also support 921.6k. Unfortunately Linux seldom uses these speeds due to lack of drivers. Thus such ports behave just like 115.2k ports unless the higher speeds are enabled by special software. To get these speeds you need to compile the kernel with special patches until support is built into the kernel's serial driver.

Unfortunately serial port manufacturers never got together on a standard way to support high speeds, so the serial driver needs to support a variety of hardware. Once high speed is enabled, a standard way to choose it is to set `baud_base` to the highest speed with `setserial` (unless the serial driver does this for you). The software will then use a divisor of 1 to set the highest speed. All this will hopefully be supported by the Linux kernel sometime in 2002.

A non-standard way to do this is to use a very large number for the divisor which isn't really a divisor at all. It's just a code number to tell the serial driver what speed to use. In such cases you need to compile the kernel

with special patches.

One patch to support this second type of high-speed is called shsmode (Super High Speed Mode). There are both Windows and Linux versions of this patch. See <http://www.devdrv.com/shsmode/>. There is also a module for the VIA VT82C686 chip <http://www.kati.fi/viahss/>. Using it may result in buffer overflow.

For internal modems, only a minority of them advertise that they support speeds of over 115.2k for their built-in serial ports. Does shsmode support these ??

How speed is set in hardware: the divisor and baud_base

Speed is set by having the serial port's clock change frequency. But this change happens not by actually changing the frequency of the oscillator driving the clock but by "dividing" the clock's frequency. For example, to divide by two, just ignore every other clock tick. This cuts the speed in half. Dividing by 3 makes the clock run at 1/3 frequency, etc. So to slow the clock down (meaning set speed), we just send the clock a divisor. It's sent by the serial driver to a register in the port. Thus speed is set by a divisor.

If the clock runs at a top speed of 115,000 bps (common), then here are the divisors for various speeds (assuming a maximum speed of 115,200): 1 (115.2k), 2 (57.6k), 3 (38.4k), 6 (19.2k), 12 (9.6k), 24 (4.8k), 48 (2.4k), 96 (1.2k), etc. The serial driver sets the speed in the hardware by sending the hardware only a "divisor" (a positive integer). This "divisor" divides the "maximum speed" of the hardware resulting in a slower speed (except a divisor of 1 obviously tells the hardware to run at maximum speed).

There are exceptions to the above since for certain serial port hardware, speeds above 115.2k are set by using a very high divisor. Keep that exception in mind as you read the rest of this section. Normally, if you specify a speed of 115.2k (in your communication program or by stty) then the serial driver sets the port hardware to divisor 1 which sets the highest speed.

Besides using a very high divisor to set high speed the conventional way to do it is as follows: If you happen to have hardware with a maximum speed of say 230.4k (and the 230.4k speed has been enabled), then specifying 115.2k will result in divisor 1. For some hardware this will actually give you 230.4k. This is double the speed that you set. In fact, for any speed you set, the actual speed will be double. If you had hardware that could run at 460.8k then the actual speed would be quadruple what you set. All the above assumes that you don't use "setserial" to modify things.

Setting the divisor, speed accounting

To correct this accounting (but not always fix the problem) you may use "setserial" to change the baud_base to the actual maximal speed of your port such as 230.4k. Then if you set the speed (by your application or by stty) to 230.4k, a divisor of 1 will be used and you'll get the same speed as you set.

If you have old software which will not permit such a high speed (but your hardware has it enabled) then you might want to look into using the "spd_cust" parameter for setserial with "divisor 1". Then when you tell the application that the speed is 38,400, it will use divisor 1 and get the highest speed.

There are some brands of UARTs that use a very high divisor to set high speeds. There isn't any satisfactory way to use "setserial" (say set "divisor 32770") to get such a speed since then setserial would then think that the speed is very low and disable the FIFO in the UART.

Crystal frequency is higher than baud_base

Note that the baud_base setting is usually much lower than the frequency of the crystal oscillator since the crystal frequency of say 1.8432 MHz is divided by 16 in the hardware to get the actual top speed of 115.2k. The reason the crystal frequency needs to be higher is so that this high crystal speed can generate clock ticks to take a number of samples of each bit to determine if it's a 1 or a 0.

Actually, the 1.8432 MHz "crystal frequency" is obtained from a 18.432 MHz crystal oscillator by dividing by 10 before being fed to the UART. Other schemes are also possible as long as the UART performs properly.

14.4 Speed Table

It's best to have at least a 16650 UART for a 56k modem but few modems or serial ports provide it. Second best is a 16550 that has been tweaked to give 230,400 bps (230.4 kbps). Most people still use a 16550 that is only 115.2 kbps but it's claimed to only slow down thruput by a few percent (on average). This is because a typical compression ratio is 2 to 1 and for downloading compressed files (packages) it's 1 to 1. There's no degradation for these cases. Here are some suggested speeds to set your serial line if your modem speed is:

- 56k (V.92): use 115.2 kbps or 230.4 kbps (best)
- 56k (V.90): use 115.2 kbps or 230.4 kbps (best)
- 33.6k (V.34bis): use 115.2 kbps
- 28.8k (V.34): use 115.2 kbps
- 14.4k (V.32bis): use 57600 bps
- 9.6k (V.32): use 38400 bps
- slower than a 9600 bps (V.32) modem: Set the speed to the same speed as the modem (unless you have data compression).

All the above speeds may use V.42bis data compression and V.42 error correction. If data compression is not used then the speed may be set lower so long as it's above the modem speed.

15. [Communications Programs And Utilities](#)

While PPP is used for Internet access you also need a dialer program (or script) that will work with PPP. Such a dialer program will dial a phone number. When the other side answers the phone then three things happen: a modem connection is established (CONNECT), PPP is started at both ends, and you get logged in automatically. The exact sequence of the last 2 events may vary. Dialer programs for ppp include wvdial, chap scripts, kppp, RP3, Linuxconf, and gnome-ppp.

There are also other dialer programs which can dial out directly (thru a modem) to local libraries, etc. This isn't the Internet. minicom is the most popular followed by Seyon (X-Windows only) and Kermit. People have likely also used these programs for dialing out with ppp for the Internet but it's not what they were originally designed for.

15.1 Minicom vs. Kermit

Minicom is only a communications program while Kermit is both a communications program and a file transfer protocol. But one may use the Kermit protocol from within Minicom (provided one has Kermit installed on one's PC). Minicom is menu based while Kermit is command line based (interactive at the special Kermit prompt). While the Kermit program is free software, the documentation is not all free. There is no

detailed manual supplied and it is suggested that you purchase a book as the manual. However Kermit has interactive online help which tells all but lacks tutorial explanations for the beginner. Commands may be put in a script file so you don't have to type them over again each time. Kermit (as a communications program) is more powerful than Minicom.

Although all Minicom documentation is free, it's not as extensive as Kermit's. Since permission is required to include Kermit in a commercial distribution, and since the documentation is not entirely free, some distributions don't include Kermit. In my opinion it's easier to set up Minicom, there is less to learn, and you can still use kermit from within Minicom.

15.2 List of Communication Software

Here is a list of some communication software you can choose from, If they didn't come with your distribution they should be available via FTP. I would like comparative comments on the dialout programs. Are the least popular ones obsolete?

Least Popular Dialout

- `ecu` – a communications program
- `pcomm` – `procomm`-like communications program with `zmodem`
- `xc` – `xcomm` communication package

Most Popular Dialout

- PPP dialers for getting on the internet: `wvdial`, `eznet`, `chat`, `pon` (uses `chat`),
- `minicom` – `telix`-like communications program. Can work with scripts, `zmodem`, `kermit`
- [C-Kermit](#) – portable, scriptable, serial and TCP/IP communications including file transfer, character-set translation, and `zmodem` support
- `seyon` – X based communication program

Fax

By using a fax program, you may use most modems to send faxes. In this case you dial out directly and not via `ppp` and an ISP. You also pay any long-distance telephone charges. email is more efficient.

- `efax` is a small fax program
- `hylafax` is a large fax program based on the client-server model.
- `mgetty+fax` handles fax stuff and login for dial-ins
- A fax protocol tutorial <http://www.iec.org/online/tutorials/vfoip/topic08.html>

Voicemail Software

- `vgetty` is an extension to `mgetty` that handles voicemail for some modems. It should come with recent releases of `mgetty`.
- [VOCP](#) is a "complete voice messaging" system for Linux.

Dial-in (uses getty)

- `mgetty+fax` is for modems and is well documented (except for voicemail as of early 1999). It also handles fax stuff and provides an alternative to `uugetty`. It's incorporating voicemail (using `vgetty`) features. See [About mgetty](#)
- `uugetty` is also for modems. It comes as a part of the `ps_getty` package. See [About getty_ps](#)

Other

- `callback` is where you dial out to a remote modem and then that modem hangs up and calls you back (to save on phone bills).
- `SLiRP` and `term` provide a PPP-like service that you can run in user space on a remote computer with a shell account. See [term and SLiRP](#) for more details
- `ZyXEL` is a control program for ZyXEL U-1496 modems. It handles dialin, dialout, dial back security, FAXing, and voice mailbox functions.
- `SLIP` and `PPP` software can be found at <ftp://metalab.unc.edu/pub/Linux/system/network/serial/>.
- Other things can be found on <ftp://metalab.unc.edu/pub/Linux/system/serial> and <ftp://metalab.unc.edu/pub/Linux/apps/serialcomm> or one of the many mirrors. These are the directories where serial programs are kept.

15.3 SLiRP and term

`SLiRP` and `term` are programs which are of use if you only have a dial-up shell account on a Unix-like machine and want to get the equivalent of a PPP account (or the like) without being authorized to have it (possibly because you don't want to pay extra for it, etc.). `SLiRP` is more popular than `term` which is almost obsolete.

To use `SLiRP` you install it in your shell account on the remote computer. Then you dial up the account and run `SLiRP` on the remote and `PPP` on your local PC. You now have a PPP connection over which you may run a web browser on your local PC such as Netscape, etc. There may be some problems as `SLiRP` is not as good as a real PPP account. Some accounts may provide `SLiRP` since it saves on IP addresses (You have no IP address while using `SLiRP`).

`term` is something like `SLiRP` only you need to run `term` on both the local and remote computer. There is no PPP on the phone line since `term` uses its own protocol. To use `term` from your PC you need to use a `term`-aware version of `ftp` to do `ftp`, etc. Thus it's easier to use `SLiRP` since the ordinary version of `ftp` works fine with `SLiRP`. There is an unmaintained Term HOWTO.

15.4 MS Windows

If you want someone who uses MS Windows to dial in to your Linux PC then if they use:

- Windows 3.x: use `Terminal`
- Windows 95/98/2000: use `HyperTerminal`

Third party dial-out programs include `HyperTerminal Private Edition`.

16. [Two Modems \(Modem Doubling\)](#)

16.1 Introduction

By using two modems at the same time, the flow of data can be doubled. It takes two modems and two phone lines. There are two methods of doing this. One is "modem bonding" where software at both ends of the modem-to-modem connection enables the paired modems to work like a single channel.

The second method is called "modem teaming. Only one end of the connection uses software to make 2 different connections to the internet. Then when a file is to be downloaded, one modem gets the first half of the file. The second modems simultaneously gets the last half of the same file by pretending that it's resuming a download that was interrupted in the middle of the file. Is there any modem teaming support in Linux ??

16.2 Modem Bonding

There are two ways to do this in Linux: EQL and multilink. These are provided as part of the Linux kernel (provided they've been selected when the kernel was compiled). For multilink the kernel must be at least v.2.4. Both ends of the connection must run them. Few (if any) ISPs provide EQL but many provide Multilink.

The way it works is something like multiplexing only it's the other way around. Thus it's called inverse-multiplexing. For the multilink case, suppose you're sending some packets. The first packet goes out on modem1 while the second packet is going out on modem2. Then the third packet follows the first packet on modem1. The forth packet goes on modem2, etc. To keep each modem busy, it may be necessary to send out more packets on one modem than the other. Since EQL is not packet based, it doesn't split up the flow on packet boundaries.

EQL

EQL is "serial line load balancing" which has been available for Linux since at least 1995. An old (1995) howto on it is in the kernel documentation (in the networking subdirectory). Unfortunately, ISPs don't seem to provide EQL.

Multilink

Starting with kernel 2.4 in 2000, experimental support is provided for multilink. It must be selected when compiling the kernel and it only works with PPP.

17. [Troubleshooting](#)

17.1 My Modem is Physically There but Can't be Found

An error messages could be something like "No modem detected", "Modem not responding". There could be no error message. If you have installed an internal modem (serial port is builtin) or are using an external one and don't know what serial port it's connected to then the problem is to find the serial port. See [My Serial Port is Physically There but Can't be Found](#). This section is about finding out which serial port has the modem on it.

Modem-HOWTO

There's a program that looks for modems on commonly used serial ports called "wvdialconf". Just type "wvdialconf <a-new-file-name>". It will create the new file as a configuration file but you don't need this file unless you are going to use "wvdial" for dialing. See [What is wvdialconf ?](#) Unfortunately, if your modem is in "online data" mode, wvdialconf will report "No modem detected" See [No response to AT](#)

Your problem could be due to a winmodem (or the like) which usually can't be used with Linux. See [Software-based Modems \(winmodems\)](#). The "setserial program may be used to detect serial ports but will not detect modems on them. Thus "wvdialconf" is best to try first.

Another way try to find out if there's a modem on a port is to start "minicom" on the port (after first setting up minicom for the correct serial port—you will need to save the setup and then exit minicom and start it again). Then type "AT" and you should see "OK" (or 0 if it's set for "digit result codes"). If you don't immediately see "OK" then if:

- No response. See [No response to AT](#)
- It takes many seconds to get an expected truncated response (including only the cursor moving down one line). See [Extremely Slow: Text appears on the screen slowly after long delays](#)
- Some strange characters appear but they are not in response to AT. This likely means that your modem is still connected to something at the other end of the phone line which is sending some cryptic packets or the like.

No response to AT

The modem should send you "OK" in response to your "AT" which you type to the modem (using minicom or the like). If you don't see "OK" (and in most cases don't even see the "AT" you typed either) then the modem is not responding (often because what you type doesn't even get to the modem).

A common cause is that there is no modem on the serial port you are typing to. For the case of an internal modem, that serial port likely doesn't exist either. That's because the PnP modem card (which has a built-in serial port) has either not been configured (by isapnp or the like) or has been configured incorrectly. See [My Serial Port is Physically There but Can't be Found](#).

If what you type is really getting thru to a modem, then the lack of response could be due to the modem being in "online data" mode where it can't accept any AT commands. You may have been using the modem and then abruptly disconnected (such as killing the process with signal 9). In that case your modem did not get reset to "command mode" where it can interact to AT commands. Thus the message from minicom "You are already online. Hangup first." Well, you are sort of online but you are may not be connected to anything over the phone line. Wvdial will report "modem not responding" for the same situation.

To fix this as a last resort you could reboot the computer. Another way to try to fix this is to send +++ to the modem to tell it to escape back to "command mode" from "online data mode". On both sides of the +++ sequence there must be about 1 second of delay (nothing sent during "guard time"). This may not work if another process is using the modem since the +++ sequence could wind up with other characters inserted in between them or after the +++ (during the guard time). Ironically, even if the modem line is idle, typing an unexpected +++ is likely to set off an exchange of control packets (that you never see) that will violate the required guard time so that the +++ doesn't do what you wanted. +++ is usually in the string that is named "hangup string" so if you command minicom (or the like) to hangup it might work. Another way to do this is to just exit minicom and then run minicom again.

17.2 "Modem is busy"

What this means depends on what program sent it. The modem could actually be in use (busy). Another cause reported for the SuSE distribution is that there may be two serial drivers present instead of one. One driver was built into the kernel and the second was a module.

In kppp, this message is sent when an attempt to get/set the serial port "stty" parameters fails. (It's similar to the "Input/output error" one may get when trying to use "stty -F /dev/ttySx"). To get a few of these stty parameters, the true address of the port must be known to the driver. So the driver may have the wrong address. The "setserial" command will display what the driver thinks but it's likely wrong in this case. So what the "modem busy" really means is that the serial port (and the modem) can't be found.

If you have a pci modem, then use one of these commands: `lspci`, or `cat /proc/pci`, or `dmesg` to find the correct address and irq of the modem's serial port. Then check to see if "setserial" shows the same thing. If not, you need to run a script at boot-time which contains a setserial command that will tell the driver the correct address and irq. The reason that the driver has it wrong may be due to failure of the kernel to understand the lspci data correctly. You might notice this in a boot-time message.

17.3 "You are already online! Hang up first." (from minicom)

The modem has its CD signal on. Either you are actually online (a remote modem is sending you a carrier) or your modem has been setup to always send the CD signal. In minicom, type `at&v` to see if `&C` or `&C0` is set. If so, CD will be on even if you are offline and you'll get this error message. The fix is to set `&C1` in the init string or save it in the modem.

17.4 I can't get near 56k on my 56k modem

There must be very low noise on the line for it to work at even close to 56k. Some phone lines are so bad that the speeds obtainable are much slower than 56k (like 28.8k or even slower). Sometimes extension phones connected to the same line can cause problems. To test this you might connect your modem directly at the point where the telephone line enters the building with the feeds for everything else on that line disconnected (if others can tolerate such a test).

17.5 Uploading (downloading) files is broken/slow

Flow control (both at your PC and/or modem-to-modem) may not be enabled. For the uploading case: If you have set a high DTE speed (like 115.2k) then flow from your modem to your PC may work OK but uploading flow in the other direction will not all get thru due to the telephone line bottleneck. This will result in many errors and the resending of packets. It may thus take far too long to send a file. In some cases, files don't make it thru at all.

For the downloading case: If you're downloading long uncompressed files or web pages (and your modem uses data compression) or if you've set a low DTE speed, then downloading may also be broken due to no flow control.

17.6 For Dial-in I Keep Getting "line NNN of inittab invalid"

Make sure you are using the correct syntax for your version of `init`. The different `init`'s that are out there use different syntax in the `/etc/inittab` file. Make sure you are using the correct syntax for your version of `getty`.

17.7 I Keep Getting: ``Id "S3" respawning too fast: disabled for 5 minutes"

Id "S3" is just an example. In this case look on the line which starts with "S3" in `/etc/inittab` and calls `getty`. This line causes the problem. Make sure the syntax for this line is correct and that the device (`ttyS3`) exists and can be found. If the modem has negated CD and `getty` opens the port, you'll get this error message since negated CD will kill `getty`. Then `getty` will respawn only to be killed again, etc. Thus it respawns over and over (too fast). It seems that if the cable to the modem is disconnected or you have the wrong serial port, it's just like CD is negated. All this can occur when your modem is chatting with `getty`. Make sure your modem is configured correctly. Look at AT commands `E` and `Q`.

If you use `uugetty`, verify that your `/etc/gettydefs` syntax is correct by doing the following:

```
linux# getty -c /etc/gettydefs
```

This can also happen when the `uugetty` initialization is failing. See section [uugetty Still Doesn't Work](#).

17.8 My Modem is Hosed after Someone Hangs Up, or uugetty doesn't respawn

This can happen when your modem doesn't reset when DTR is dropped. Greg Hankins saw his RD and SD LEDs go crazy when this happened. You need to have your modem reset. Most Hayes compatible modems do this with `&D3`, but for USR Courier, SupraFax, and other modems, you must set `&D2` (and `S13=1` for USR Courier). Check your modem manual (if you have one).

17.9 NO DIALTONE

It means exactly what it says. Someone else may be using another telephone on the same line. You also get this error if there is no phone line plugged into the modem, or if the phone line is somehow broken. Try plugging a real telephone into the phone cord used by the modem. Check it for a dialtone.

If for some reason your modem doesn't detect a dialtone, then you can force it to dial anyway by putting `X3` in the `init` string.

17.10 NO CARRIER

This means that the analog sine wave (the carrier) from the other modem isn't present like it should be. If you were already connected, this means that the connection has been lost. There may have been noise on the line or a bad connection. The other modem may have hung up on you for some reason: Perhaps the automatic login process didn't work out OK. Perhaps PPP didn't get started OK. Perhaps a time limit was exceeded.

If you get this error before you get connected, it means that the carrier of the other modem wasn't detected by your modem. This may happen if there is there is no properly working modem on the other end. For example, an answering machine could have picked up your call instead of a modem. NO CARRIER will also happen if

the modems fail to negotiate a protocol to use. This can happen if you have an early V.90 modem that first tries to negotiate a high speed X2 or K56flex protocol. These two protocols are obsolete and some ISP servers will drop the connection (hang up) when this happens since they have no understanding of such protocols and don't wait around long enough for the calling modem to fallback to V.90.

If you force your modem to drop the connection by dropping the DTR signal or sending your modem the hangup signal (ATH) you may get this error message. But in this case you (or your software) wanted to drop the connection so there should be no problem. In this case you are only supposed to get NO CARRIER if data was lost. So for most cases of dropping a connection by hangup (or by dropping DTR) you only get an OK message. Your modem dialer program may not even display that to you.

17.11 uugetty Still Doesn't Work

There is a DEBUG option that comes with `getty_ps`. Edit your config file `/etc/conf.{uu}getty.ttySN` and add `DEBUG=NNN`. Where *NNN* is one of the following combination of numbers according to what you are trying to debug:

D_OPT	001	option settings
D_DEF	002	defaults file processing
D_UTMP	004	utmp/wtmp processing
D_INIT	010	line initialization (INIT)
D_GTAB	020	gettytab file processing
D_RUN	040	other runtime diagnostics
D_RB	100	ringback debugging
D_LOCK	200	uugetty lockfile processing
D_SCH	400	schedule processing
D_ALL	777	everything

Setting `DEBUG=010` is a good place to start.

If you are running `syslogd`, debugging info will appear in your log files. If you aren't running `syslogd` info will appear in `/tmp/getty:ttySN` for debugging `getty` and `/tmp/uugetty:ttySN` for `uugetty`, and in `/var/adm/getty.log`. Look at the debugging info and see what is going on. Most likely, you will need to tune some of the parameters in your config file, and reconfigure your modem.

You could also try `mgetty`. Some people have better luck with it.

17.12 (The following subsections are in both the Serial and Modem HOWTOs)

17.13 My Serial Port is Physically There but Can't be Found

If a physical device (such as a modem) doesn't work at all it's often because it's disabled and has no address (PnP hasn't enabled it) or that it is enabled but is not at the I/O address that `setserial` thinks it's at. Thus it can't be found.

Check the BIOS menus and BIOS messages at boot-time. For the PCI bus use `lspci` or `scanpci`. If it's an ISA bus PnP serial port, try `"pnpdump --dumppregs"` and/or see `Plug-and-Play-HOWTO`. If the port happens to be enabled then the following two paragraphs may help find it:

Using "scanport" (Debian only ??) will scan all ISA bus ports and may discover an unknown port that could be a serial port (but it doesn't probe the port). It could hang your PC. You may try probing with setserial. See [Probing](#). If nothing seems to get thru the port it may be accessible but have a bad interrupt. See [Extremely Slow: Text appears on the screen slowly after long delays](#). Use `setserial -g` to see what the serial driver thinks and check for IRQ and IO address conflicts. Even if you see no conflicts the driver may have incorrect information (view it by "setserial") and conflicts may still exist.

If two ports have the same IO address then probing it will erroneously indicate only one port. Plug-and-play detection will find both ports so this should only be a problem if at least one port is not plug-and-play. All sorts of errors may be reported/observed for devices illegally "sharing" a port but the fact that there are two devices on the same a port doesn't seem to get detected (except hopefully by you). In the above case, if the IRQs are different then probing for IRQs with setserial might "detect" this situation by failing to detect any IRQ. See [Probing](#).

17.14 Extremely Slow: Text appears on the screen slowly after long delays

It's likely mis-set/conflicting interrupts. Here are some of the symptoms which will happen the first time you try to use a modem, terminal, or serial printer. In some cases you type something but nothing appears on the screen until many seconds later. Only the last character typed may show up. It may be just an invisible <return> character so all you notice is that the cursor jumps down one line. In other cases where a lot of data should appear on the screen, only a batch of about 16 characters appear. Then there is a long wait of many seconds for the next batch of characters. You might also get "input overrun" error messages (or find them in logs).

For more details on the symptoms and why this happens see the Serial-HOWTO section: "Interrupt Problem Details".

If it involves Plug-and-Play devices, see also Plug-and-Play-HOWTO.

As a quick check to see if it really is an interrupt problem, set the IRQ to 0 with "setserial". This will tell the driver to use polling instead of interrupts. If this seems to fix the "slow" problem then you had an interrupt problem. You should still try to solve the problem since polling uses excessive computer resources.

Checking to find the interrupt conflict may not be easy since Linux supposedly doesn't permit any interrupt conflicts and will send you a [/dev/ttyS?: Device or resource busy](#) error message if it thinks you are attempting to create a conflict. But a real conflict can be created if "setserial" has told the kernel incorrect info. The kernel has been lied to and thus doesn't think there is any conflict. Thus using "setserial" will not reveal the conflict (nor will looking at /proc/interrupts which bases its info on "setserial"). You still need to know what "setserial" thinks so that you can pinpoint where it's wrong and change it when you determine what's really set in the hardware.

What you need to do is to check how the hardware is set by checking jumpers or using PnP software to check how the hardware is actually set. For PnP run either "pnpdump --dumppregs" (if ISA bus) or run "lspci" (if PCI bus). Compare this to how Linux (e.g. "setserial") thinks the hardware is set.

17.15 Somewhat Slow: I expected it to be a few times faster

Modem-HOWTO

An obvious reason is that the baud rate is actually set too slow. It's claimed that this happened by trying to set the baud rate to a speed higher than the hardware can support (such as 230400).

Another reason may be that whatever is on the serial port (such as a modem, terminal, printer) doesn't work as fast as you thought it did. A 56k Modem seldom works at 56k and the Internet often has congestion and bottlenecks that slow things down. If the modem on the other end does not have a digital connection to the phone line (and uses a special "digital modem" not sold in most computer stores), then speeds above 33.6k are not possible.

Another possible reason is that you have an obsolete serial port: UART 8250, 16450 or early 16550 (or the serial driver thinks you do). See "What are UARTS" in the Serial-HOWTO.

Use "setserial -g /dev/ttyS*". If it shows anything less than a 16550A, this may be your problem. If you think that "setserial" has it wrong check it out. See [What is Setserial](#) for more info. If you really do have an obsolete serial port, lying about it to setserial will only make things worse.

17.16 The Startup Screen Show Wrong IRQs for the Serial Ports.

For non-PnP ports, Linux does not do any IRQ detection on startup. When the serial module loads it only does serial device detection. Thus, disregard what it says about the IRQ, because it's just assuming the standard IRQs. This is done, because IRQ detection is unreliable, and can be fooled. But if and when setserial runs from a start-up script, it changes the IRQ's and displays the new (and hopefully correct) state on the startup screen. If the wrong IRQ is not corrected by a later display on the screen, then you've got a problem.

So, even though I have my `ttys2` set at IRQ 5, I still see

```
ttys02 at 0x03e8 (irq = 4) is a 16550A
```

at first when Linux boots. (Older kernels may show "ttyS02" as "tty02" which is the same as ttyS2). You may need to use `setserial` to tell Linux the IRQ you are using.

17.17 "Cannot open /dev/ttyS?: Permission denied"

Check the file permissions on this port with "ls -l /dev/ttyS?"_ If you own the ttyS? then you need read and write permissions: crw with the c (Character device) in col. 1. If you don't own it then it should show rw- in cols. 8 & 9 which means that everyone has read and write permission on it. Use "chmod" to change permissions. There are more complicated ways to get access like belonging to a "group" that has group permission.

17.18 "Operation not supported by device" for ttyS?

This means that an operation requested by setserial, stty, etc. couldn't be done because the kernel doesn't support doing it. Formerly this was often due to the "serial" module not being loaded. But with the advent of PnP, it may likely mean that there is no modem (or other serial device) at the address where the driver (and setserial) thinks it is. If there is no modem there, commands (for operations) sent to that address obviously don't get done. See [What is set in my serial port hardware?](#)

If the "serial" module wasn't loaded but "lsmod" shows you it's now loaded it might be the case that it's loaded now but wasn't loaded when you got the error message. In many cases the module will automatically load when needed (if it can be found). To force loading of the "serial" module it may be listed in the file: /etc/modules.conf or /etc/modules. The actual module should reside in: /lib/modules/.../misc/serial.o.

17.19 "Cannot create lockfile. Sorry"

When a port is "opened" by a program a lockfile is created in /var/lock/. Wrong permissions for the lock directory will not allow a lockfile to be created there. Use "ls -ld /var/lock/" to see if the permissions are OK: usually rwx for everyone (repeated 3 times). If it's wrong, use "chmod" to fix it. Of course, if there is no "lock" directory no lockfile can be created there. For more info on lockfiles see the Serial-HOWTO subsection: "What Are Lock Files".

17.20 "Device /dev/ttyS? is locked."

This means that someone else (or some other process) is supposedly using the serial port. There are various ways to try to find out what process is "using" it. One way is to look at the contents of the lockfile (/var/lock/LCK...). It should be the process id. If the process id is say 100 type "ps 100" to find out what it is. Then if the process is no longer needed, it may be gracefully killed by "kill 100". If it refuses to be killed use "kill -9 100" to force it to be killed, but then the lockfile will not be removed and you'll need to delete it manually. Of course if there is no such process as 100 then you may just remove the lockfile but in most cases the lockfile should have been automatically removed if it contained a stale process id (such as 100).

17.21 "/dev/tty? Device or resource busy"

This means that the device you are trying to access (or use) is supposedly busy (in use) or that a resource it needs (such as an IRQ) is supposedly being used by another device (the resource is "busy"). This message is easy to understand if it only means that the device is busy (in use). But it often means that a resource is in use. What makes it even more confusing is that in some cases neither the device nor the resources that it needs are actually "busy".

The "resource busy" part often means (example for ttyS2) "You can't use ttyS2 since another device is using ttyS2's interrupt." The potential interrupt conflict is inferred from what "setserial" thinks. A more accurate error message would be "Can't use ttyS2 since the setserial data (and kernel data) indicates that another device is using ttyS2's interrupt". If two devices use the same IRQ and you start up only one of the devices, everything is OK because there is no conflict yet. But when you next try to start the second device (without quitting the first device) you get a "... busy" error message. This is because the kernel only keeps track of what IRQs are actually in use and actual conflicts don't happen unless the devices are in use (open). The situation for I/O address (such as 0x3f8) conflict is similar.

This error is sometimes due to having two serial drivers: one a module and the other compiled into the kernel. Both drivers try to grab the same resources and one driver finds them "busy".

There are two possible cases when you see this message:

1. There may be a real resource conflict that is being avoided.
2. Setserial has it wrong and the only reason ttyS2 can't be used is that setserial erroneously predicts a conflict.

Modem-HOWTO

What you need to do is to find the interrupt `setserial` thinks `ttyS2` is using. Look at `/proc/tty/driver/serial` (if you have it). You should also be able to see it with the "`setserial`" command for `ttyS2`.

Bug in old versions: Prior to 2001 there was a bug which wouldn't let you see it with "`setserial`". Trying to see it would give the same "... busy" error message.

To try to resolve this problem reboot or: exit or gracefully kill all likely conflicting processes. If you reboot: 1. Watch the boot-time messages for the serial ports. 2. Hope that the file that runs "`setserial`" at boot-time doesn't (by itself) create the same conflict again.

If you think you know what IRQ `ttyS2` is using then you may look at `/proc/interrupts` to find what else (besides another serial port) is currently using this IRQ. You might also want to double check that any suspicious IRQs shown here (and by "`setserial`") are correct (the same as set in the hardware). A way to test whether or not it's a potential interrupt conflict is to set the IRQ to 0 (polling) using "`setserial`". Then if the busy message goes away, it was likely a potential interrupt conflict. It's not a good idea to leave it permanently set at 0 since it will put more load on the CPU.

17.22 "Input/output error" from `setserial` or `stty`

You may have typed "`ttys`" instead of "`ttyS`". You will see this error message if you try to use the `setserial` command for any device that is not a serial port. It also may mean that the serial port is in use (busy or opened) and thus the attempt to get/set parameters by `setserial` or `stty` failed. It could also mean that there isn't any serial port at the IO address that `setserial` thinks your port is at.

17.23 Overrun errors on serial port

This is an overrun of the hardware FIFO buffer and you can't increase its size. Bug note (reported in 2002): Due to a bug in some kernel 2.4 versions, the port number may be missing and you will only see "`ttyS`" (no port number). But if devfs notation such as "`tts/2`" is being used, there is no bug. See "Higher Serial Thruput" in the Serial-HOWTO.

17.24 Modem doesn't pick up incoming calls

This paragraph is for the case where a modem is used for both dial-in and dial-out. If the modem generates a DCD (=CD) signal, some programs (but not `mgetty`) will think that the modem is busy. This will cause a problem when you are trying to dial out with a modem and the modem's DCD or DTR are not implemented correctly. The modem should assert DCD only when there is an actual connection (ie someone has dialed in), not when `getty` is watching the port. Check to make sure that your modem is configured to only assert DCD when there is a connection (&C1). DTR should be on (asserted) by the communications program whenever something is using, or watching the line, like `getty`, `kermit`, or some other comm program.

17.25 Port get characters only sporadically

There could be some other program running on the port. Use "`top`" (provided you've set it to display the port number) or "`ps -alxw`". Look at the results to see if the port is being used by another program. Be on the lookout for the `gpm` mouse program which often runs on a serial port.

17.26 Troubleshooting Tools

These are some of the programs you might want to use in troubleshooting:

- "lsof /dev/ttyS*" will list serial ports which are open.
- "setserial" shows and sets the low-level hardware configuration of a port (what the driver thinks it is). See [What is Setserial](#)
- "stty" shows and sets the configuration of a port (except for that handled by "setserial"). See the Serial-HOWTO section: "Stty".
- "modemstat" or "statserial" will show the current state of various modem signal lines (such as DTR, CTS, etc.)
- "irqtune" will give serial port interrupts higher priority to improve performance.
- "hdparm" for hard-disk tuning may help some more.
- "lspci" shows the actual IRQs, etc. of hardware on the PCI bus.
- "pnpdump --dumpregs" shows the actual IRQs, etc. of hardware for PnP devices on the ISA bus.
- Some "files" in the /proc tree (such as ioports, interrupts, and tty/driver/serial).

18. [Flash Upgrades](#)

Many modems can be upgraded by reprogramming their flash memories with an upgrade program which you get from the Internet. By sending this "program" from the PC via the serial port to the modem, the modem will store this program in its non-volatile memory (it's still there when the power is turned off). The instructions on installing it are usually on how to do in under Windows so you'll need to figure out how to do the equivalent under Linux (unless you want to install the upgrade under Windows). Sending the program to the modem is often called a download.

If the latest version of this HOWTO still contains this request (see [New Versions of this HOWTO](#)) please send me your experiences with installing such upgrades that will be helpful to others.

Here's the general idea of doing an upgrade. First, there may be a command that you need to send your modem to tell it that what follows is a flash ROM upgrade. In one case this was AT** You can do this by starting a communications program (such as minicom) and type. First type AT <enter> to see if your modem is there and answers "OK".

Next, you need to send an file (sometimes two files) directly to the modem. Communication programs (such as minicom) often use zmodem or kermit to send files to the modem (and beyond) but these put the file into packets which append headers and you want the exact file sent to the modem, not a modified one. But the kermit communications program has a "transmit" command that will send the file directly (without using the kermit packets) so this is one way to send a file directly. Minicom didn't have this feature in 1998.

Another way to send the file(s) would be to escape from the communications program to the shell (in minicom this is ^AJ) and then: `cat upgrade_file_name > /dev/ttyS2` (if your serial port is ttyS2). Then go back to the communication program (type fg at the command line prompt in minicom) to see what happened.

Here's an example session for a certain Rockwell modem (C-a is ^A):

```
- Run minicom
- Type AT** : see "Download initiated ..."
- C-a J
- cat FLASH.S37 > /dev/modem
- fg : see "Download flash code ..."
```

```
- C-a J
- cat 283P1722.S37 > /dev/modem
- fg : see "Device successfully programmed"
```

19. [Other Sources of Information](#)

19.1 Misc

- man pages for: `agetty(8)`, `getty(1m)`, `gettydefs(5)`, `init(1)`, `isapnp(8)`, `login(1)`, `mgetty(8)`, `setserial(8)`
- Your modem manual (if it exists). Some modems come without manuals.
- [Serial Suite](#) by Vern Hoxie is a collection of blurbs about the care and feeding of the Linux serial port plus some simple programs.
- The Linux serial mailing list. To subscribe, send email to majordomo@vger.rutgers.edu, with `subscribe linux-serial` in the message body. If you send `help` in the message body, you get a help message. The server also serves many other Linux lists. Send the `lists` command for a list of mailing lists.

19.2 Books

I've been unable to find a good up-to-date book on modems.

- The Complete Modem Reference by Gilbert Held, 1997. Contains too much info about obsolete topics. More up-to-date info may be found on the Internet.
- Modems For Dummies by Tina Rathbone, 1996. (Have never seen it.)
- The Modem Technical Guide by Douglas Anderson, 1996.
- Ultimate Modem Handbook by Cass R. Lewart, 1998.
- Black, Uyless D.: Physical Layer Interfaces & Protocols, IEEE Computer Society Press, Los Alamitos, CA, 1996.

19.3 HOWTOs

- Cable-Modem mini-howto
- SuSE ISDN Howto (not a LDP Howto) <http://sol.parkland.cc.il.us/sdb/en/html/isdn.html> or <http://brenner.chemietechnik.uni-dortmund.de/doc/sdb/en/html/isdn.html>
- Linux-Modem-Sharing mini-howto. Computers on a network share a single modem for dial-out (like a shared printer).
- Modems-HOWTO: In French (Not used in creating this Modem-HOWTO)
- NET-3-4-HOWTO: all about networking, including SLIP, CSLIP, and PPP
- PPP-HOWTO: help with PPP including modem set-up
- Serial-HOWTO has info on Multiport Serial Cards used for both terminals and banks of modems. Covers the serial port in more detail than in the HOWTO.
- Serial-Programming-HOWTO: for some aspects of serial-port programming
- Text-Terminal-HOWTO: (including connecting up with modems)
- UUCP-HOWTO: for information on setting up UUCP

19.4 Usenet newsgroups

- comp.os.linux.answers; FAQs, How-To's, READMEs, etc. about Linux.
- comp.os.linux.hardware; Hardware compatibility with the Linux operating system.
- comp.os.linux.setup; Linux installation and system administration.
- comp.dcom.modems; Modems for all OS's

19.5 Web Sites

- Modem List of modems which work/don't_work under Linux
<http://www.idir.net/~gromitkc/winmodem.html>
- [Linux Serial Driver home page](#) Includes info about support for PCI modems.
- Hayes AT modem commands [Technical Reference for Hayes \(tm\) Modem Users](#)
- [AT Command Set and Register Summary for Analog Modem Modules \(Cisco\)](#)
- [Controlling your Modem with AT Commands](#)
- Modem FAQs:
[Navas 28800-56K Modem FAQ](#)
- [Curt's High Speed Modem Page](#)
- Much info on 56k modems [56k Modem = v.Unreliable](#)
- [Links to modem manufacturers](#)
- [More Links to modem manufacturers](#)
- <http://search.fcc.gov/> name="Search for manufacturer by FCC ID">

20. [Appendix A: How Analog Modems Work \(technical\) \(unfinished\)](#)

20.1 Modulation Details

Intro to Modulation

This part describes the modulation methods used for conventional modems. It doesn't cover the high speed PCM methods (modulus conversion) sometimes used by [56k Modems \(V.90, V.92\)](#). But 56k modems also use the modulation methods described here.

Modulation is the conversion of a digital signal represented by binary binary (0 or 1) into an analog signal something like a sine wave. The modulated signal consists pure sine wave "carrier" signal which is modified to convey information. A pure carrier sine wave, unchanging in frequency and voltage, provides no flow of information at all (except that a carrier is present). To make it convey information we modify (or modulate) this carrier. There are 3 basic types of modulation: frequency, amplitude, and phase. They will be explained next.

Frequency Modulation

The simplest modulation method is frequency modulation. Frequency is measured in cycles per second (of a sine wave). It's the count of the number of times the sine wave shape repeats itself in a second. This is the same as the number of times it reaches it peak value during a second. The word "Hertz" (abbreviated Hz) is used to mean "cycles per second".

A simple example of frequency modulation is where one frequency means a binary 0 and another means a 1. For example, for some obsolete 300 baud modems 1070 Hz meant a binary 0 while 1270 Hz meant a binary 1. This was called "frequency shift keying". Instead of just two possible frequencies, more could be used to allow more information to be transmitted. If we had 4 different frequencies (call them A, B, C, and D) then each frequency could stand for a pair of bits. For example, to send 00 one would use frequency A. To send 01, use frequency B; for 10 use C; for 11 use D. In like manner, by using 8 different frequencies we could send 3 bits with each shift in frequency. Each time we double the number of possible frequencies we increase the number of bits it can represent by 1.

Amplitude Modulation

Once one understands frequency modulation example above including the possibilities of representing a few bits by a single shift in frequency, it's easier to understand both amplitude modulation and phase modulation. For amplitude modulation, one just changes the height (voltage) of the sine wave analogous to changing the frequency of the sine wave. For a simple case there could only be 2 allowed amplitude levels, one representing a 0-bit and another representing a 1-bit. As explained for the case of frequency modulation, having more possible amplitudes will result in more information being transmitted per change in amplitude.

Phase Modulation

To change the phase of a sine wave at a certain instant of time, we stop sending this old sine wave and immediately begin sending a new sine wave of the same frequency and amplitude. If we started sending the new sine wave at the same voltage level (and slope) as existed when we stopped sending the old sine wave, there would be no change in phase (and no detectable change at all). But suppose that we started up the new sine wave at a different point on the sine wave curve. Then there would likely be a sudden voltage jump at the point in time where the old sine wave stopped and the new sine wave began. This is a phase shift and it's measured in degrees (deg.) A 0 deg. (or a 360 deg.) phase shift means no change at all while a 180 deg. phase shift just reverses the voltage (and slope) of the sine wave. Put another way, a 180 deg. phase shift just skips over a half-period (180 deg.) at the point of transition. Of course we could just skip over say 90 deg. or 135 deg. etc. As in the example for frequency modulation, the more possible phase shifts, the more bits a single shift in phase can represent.

Combination Modulation

Instead of just selecting either frequency, amplitude, or phase modulation, we may chose to combine modulation methods. Suppose that we have 256 possible frequencies and thus can send a byte (8 bits) for each shift in frequency (since 2 to the 8 power is 256). Suppose also that we have another 256 different amplitudes so that each shift in amplitude represents a byte. Also suppose there are 256 possible phase shifts. Then a certain points in time we may make a shift in all 3 things: frequency, amplitude and phase. This would send out 3 bytes for each such transition.

No modulation method in use today actually does this. It's not practical due to the relatively long time it would take to detect all 3 types of changes. The main problem is that frequent shifts in phase can make it appear that a shift in frequency has happened when it actually didn't.

To avoid this difficulty one may simultaneous change only the phase and amplitude (with no change in frequency). This is called phase–amplitude modulation. It is also called quadrature amplitude modulation (= QAM) since there were only 4 possible phases (quadrature) in early versions of it. This method is used today for the common modem speeds of 14.4k, 28.8k, and 33.6k. The only significant case where this modulation method is not used today is for 56k modems. But even 56k modems exclusively use QAM (phase–amplitude

modulation) in the direction from your PC out the telephone line. Sometimes even the other direction will also fall back to QAM when line conditions are not good enough. Thus QAM (phase-amplitude modulation) still remains the most widely used method on ordinary telephone lines.

20.2 56k Modems (V.90, V.92)

The "modulation" method used for speeds above 33.6k is entirely different than the common phase-amplitude modulation used at 33.6k and below. Since ordinary telephone calls are converted to digital signals at the local offices of the telephone company, the fastest speed that you can send digital data by an ordinary telephone call is the same speed that the telephone company uses over its digital portion of its network (for a phone call). What is this speed? Well, it's close to 64kbps. It would be 64k but sometimes bits are "stolen" for signalling purposes. But if the phone Co. knows that the link is not for voice, bits may not get stolen. The case of 64k will be presented and then it will be explained why the actual speed is lower (56k or less —often significantly less).

Thus 64k is the absolute top speed possible (not counting data compression) for an ordinary telephone call using the digital portion of the circuit that was designed to send digital encodings of the human voice. In order to use 64k, the modems need to either have direct access to the digital portion of the circuit or be able to determine the exact digital signal that generated a received analog signal (and conversely). This task is far too error prone if both sides of a telephone call have only an analog interface to the telephone company. But if one side has a digital interface, then it's possible (in one direction for V.90 and in both directions for V.92). Thus if your ISP has a digital interface to the phone company, the ISP may send out a certain digital signal over the phone lines toward your PC. The digital signal from the ISP gets converted to analog at the local telephone office near your PC's location (perhaps near your home). Then it's your modem's task to try to figure out exactly what that digital signal was. If it could do this then transmission at 64k (the speed of the telephone company's digital signal) is possible in this direction.

What method does the telephone company use to digitally encode analog signals? It uses a method of sampling the amplitude of the analog signal at a rate of 8000 samples per second. Each sample amplitude is encoded as a 8-bit byte. (Note: $8 \times 8000 = 64k$) This is called "Pulse Code Modulation" = PCM. These bytes are then sent digitally on the telephone company's digital circuits where many calls share a single circuit using a time-sharing scheme known as "time division multiplexing". Then finally at a local telephone office near your home, the digital signal is de-multiplexed resulting in the same digital signal as was originally created by PCM. Then this signal is converted back to analog and sent to your home. This analog to digital conversion (and conversely) is done by telephone company hardware called a "codec" (coder/decoder). Each PCM 8-bit byte creates a certain amplitude of the analog signal. Your modem's task is to determine just what that PCM 8-bit byte was, based on the analog amplitude it detects.

This was originally called is called "modulus conversion". It's now often called "PCM"—something since its just like encoding/decoding PCM but with the added problem of sampling at the precise time that the codec generated the analog voltage from the digital PCM code.

In order to determine the digital codes the telephone Co. used to create the analog signal, the modem must sample this analog signal amplitude at exactly the same points in time the phone Co. did when it created the analog signal. To do this an 8kHz clock timing signal is generated with help from a residual 4kHz signal on the analog phone line. The creation of amplitudes to go out to your home/office at 8k amplitudes/sec sort of creates a 4kHz signal. Suppose every other amplitude was of opposite polarity. Then there would be a 4kHz sine-like wave created. Each amplitude is in a sense a 8-bit symbol and when to sample amplitudes is known as "symbol timing". The modem's task is to insure that it's 8kHz clock runs at precisely twice the speed of the 4kHz signal (which could drift slightly off 4kHz) and that the modem's clock is synchronized with that used

Modem-HOWTO

by the telephone company's codec. The actual electronics may use much higher frequency clocks (dividing them down) and take more than a single sample. If you know how this synchronization works, let me know (if this is a recent Modem-HOWTO).

Now the encoding of amplitudes in PCM is not linear. At low amplitudes an increment of 1 in the PCM byte value represents a much smaller increment (delta) in analog signal amplitude than would be the case if the amplitude being sampled were much higher. Thus for low amplitudes it's difficult to distinguish between adjacent byte values. To make it easier to do this (for 56k modems) certain PCM codes representing very low amplitudes are not used. This gives a larger delta between possible amplitudes and makes correct detection of them by your modem easier. Thus half of the amplitude levels are not used (in the downstream direction) by V.90 or V.92. This is tantamount to each symbol (valid amplitude level) representing 7 bits instead of 8. This is where 56k comes from: 7 bits/symbol x 8k symbols/sec = 56k bps. Of course each amplitude symbol is actually generated by 8-bits but only 128 bytes of the possible 256 bytes are actually used by the ISP sender. There is a code table mapping these 128 8-bit bytes to 128 7-bit bytes. It's not just a simple mapping like ignoring the last bit. Thus to send 7 normal data bytes (8-bits) will take 8 of the above mentioned bytes.

But it's a little more complicated than this. If the line conditions are not nearly perfect or if the direction is upstream (V.92 only), then even fewer possible levels (symbols) are used resulting in speeds under 56k. Also due to US government rules prohibiting high power levels on phone lines, certain high amplitude levels can't be used resulting in only about 53.3k at best for "56k" modems in the downstream direction.

Note that the digital part of the telephone network is bi-directional. Two such circuits are used for a phone call, one in each direction. For V.90, the 56k signal is only used in one of these directions: from your ISP to your PC (called the "downstream" direction). For this V.90, the other direction (upstream, from your home/office to the ISP) uses the conventional phase-amplitude modulation scheme with a maximum of 36.6kbps (and not 53.3kbps). For V.92, this upstream direction also uses the PCM method and supports up to 48 kbps. The analog portion of the circuit from your home/office to the nearest telephone Co. office was never intended to be bi-directional since it's only a single twisted pair. But due to sophisticated cancellation methods it's able to convey data simultaneously in both directions as explained in the next subsection. It's claimed that with V.92, it's almost impossible to get maximum throughput in both directions simultaneously due to the difficulties of bi-directional flow on a single circuit.

20.3 Full Duplex on One Circuit

Modern modems are able to both send and receive signals simultaneously. One could call this "bidirectional" or "full duplex". This was once done by using one frequency for sending and another for receiving. Today, the same frequency is used for both sending and receiving. How this works is not easy to comprehend.

Most of the telephone system "main lines" are digital with two channels in use when you make a telephone call. What you say goes over one digital channel and what the other person says goes over the other (reverse) digital channel. Unfortunately, the part of the telephone system which goes to homes (and many offices) is not digital but only a single analog channel. If both modems were directly connected to the digital part of the phone system then bidirectional communication (sending and receiving at the same time) would be no problem because two channels would be available.

But the end portion of the signal path goes over just one circuit. How can there be two-way communication on it simultaneously? It works something like this. Suppose your modem is receiving a signal from the other modem and is not transmitting. Then there's no problem. But if your modem were to start transmitting (with the other received signal still flowing into your modem) it would drown out the received signal. If the transmitted signal was a "solid" voltage wave applied to the end of the line then there is no way any received

signal could be present at that point.

But the transmitter has "internal impedance" and the transmitted signal applied to the end of the line is not solid (or strong enough) to completely eliminate the received signal coming from the other end. Thus while the voltage at the end of the line is mostly the stronger transmitted signal a small part of it is the desired received signal. All that is needed is to filter out this stronger transmitted signal and then what remains will be the signal from the other end which we want. To do this, one only needs to get the pure transmitted signal directly from the transmitter (before it's applied to the line) amplify it a determined amount, and then subtract it from the total signal present at the end of the line. Doing this in the receiver circuits leaves a signal which mostly came from the other end of the line.

20.4 Echo Cancellation

An analog signal traveling down a line in one direction may encounter changes in the line that will cause part of the signal to echo back in the opposite direction. Since the same circuit is used for bi-directional flow of data, such echos will result in garbled reception. One way to ameliorate this problem is to send training signals once in a while to determine the echo characteristic of the line. This will enable one to predict the echos that will be generated by any given signal. Then this prediction method is used to predict what echos the transmitted signal will cause. Then this predicted echo signal is subtracted from the received signal. This cancels out the echoes.

21. [Appendix B: \(Reserved for future use\)](#)

22. [Appendix C: "baud" vs. "bps"](#)

22.1 A simple example

``baud" and ``bps" are perhaps one of the most misused terms in the computing and telecommunications field. Many people use these terms interchangeably, when in fact they are not! bps is simply the number of bits transmitted per second. The baud rate is a measure of how many times per second a signal changes (or could change). For a typical serial port a 1-bit is -12 volts and a 0-bit is +12 v (volts). If the bps is 38,400 a sequence of 010101... would also be 38,400 baud since the voltage shifts back and forth from positive to negative to positive, etc. and there are 38,400 shifts per second. For another sequence say 111000111... there will be fewer shifts of voltage since for three 1's in sequence the voltage just stays at -12 volts yet we say that its still 38,400 baud since there is a possibility that the number of changes per second will be that high.

Looked at another way, put an imaginary tic mark separating each bit (even though the voltage may not change). 38,400 baud then means 38,400 tic marks per second. The tic marks at the instants of permitted change and are actually marked by a synchronized clock signal generated in the hardware but not sent over the external cable.

Suppose that a "change" may have more than the two possible outcomes of the previous example (of +- 12 v). Suppose it has 4 possible outcomes, each represented by a unique voltage level. Each level may represent a pair of bits (such as 01). For example, -12v could be 00, -6v 01, +6v 10 and +12v 11. Here the bit rate is double the baud rate. For example, 3000 changes per second will generate 2 bits for each change resulting in 6000 bits per second (bps). In other words 3000 baud results in 6000 bps.

22.2 Real examples

The above example is overly simple. Real examples are more complicated but based on the same idea. This explains how a modem running at 2400 baud, can send 14400 bps (or higher). The modem achieves a bps rate greater than baud rate by encoding many bits in each signal change (or transition). Thus, when 2 or more bits are encoded per baud, the bps rate exceeds the baud rate. If your modem-to-modem connection is at 14400 bps, it's going to be sending 6 bits per signal transition (or symbol) at 2400 baud. A speed of 28800 bps is obtained by 3200 baud at 9 bits/baud. When people misuse the word baud, they may mean the modem speed (such as 33.6k).

Common modem bps rates were formerly 50, 75, 110, 300, 1200, 2400, 9600. These were also the bps rates over the serial_port-to-modem cables. Today the bps modem-to-modem (maximum) rates are 14.4k, 28.8k, 33.6k, and 56k, but the common rates over the serialPort-to-modem cables are not the same but are: 19.2k, 38.4k, 57.6k, 115.2k, 230.4k. The high speed of 230.4k is (as of late 2000) unfortunately not provided by most new (and old) hardware. Using modems with V.42bis compression (max 4:1 compression), rates up to 115.2k bps are possible for 33.6k modems. 203.2k (4 x 53.3k) is possible for 56k modems.

Except for 56k modems, most modems run at 2400, 3000, or 3200 baud. Even the 56k modems use these bauds for transmission and sometimes fall back to them for reception. Because of the bandwidth limitations on voice-grade phone lines, baud rates greater than 2400 are harder to achieve, and only work under conditions of good phone line quality.

How did this confusion between bps and baud start? Well, back when antique low speed modems were high speed modems, the bps rate actually did equal the baud rate. One bit would be encoded per phase change. People would use bps and baud interchangeably, because they were the same number. For example, a 300 bps modem also had a baud rate of 300. This all changed when faster modems came around, and the bit rate exceeded the baud rate. ``baud" is named after Emile Baudot, the inventor of the asynchronous telegraph printer. One way this problem gets resolved is to use the term "symbol rate" instead of "baud" and thus avoid using the term "baud". However when talking about the "speeds" between the modem and the serial port (DTE speed) baud and the symbol rate are the same. And even "speed" is a misnomer since we really mean flow rate.

23. [Appendix D: Terminal Server Connection](#)

This section was adapted from Text-Terminal-HOWTO.

A terminal server is something like an intelligent switch that can connect many modems (or terminals) to one or more computers. It's not a mechanical switch so it may change the speeds and protocols of the streams of data that go thru it. A number of companies make terminal servers: Xyplex, Cisco, 3Com, Computone, Livingston, etc. There are many different types and capabilities. Another HOWTO is needed to compare and describe them (including the possibility of creating your own terminal server with a Linux PC). Most are used for modem connections rather than directly connected terminals.

One use for them is to connect many modems (or terminals) to a high speed network which connects to host computers. Of course the terminal server must have the computing power and software to run network protocols so it is in some ways like a computer. The terminal server may interact with the user and ask what computer to connect to, etc. or it may connect without asking. One may sometimes send jobs to a printer thru a terminal server.

A PC today has enough computing power to act like a terminal server except that each serial port should have its own hardware interrupt. PC's only have a few spare interrupts for this purpose and since they are hard-wired you can't create more by software. A solution is to use an advanced multiport serial card which has its own system of interrupts (or on lower cost models, shares one of the PC's interrupts between a number of ports). See Serial-HOWTO for more info. If such a PC runs Linux with getty running on many serial ports it might be thought of as a terminal server. It is in effect a terminal server if it's linked to other PC's over a network and if its job is mainly to pass thru data and handle the serial port interrupts every 14 (or so) bytes. Software called "radius" is sometimes used.

Today real terminal servers serve more than just terminals. They also serve PC's which emulate terminals, and are sometimes connected to a bank of modems connected to phone lines. Some even include built-in modems. If a terminal (or PC emulating one) is connected directly to a modem, the modem at the other end of the line could be connected to a terminal server. In some cases the terminal server by default expects the callers to use PPP packets, something that real text terminals don't generate.

24. Appendix E: Digital Modems: ISDN, DSL, RAS

24.1 Introduction

This HOWTO only deals with the common type of analog modem used to connect PC's to ordinary analog telephone lines. The standard definition of a modem is sometimes broadened to include digital "modems". Today direct digital service is now being provided to many homes and offices so that a computer there sends out digital signals directly (well almost) into the telephone lines. But a device is still needed to convert the computer digital signal into the type of digital signal used telephone circuits. This device is sometimes called a modem. While this HOWTO doesn't cover such modems, some links to documents that do may be found at the start of this HOWTO. The next 3 sub-sections: ISDN, DSL and 56k, briefly mention such "modems".

24.2 ISDN "Modems"

Such a "modem" is really a Terminal Adapter (TA). Support for some of them can be built into the kernel 2.4 or added as a module. The kernel documentation has an isdn subdirectory. Configuration might use "isdn-config" GUI. A Debian package "isdnutils" is available. There is SuSE ISDN Howto (not a LDP Howto) which is translated from German <http://sol.parkland.cc.il.us/sdb/en/html/isdn.html> There is an isdn4linux package and a newsgroup: de.alt.comm.isdn4linux. Many of the postings are in German. You might try using a search engine to look for "isdn4linux".

24.3 Digital Subscriber Line (DSL)

DSL uses the existing twisted pair line from your home (etc.) to the local telephone office. This can be used if your telephone line can accept significantly higher speeds than an ordinary modem would use. It replaces the analog-to-digital converter at the local telephone office with a converter which can accept a much faster flow of data (in a different format of course). The device which converts the digital signals from your computer to the signal used to represent digital data on the local telephone line is also called a modem.

24.4 56k Digital-Modems

These are not the 56k modems that people use in their PCs. They are the "modems" at an ISP that these 56k modems connect to. The ISP must be connected directly to the digital system of the telephone company,

otherwise the customers modem can't be used as a 56k modem. The ISP likely has banks of many modems multiplexed onto a high capacity telephone cable that transports a large number of phone calls simultaneously (such as a T1, E1, ISDN PRI, etc.). This requires a concentrator or "remote access server" (RAS). This has previously been done by stand-alone units (like PC's but they cost much more and have proprietary OSs). Now there are some cards one may insert into a PC's PCI bus to do this. See [Digital Modems](#)

25. [Appendix F: Leased Line Modems](#)

See the mini-howto: Leased-Line which covers leased lines where there is no dialtone. Leased line modems are analog and not digital. These special modems are used on lines leased from the telephone company or sometimes on just a long direct wire hookup. They often will also work as ordinary modems but go into leased-line mode when the AT command &L1 is given.

Ordinary modems for a telephone line will not normally work on such a leased line. An ordinary telephone line has about 40-50 volts (known as the "battery") on it when not in use and the conventional modem uses this voltage for transmission. Furthermore, the telephone company has special signals indicating a ring, line busy, etc. Conventional modems expect and respond to these signals. Connecting two such modems by a long cable will not provide the telephone signals on the cable and thus the modems will not work.

Leased-line modems often use a "dumb mode" where they ignore AT commands, disable result reporting, etc. One type of leased line used two pairs of wires (one for each direction) using V.29 modulation at 9600 baud. Some brands of leased line modems are incompatible with other brands.

26. [Appendix G: Fax pixels \(dots\)](#)

Here's some info on the bloated bandwidth required for standard fax including the dot density. You can of course send a fax via your modem if you dial the real telephone number of the recipient.

A4 paper:	216mm (horizontal)	* 297mm (vertical)
normal mode	8dots/mm	* 3.85dots/mm
fine mode		* 7.7dots/mm
extra fine mode		*15.4dots/mm

Each dot is either white or black and thus 1 bit. One sheet of A4 paper using fine mode is $(216*8) * (297*7.7)$ = about 4 million dots. With a compression ratio of 8:1 it takes about 50 seconds at 9600bps for transmission.

27. [Appendix H: Antique Modems](#)

27.1 Introduction

By "antique" I mean modems with speeds of 14.4 kbps or less. Many of them were made in the 1980s. Faster modems are also included if they use a proprietary protocol. This appendix compares the antique modems with the modern ones. You should read it if you are interested in modem history or are intending to actually use an antique modem. Also, many current modems and software still support the old protocols and you might find that these have been configured by mistake.

27.2 Old CCITT (ITU) and Bell Protocols

- Bell 103 300 bps; frequency shift keying = FSK (1962)
- V.21 300 bps; frequency shift keying (used a different frequency than Bell 103) (1964)
- V.23 1200/75 bps and 600/75 bps asymmetric; 75 bps is the reverse channel; frequency shift keying = FSK (1964)
- Bell 212A 1200 bps; quadrature differential phase shift keying = QDPSK = DPSK
- V.22 1200 bps; fallback to 600 bps ; QDPSK = DPSK (1980)
- V.22bis 2400 bps; QAM (1984)
- V.32 9600 bps; QAM (1984 but not widely used until years later)
- V.32bis 14400 bps; QAM (1991)

QAM= Quadrature Amplitude Modulation. The word "Quadrature" is short for "quadrature differential phase shift keying" =QDPSK

27.3 Historical Overview

Teletypes and dumb terminals

Prior to 1960, 110 bps (0.11) modems were used for teletype machines (like an electric typewriter only much more noisy). Then in 1960 AT&T came out with a 300 bps modem (for use on it's phone system). Such slow (and expensive modems) were later mainly used for transmitting data between mainframe computers or for connecting a dumb terminal to a mainframe computer over phone lines. Many dumb terminals didn't even have a screen display, but printed on paper instead.

PCs and BBSs

With the advent of the personal computer (PCs) in the early 1980s, the PC was used like a dumb terminal for connecting to mainframes. But now files could be transferred and one PC could connect to another.

The 1980s saw the rise of the Bulletin Board System (BBS). The public could dial up a BBS with a modem and then downloadable free software, participate in discussions on various topics, play on–line games, etc. It was something like visiting a large Internet site. Many BBSs would have a monthly charge but some were run by volunteers and were free. Many companies established BBSs for customers that contained support information, catalogs, etc. In the early 1990s, BBSs were booming. By the mid 1990s some even offered Internet connections. For some history of BBSs see [Sysops' Corner: History of BBSing](#)

The Internet

Then came the advance of Internet in the mid 1990s which resulted in the demise of the BBSs near the end of the 1990s. Some BBSs became websites, but when BBSs were dying in droves, websites were quite expensive so most BBSs just disappeared. Also, the public was unwilling to pay for using websites like they previously paid for the use of BBSs. There were such a huge number of free websites to visit that subscription BBSs were no longer competitive.

Modems permitted the public to connect to the Internet. In the 1990s Modems became fast, cheap and widely used. Then in the late 1990s, faster non–analog "modems" appeared: ISDN, DSL, and cable. The history of these isn't in this HOWTO.

Speeds

Before V.32 (9600 bps), modems typically had speeds of 300 to 2400 bps. Some super fast ones had much higher speeds (such as 19.2k bps) and used non–standard protocols. To utilize these "fast" ones, both modems for a connection needed to support the same proprietary protocol which often meant that they must be the same brand.

Prior to the V.42 standard for error correction and the V.42bis (1990) standard for data compression, the MNP standards were usually used for both error correction and data compression. An X.PC error correction standard was used on some commercial data networks. Compression and error correction were available on some 2400 bps modems.

>From 1960 to 1980 most modems only had a speed of 300 bps (which was also 300 baud). This is only 0.3kbps. Modern modems are over 100 times faster. Some old–slow modems are still in use so they are not really "antique" quite yet.

27.4 Proprietary protocols, etc.

These were used in order to obtain higher speeds before more standardized higher speeds became established. The modem at the other end needs to support the same protocol for this to work. The dates shown below may be only approximate.

- PEP (Packetized Ensemble Protocol 1985): 18k (at best).
- Turbo PEP: 23k 1994?
- Hayes Express 96: 9.6k (Hayes 1987)
- HST: 9.6k (US Robotics 1986)
- HST: 14.4k (US Robotics 1989)
- HST: 16.8k (US Robotics 1992)
- V.32 terbo: 19.2k (AT&T 1993)
- V.FastClass: 28.8k (Rockwell 1993)
- X2 :57.3k (US Robotics 1997)
- K56: Flex 57.3k (Rockwell 1997)

The PEP used as much bandwidth as feasible by splitting the spectrum into as many as 512 sub–bands. It was supported by Ven–Tel's Pathfinder and Telebit's Trailblazer.

27.5 Autobauding

This term has a few different meanings. In general it means either the automatic adjustment of modem–to–modem speed or of modem–to–serial_port speed.

27.6 Modem–to–modem Speed

Modern modems negotiate the modem–to–modem speed and protocol when they first connect to each other and normally connect to each other at the highest possible speed. If one side can't negotiate, the other side should accept whatever speed and protocol that the fixed side has available. Except that some modern modems may no longer support some of the antique protocols. During negotiations, one modem often must use a lower speed than its maximum in order to connect with the other modem. This is sometimes called "fallback" since one modem falls back to a lower speed (although it never really used its higher speed

Modem-HOWTO

modem-to-modem). This is also called "autobauding" or "automode". Sometimes fallback also happens when both modems automatically lower their speed due to a noisy line. Register S37 in a modem is normally set to enable autobauding but may also be set for a fixed modem-to-modem speed in some modems.

Early modems didn't have such autobauding or fallback. If you have such a modem, it will likely work OK if the other modem you connect to is a modern one that can adjust its speed and protocol to yours. But a problem arises if both modems which want to communicate with each other are both antique and don't support automode. In this case they need to be manually set to the same speed and protocol.

Even when this automode existed, there was sometimes a limited choices of speed (like only 1200/300 bps). In olden days (and even today), a computer dial-in site might have groups of phone lines, where each group which had a specific type modem on it which supported specific speeds and protocols. For example, if you had a 2400 bps Bell 212A modem then you simply only dialed in to certain telephone numbers that supported that speed and protocol. Once a site obtained modems that could support a wider variety of speeds and protocols, then there was no need to have different groups of phone lines.

27.7 Modem-to-serial_port Speed

Same speed required

For old modems (mostly under 9600 bps) the modem-to-serial_port speed had to be the same as the modem-to-modem speed. This was because data flowed straight thru the modem without "speed buffering" (storing bytes) inside the modem. This meant that both the modem's serial port and the computer's serial port had to be set to this speed. That is, both ends of the serial cable had to be set for this speed.

One might erroneously reason that if the serial port speed was higher than the modem-to-modem speed, all would work OK since then there would be no bottleneck in the serial line. This works OK in the direction from the modem to the PC since a higher speed line can have a lower thuput speed due to time spacing between bytes. But disaster strikes for the flow from the PC to the modem since it would flow at a speed faster than the modem could transmit the data. Data would be lost since there is no speed buffering.

Equalizing speed

If a modem had only one modem-to-modem speed (or was set by software or physical switches to only operate at one speed), then this wasn't a problem since one would just set the PC's serial port for this speed. Even if the modem had various modem-to-modem speeds which were set by negotiations with the other modem, there was no problem in setting the modem's serial port speed correctly. It would simply set this port speed to its current modem-to-modem speed. Another way make the speeds equal is for the modem to detect the PC's serial port speed and then set its modem-to-modem speed the same. This will be explained later.

But setting the computer's serial port to the modem-to-modem speed was a problem since the modem has no way to directly give commands to the PC's serial port to change its speed. Only system software can do that. The modem finds out what speed to use based on negotiations with the other modem and thus the change of this serial port speed can't be done in advance. How does the modem communicate its chosen modem-to-modem speed to the system software?

Use "CONNECT" message to set speed

Here's one way to do it. Consider the case of a dial-in modem that others dial into. A getty program will be

Modem-HOWTO

used to send login prompt thru the modems to users. Getty will also be the system software that changes the speed of the serial port and the modem will tell getty what modem-to-modem speed it's using. The modem will do this by sending getty a "CONNECT" message giving the modem-to-modem speed.

But there's one problem here. How does one insure that the "CONNECT" message, which the modem sends to getty via the serial port, is sent at the same speed as the PC's serial port? Here's how it's done.

When the modem is first sent an init string, the modem detects the speed of the computer's serial port and sets its modem-to-serial_port speed to this value. Now it can communicate with getty. The modem senses the serial speed by examining the "AT" at the beginning of the string. This is sometimes also called autobauding. For modern modems, this same modem-to-serial port speed is always retained, even after the modem connects to another modem and regardless of what the modem-to-modem speed is. But for our old modem this serial speed needs to be equal the modem-to-modem speed.

So now, for example, getty gets a CONNECT 2400 from the modem and switches the PC's serial port speed to 2400. The modem also switches its serial port speed to 2400. Now both ends of the modem serial cable are at 2400 and there is no speed mismatch. Then getty sends a login prompt out over the phone line thru the modems. The 2400 bps is now both the modem-to-modem speed and the modem-to-serial_port speed. Problem solved. Mgetty can do this by configuring it for "autobauding".

For dialing out, the same method is used, but now the communication software must handle it instead of getty.

Setting modem-to-modem speeds by the serial speed

Another way to switch modem-to-modem speed was by using a modem feature where the modem would set its modem-to-modem speed to be the same as the modem-to-serial port speed it detected. The Bn AT commands would enable this and determine what protocol to use for each speed. So with this enabled, setting the serial speed by the computer would also set the modem-to-modem speed to be the same. This should result in this modem being inflexible in any speed negotiations between the modems.

Manual bauding

Another (but cruder) way to solve the serial speed problem when dialing in to a site was to get the remote site to change its modem-to-modem speed to match your serial port speed. It works like this: The person trying to login over a modem connection doesn't see any login prompt because of a speed mismatch. So the person trying to login hits a "break" key to send a break signal over the phone line (via modem) to getty on the remote machine. A break signal will always get through even if there is a speed mismatch in a serial line.

The remote getty gets this break signal and switches the remote's serial port to the next speed as specified in its getty configuration file. This new remote serial port speed causes the remote modem to switch to the same modem-to-modem speed as previously configured by the ATB command. Then the local modem would transmit the login prompt over the local's serial line at this speed. If one doesn't see a login prompt, then they hit the break key again and a new speed is tried. This continues until the remote getty finally gets the speed correct (equal to the serial speed set on the local PC) and a login prompt finally displays. Note that PC keyboards have no "break" key but dumb terminal keyboards did. Mgetty, agetty, and uugetty can do this obsolete break method and it's called "manual bauding".

Unsupported speeds

In Linux, there's a problem if the speed is set to a speed not supported by Linux's serial port (for example 7200 bps). You may dial out and connect at 7200 bps (both modem-to-modem and modem-to-serial_port speed) but you only see garbage since Linux doesn't support 7200 on the serial port. Once you connect there is no simple way to hang up because even the +++ escape sequence can't be sent to the modem over a 7200 baud interface.

Modern modems, speed buffering

To dial out by the antique method using some modern modems set &Q0 N0 and S17=5 (if you want 1200 bps). Some of the S17 settings vary with the make of modem. S17=0 is the default that connects the modem way at the highest speed supported.

Modern modems can use almost any serial port speed and it doesn't depend at all on modem-to-modem speed. To do this they employ speed buffering and flow control. Speed buffering means that modems have buffers so that there can be a difference between the modem-to-modem speed and the modem-to-serial_port speed. If the flow entering the modem is faster than the flow exiting it, the excess flow is simply stored in a buffer in the modem. Then to prevent the buffer from overflowing, the modem sends a flow control signal to stop the input flow to the modem. This is true for either direction of flow. See [Flow Control](#) for more details.

27.8 Before AT Commands

Hayes introduced the AT command set and other modem manufacturers adopted it as a standard. Before the AT commands, many modems used dip switches to configure the modem. Another command set is the CCITT V.25bis command set. Some modems supported both CCITT and AT commands. The CCITT V.25bis also specifies how Synchronous modem-to-serial_port communication is to take place using either the ASCII or 8-bit EBCDIC character sets.

27.9 Acoustic-Coupling

This is where one connects a modem to a telephone using audio tones that one can hear. The modem contains a microphone and speaker which "talks" directly into the telephone handset without using any wires. It's "wireless" in a sense but uses sound waves instead of radio waves. The modem speaker is placed in contact with the telephone microphone (on the handset) so that the tones from the modem go into the telephone. The modem microphone, picks up tones from the telephone handset speaker. This scheme is called "acoustic coupling".

A major problem is that outside noises can interfere and cause errors. The advantage is convenience: There are no cables to plug in. Most modems that could do this were only 300 baud, but higher speeds were used too. It's said that 9600 bps didn't work very well using this scheme.

27.10 Data Compression and Error Correction

MNP 2, 3, or 4 were used for error correction. MNP 5 was compression. Modern modems generally use V42 (error correction) and V42bis (compression). Many modems support both MNP and V42.

END OF Modem-HOWTO

